



DAYTONA 675

STREET TRIPLE

STREET TRIPLE R

SERVICE MANUAL

INSPEKTIONSHANDBUCH

MANUEL D'ENTRETIEN

MANUALE DI MANUTENZIONE

モーターサイクル整備説明書

MANUAL DE MANTENIMIENTO

Triumph Daytona 675, Street Triple and Street Triple R Motorcycle Service Manual

Part Number 3856750 issue 1, 06.2009



Service Manual - Daytona 675, Street Triple and Street Triple R

i


Table of Contents

Introduction	
General Information	1
Scheduled Maintenance	2
Cylinder Head	3
Clutch	4
Crankshaft, Connecting Rods and Pistons	5
Balancer	6
Transmission	7
Lubrication	8
Engine Removal/Refit	9
Fuel System/Engine Management	10
Cooling	11
Rear Suspension	12
Front Suspension	13
Brakes	14
Wheels/Tyres	15
Frame and Bodywork	16
Electrical	17

Introduction

Table of Contents

How to use this manualvi
Warnings, Cautions and Notesvi
Tampering with Noise Control System Prohibitedvii
Referencesvii
Dimensionsvii
Repairs and Replacementsvii
Forcevii
Edgesvii
Tightening procedurevii



Introduction

This manual is designed primarily for use by trained technicians in a properly equipped workshop. However, it contains enough detail and basic information to make it useful to the owner who desires to perform his own basic maintenance and repair work. The work can only be carried out if the owner has the necessary hand and special service tools to complete the job.

A basic knowledge of mechanics, including the proper use of tools and workshop procedures is necessary in order to carry out maintenance and repair work satisfactorily. Whenever the owner has insufficient experience or doubts his ability to do the work, an authorised Triumph dealer must undertake all adjustments, maintenance, and repair work.

In order to perform the work efficiently and to avoid costly mistakes, read the text and thoroughly familiarise yourself with procedures before starting work.

All work should be performed with great care and in a clean working area with adequate lighting.

Always use the correct special service tools or equipment specified. Under no circumstances use makeshift tools or equipment since the use of substitutes may adversely affect safe operation.

Where accurate measurements are required, they can only be made using calibrated, precision instruments.

For the duration of the warranty period, an authorised Triumph dealer must perform all repairs and scheduled maintenance.

To maximise the life of your Motorcycle:

- Accurately follow the maintenance requirements of the periodic maintenance chart in the service manual.
- Do not allow problems to develop. Investigate unusual noises and changes in the riding characteristics of the motorcycle. Rectify all problems as soon as possible (immediately if safety related).
- Use only genuine Triumph parts as listed in the parts catalogue/parts microfiche.
- Follow the procedures in this manual carefully and completely. Do not take short cuts.
- Keep complete records of all maintenance and repairs with dates and any new parts installed.
- Use only approved lubricants, as specified in the owner's handbook, in the maintenance of the motorcycle.

How to use this manual

To assist in the use of this manual, the section title is given at the top of each page.

Each major section starts with a contents page, listing the information contained in the section.

The individual steps comprising repair operations are to be followed in the sequence in which they appear.


Adjustment and repair operations include reference to service tool numbers and the associated illustration depicts the tool.


Where usage is not obvious, the tool is shown in use.

Adjustment and repair operations also include reference to wear limits, relevant data, torque figures, specialist information and useful assembly details.

Warnings, Cautions and Notes

Particularly important information is presented in the following form:

 Warning
This warning symbol identifies special instructions or procedures which, if not correctly followed, could result in personal injury, or loss of life.

 Caution
This caution symbol identifies special instructions or procedures which, if not strictly observed, could result in damage to or destruction of equipment.

Note:

- This note symbol indicates points of particular interest for more efficient and convenient operation.

Tampering with Noise Control System Prohibited

Owners are warned that the law may prohibit:

- a) The removal or rendering inoperative by any person other than for purposes of maintenance, repair or replacement, of any device or element of design incorporated into any new vehicle for the purpose of noise control prior to its sale or delivery to the ultimate purchaser or while it is in use; and
- b) the use of the vehicle after such device or element of design has been removed or rendered inoperative by any person.

References

References to the left-hand or right-hand side given in this manual are made when viewing the motorcycle from the rear.

Operations covered in this manual do not always include reference to testing the motorcycle after repair. It is essential that work is inspected and tested after completion and if necessary a road test of the motorcycle is carried out particularly where safety related items are concerned.

Dimensions

The dimensions quoted are to design engineering specification with service limits where applicable.

During the period of running-in from new, certain adjustments may vary from the specification figures given in this manual. These will be reset by the dealer at the 500 mile/800 km service, and thereafter should be maintained at the figures specified in this manual.

Repairs and Replacements

Before removal and disassembly, thoroughly clean the motorcycle. Any dirt entering the engine or other parts will work as an abrasive and shorten the life of the motorcycle. Particular attention should be paid when installing a new part, that any dust or metal filings are cleared from the immediate area.

Force

Common sense should dictate how much force is necessary in assembly and disassembly. If a part seems especially difficult to remove or install, stop and examine what may be causing the problem. Never lever a component as this will cause damage both to the component itself and to the surface being levered against.

Whenever tapping to aid removal of an item is necessary, tap lightly using a hide or plastic faced mallet.

Edges

Watch for sharp edges, especially during engine disassembly and assembly. Protect the hands with industrial quality gloves.

When replacement parts are required, it is essential that only genuine Triumph parts are used.

Safety features and corrosion prevention treatments embodied in the motorcycle may be impaired if other than genuine Triumph parts are fitted. In certain territories, legislation prohibits the fitting of parts not to the manufacturer's specification.

Tightening procedure

Generally, when installing a part with several bolts, nuts or screws, they should all be started in their holes and tightened to a snug fit, evenly and in a cross pattern. This is to avoid distortion of the part and/or causing gas or oil leakage. Conversely, bolts, nuts, or screws, should all be loosened (in sequence if specified) by about a quarter of a turn and then removed.

Where there is a tightening sequence specified in this Service Manual, the bolts, nuts, or screws must be tightened in the order and by the method indicated.

Torque wrench setting figures given in this Manual must be observed. The torque tools used must be of accurate calibration.

Locking devices, where specified, must be fitted. If the efficiency of a locking device is impaired during removal it must be renewed. This applies particularly to micro-encapsulated fixings which must always be replaced if disturbed. Where necessary, the text in this manual will indicate where such a fixing is used.

1 General Information

Table of Contents

Ignition System Safety Precautions	1.4
Dangerous Substances	1.4
Third Party Products	1.4
Fluoroelastomers	1.4
Oils	1.4
Health Protection Precautions	1.4
Environmental Protection Precautions	1.5
Brakes	1.5
Safety Instructions	1.6
Jacking and Lifting	1.6
Precautions against Damage	1.6
Coolant	1.6
Cleaning Components	1.7
Lubrication	1.7
Joints and Joint Faces	1.7
Gaskets, O-rings	1.7
Liquid Gasket, Non-permanent Locking Agent	1.7
Screw Threads	1.7
Locking Devices	1.8
Fitting a Split Pin	1.8
Circlips, Retaining Rings	1.8
Self Locking Nuts	1.8
Encapsulated Bolts	1.8
Oil and Grease Seals	1.8
Press	1.8
Ball Bearings	1.8
Chassis Bearing Lubrication	1.8
Metal bushes	1.10
Fuel Handling Precautions	1.10
General	1.10
Petrol - Gasoline	1.10
Fuel Tank Removal	1.11
Chassis Repairs	1.11

General Information

Electrical Precautions	1.12
Battery Disconnecting	1.12
Disciplines	1.12
Electrical Wires	1.13
Electrical Testing	1.13
Ohm's Law	1.13
Basic Electrical Circuits	1.13
Circuit Diagrams	1.14
Glossary of Circuit Diagram Symbols	1.14
Tracing Circuits	1.15
To Check Continuity:	1.16
To Measure Voltage:	1.16
Splices	1.17
CAN (Controller Area Networking)	1.17
Alternator/Charging System	1.18
Diagnosis - Charging Circuit	1.18
Starting Circuit	1.19
General Fault Finding - Starter Motor and Relay	1.19
Diagnosis - Starter Circuit	1.20
Inspection	1.21
Replacement Parts	1.21
Service Data	1.21
Specification	1.21
Service Tools and Garage Equipment	1.22
Special Service Tools	1.22
Engine	1.27
Cylinder Head & Valves	1.28
Cylinder Head & Valves (continued)	1.29
Camshafts	1.29
Clutch/Primary Drive	1.30
Pistons	1.30
Connecting Rods	1.30
Crankshaft	1.31
Transmission	1.31
Final Drive	1.31
Lubrication	1.32
Ignition System	1.32
Fuel System	1.32
Coolant System	1.33
Suspension	1.33
Fuel Injection System	1.34
Emissions Controls	1.34
Brakes	1.34
Brakes (continued)	1.35
Wheels and Tyres	1.35
Frame	1.36
Electrical Equipment	1.36

General Information

Torque Wrench Settings	1.37
Cylinder Head Area	1.37
Clutch	1.37
Crankshaft and Crankcase, Sprag	1.37
Engine Covers	1.38
Transmission	1.38
Lubrication System	1.38
Final Drive	1.39
Cooling System	1.39
Fuel System, Exhaust System and Airbox	1.39
Fuel System, Exhaust System and Airbox (continued)	1.40
Rear Suspension	1.40
Front Suspension	1.41
Wheels	1.41
Front Brakes	1.41
Rear Brakes	1.42
Frame, Footrests, Control Plates and Engine Mountings	1.42
Electrical	1.43
Bodywork	1.43
Clutch Cable Routing - Daytona 675	1.44
Clutch Cable Routing - Street Triple and Street Triple R	1.45
Throttle Cable Routing - Daytona 675	1.46
Throttle Cable Routing - Street Triple	1.47
Throttle Cable Routing - Street Triple R	1.48
Main Wiring Harness Routing - Daytona 675 up to VIN 381274	1.49
Main Wiring Harness Routing - Daytona 675 from VIN 381275	1.50
Main Wiring Harness Routing - Street Triple and Street Triple R	1.51
Rear Light Harness Routing - Daytona 675	1.52
Front Brake Hose Routing - Daytona 675	1.53
Front Brake Hose Routing - Street Triple	1.54
Front Brake Hose Routing - Street Triple R	1.55
Rear Brake Hose Routing - All Models (Daytona 675 shown)	1.56
Fuel Tank Breather Hose Routing - Daytona 675	1.57
Fuel Tank Breather Hose Routing - Street Triple and Street Triple R	1.58
Fuel Tank Breather Hose Routing - Models with Evaporative Emissions - Daytona 675	1.59
Fuel Tank Breather Hose Routing - Models with Evaporative Emissions - Street Triple and Street Triple R	1.60
Intake Air Flap Vacuum Hose Routing - Daytona 675 only	1.61

Ignition System Safety Precautions

Warning

The ignition system produces extremely high voltages. Do not touch any part of the ignition system or any cables while the engine is running.

An electric shock caused by contact with the ignition system may lead to illness, injury or death.

Warning

Wearers of surgically implanted heart pacemaker devices should not be in close proximity to ignition circuits and or diagnostic equipment.

The ignition system and any diagnostic equipment may interrupt the normal operation of such devices causing illness or death.

Dangerous Substances

Warning

Many liquids and other substances used in motor vehicles are poisonous and should under no circumstances be consumed and should, as far as possible, be kept from contact with the skin. These substances among others include acid, anti-freeze, asbestos, brake fluid, fuel, lubricants, and various adhesives. Always pay close attention to the instructions printed on container labels and obey the instructions contained within. These instructions are included for your safety and well-being.

NEVER DISREGARD THESE INSTRUCTIONS!

Third Party Products

Warning

Many propriety products, such as chemicals, solvents and cleaning agents, will cause damage to components if used incorrectly or inappropriately. Always follow the manufacturer's instructions printed on the product container's labels and obey the instructions given. These instructions are included for your safety and well-being.

Damage to the motorcycle components caused by the incorrect or inappropriate use of chemicals, solvents and cleaning agents may reduce the components efficiency, resulting in loss of motorcycle control and an accident.

Fluoroelastomers

Warning

Fluoroelastomer material is used in the manufacture of various seals in Triumph motorcycles.

In fire conditions involving temperatures greater than 315°C this material will decompose and can then be potentially hazardous. Highly toxic and corrosive decomposition products, including hydrogen fluoride, carbonyl fluoride, fluorinated olefins and carbon monoxide can be generated and will be present in fumes from fires.

In the presence of any water or humidity hydrogen fluoride may dissolve to form extremely corrosive liquid hydrofluoric acid.

If such conditions exist, do not touch the material and avoid all skin contact. Skin contact with liquid or decomposition residues can cause painful and penetrating burns leading to permanent, irreversible skin and tissue damage.

Oils

Warning

The engine and bevel box oils may be hot to the touch. Contact with hot oil may cause the skin to be scalded or burned.

Warning

Prolonged or repeated contact with engine oil can lead to skin dryness, irritation and dermatitis. In addition used engine oil contains potentially harmful contaminants which can cause cancer. Wear suitable clothing and avoid skin contact.

Health Protection Precautions

- Avoid prolonged and repeated contact with oils, particularly used engine oils.
- Wear protective clothing, including impervious gloves where practicable.
- Do not put oily rags in pockets.
- Overalls must be cleaned regularly. Discard heavily soiled clothing and oil impregnated footwear.
- First aid treatment should be obtained immediately for open cuts and wounds. Always be aware of who your nearest first-

aider is and where the medical facilities are kept.

- Use barrier creams, applying before each work period to protect the skin from the effects of oil and grease and to aid removal of the same after completing work.
- Wash with soap and water to ensure all oil is removed (skin cleansers and nail brushes will help). Preparations containing lanolin replace the natural skin oils which have been removed.
- Do not use petrol, kerosene, diesel fuel, gas oil, thinners or solvents for cleaning skin.
- If skin disorders develop, obtain medical advice without delay.
- Where practicable, de-grease components prior to handling.

Warning

Any risk of eye injury must be avoided. Always wear eye protection when using a hammer, air line, cleaning agent or where there is ANY risk of flying debris or chemical splashing.

Environmental Protection Precautions

Caution

Do not pour oil on the ground, down sewers or drains, or into water courses. To prevent pollution of water-courses etc., dispose of used oil sensibly. If in doubt contact your local authority.

Burning of used engine oil in small space heaters or boilers can be recommended only for units of approved design. If in doubt, check with the appropriate local authority and/or manufacturer of the approved appliance.

Dispose of used oil and used filters through authorised waste disposal contractors, to licensed waste disposal sites, or to the waste oil reclamation trade. If in doubt, contact your local authority for advice on disposal facilities.

Brakes

Warning

Brake fluid is hygroscopic which means it will absorb moisture from the air. Any absorbed moisture will greatly reduce the boiling point of the brake fluid causing a reduction in braking efficiency.

Replace brake fluid in line with the routine maintenance schedule. A dangerous riding condition could result if this important maintenance item is neglected!

Do not spill brake fluid onto any area of the bodywork as this will damage any painted or plastic surface.

Always use new brake fluid from a sealed container and never use fluid from an unsealed container or from one that has been previously opened.

Do not mix different brands of fluid. Check for fluid leakage around brake fittings, seals and joints.

Check regularly for brake hose damage.

FAILURE TO OBSERVE ANY OF THE ABOVE WARNINGS MAY REDUCE BRAKING EFFICIENCY LEADING TO AN ACCIDENT.

Warning

If there has been an appreciable drop in the level of the fluid in either brake fluid reservoir, consult your authorised Triumph dealer for advice before riding.

If the brake lever or pedal feels soft when it is applied, or if the lever/pedal travel becomes excessive, there may be air in the brake lines or the brake may be defective.

It is dangerous to operate the motorcycle under such conditions and remedial action must be taken by your authorised Triumph dealer before riding the motorcycle.

Failure to take remedial action may reduce braking efficiency leading to an accident.

Warning

Use only DOT 4 specification brake fluid as listed in the general information section of this manual. The use of brake fluids other than those DOT 4 fluids listed in the general information section may reduce the efficiency of the braking system leading to an accident.

Failure to change the brake fluid at the interval specified in the routine maintenance schedule may reduce braking efficiency resulting in an accident.

Warning

Never use mineral based grease in any part of the braking system or in any area where contact with the braking system is possible. Mineral based grease will damage the hydraulic seals in the calipers and master cylinders.

Damage caused by contact with mineral based grease may reduce braking efficiency resulting in an accident.

Warning

Before installation, all internal brake components should be cleaned and lubricated with clean new DOT 4 brake fluid.

Never use solvents, petrol (gasoline), engine oil, or any other petroleum distillate on internal brake components as this will cause deterioration of the hydraulic seals in the calipers and master cylinders.

A dangerous riding condition leading to loss of motorcycle control and an accident could result if this warning is ignored.

Safety Instructions

Jacking and Lifting

Warning

Always ensure that any lifting apparatus has adequate load and safety capacity for the weight to be lifted. Ensure the motorcycle is well supported to prevent any possibility of the machine falling during lifting or jacking, or while repairs and servicing are carried out.

Never rely on a single means of support when working with the motorcycle. Use additional safety supports and straps to prevent toppling.

Do not leave tools, lifting equipment, spilt oil, etc. in a place where they could become a hazard to health. Always work in a clean, tidy area and put all tools away when the work is finished.

Precautions against Damage

Avoid spilling brake fluid or battery acid on any part of the bodywork. Wash spillages off with water immediately.

Disconnect the battery earth lead before starting work, see ELECTRICAL PRECAUTIONS.

Always use the recommended service tool where specified.

Protect exposed bearing and sealing surfaces, and screw threads from damage.

Coolant

Warning

Coolant mixture, which is blended with anti-freeze and corrosion inhibitors contains toxic chemicals which are harmful to the human body. Never swallow anti-freeze, corrosion inhibitors or any of the motorcycle coolant.

Warning

Do not remove the radiator cap when the engine is hot. When the engine is hot, the coolant inside the radiator is hot and also under pressure. Contact with the pressurised coolant will cause scalds and skin damage.

Caution

The coolant anti-freeze contains a corrosion inhibitor which helps prevent damage to the metal surfaces inside the cooling system. Without this inhibitor, the coolant would 'attack' the metals and the resulting corrosion would cause blockages in the cooling system leading to engine overheating and damage. Always use the correct anti-freeze as specified in the Owner's Handbook. Never use a methanol based anti-freeze as this does not contain the required corrosion inhibition properties.

Caution

Distilled water must be used with the anti-freeze (see specification for anti-freeze) in the cooling system. If hard water is used in the system, it causes scale accumulation in the water passages, and considerably reduces the efficiency of the cooling system. Reduced cooling system efficiency may lead to the engine overheating and engine damage.

Cleaning Components

A high flash-point solvent is recommended to reduce fire hazard.

Always follow container directions regarding the use of any solvent.

Always use the recommended cleaning agent or equivalent.

Do not use degreasing equipment for components containing items which could be damaged by the use of this process. Whenever possible, clean components and the area surrounding them before removal. Always observe scrupulous cleanliness when cleaning dismantled components.

Lubrication

The majority of engine wear occurs while the engine is warming up and before all the rubbing surfaces have an adequate lubrication film. During assembly, oil or grease (whichever is more suitable) should be applied to any rubbing surface, which has lost its lubrication film. Old grease and dirty oil should be cleaned off. This is because used lubricants will have lost some lubrication qualities and may contain abrasive foreign particles.

Use recommended lubricants. Some oils and greases in particular should be used only in certain applications and may be harmful if used in an application for which they are not intended. This manual makes reference to molybdenum disulphide grease in the assembly of certain engine and chassis parts. Always check manufacturer recommendations before using such special lubricants.

Joints and Joint Faces

Assemble joints dry unless otherwise specified in this manual.

If gaskets and/or jointing compound is recommended for use, remove all traces of old jointing material prior to re-assembly. Do not use a tool which will damage the joint faces and smooth out any scratches or burrs on the joint faces using an oil stone. Do not allow dirt or jointing material to enter any tapped holes.

Gaskets, O-rings

Do not re-use a gasket or O-ring once it has been in service. The mating surfaces around the gasket should be free of foreign matter and perfectly smooth to avoid oil or compression leaks.

Liquid Gasket, Non-permanent Locking Agent

Follow manufacturer's directions for cleaning and preparing surfaces where these compounds will be used. Apply sparingly as excessive amounts of sealer may block engine oil passages and cause serious damage.

Prior to re-assembly, blow through any pipes, channels or crevices with compressed air.



Warning

To prevent injury, always use eye, face and ear protection when using compressed air. Always wear protective gloves if the compressed air is to be directed in proximity to the skin.

Screw Threads

Metric threads to ISO standard are used.

Damaged nuts, bolts and screws must always be discarded.

Castellated nuts must not be slackened back to accept a split-pin, except in those recommended cases when this forms part of an adjustment.

Do not allow oil or grease to enter blind threaded holes. The hydraulic action on screwing in the bolt or stud could split the housing.

Always tighten a nut or bolt to the recommended torque figure. Damaged or corroded threads can affect the torque reading.

Unless specified, threaded fixings must always be fitted dry (no lubrication).



Warning

Never lubricate a thread unless instructed to do so.

When a thread of a fixing is lubricated, the thread friction is reduced. When the fixing is tightened, reduced friction will cause overtightening and possible fixing failure.

A fixing which fails in service could cause component detachment leading to loss of control and an accident.

Locking Devices

Always release locking tabs and fit new locking washers, do not re-use locking tabs.

Fitting a Split Pin

Always fit new split-pins of the correct size for the hole in the bolt or stud. Do not slacken back castle nuts when fitting split pin, except in those recommended cases when this forms part of an adjustment.

Always fit new roll pins of an interference fit in the hole.

Circlips, Retaining Rings

Replace any circlips and retaining rings that are removed. Removal weakens and deforms circlips causing looseness in the circlip groove. When installing circlips and retaining rings, take care to compress or expand them only enough to install them.

Always use the correct replacement circlip as recommended in the Triumph Parts Catalogue.

Self Locking Nuts

Self-locking nuts can be re-used, providing resistance can be felt when the locking portion passes over the thread of the bolt or stud.

DO NOT re-use self-locking nuts in critical locations, e.g. suspension components. Always use the correct replacement self-locking nut.

Encapsulated Bolts

An encapsulated bolt can be identified by a coloured section of thread which is treated with a locking agent.

Unless a specified repair procedure states otherwise, encapsulated bolts cannot be reused and **MUST** be replaced if disturbed or removed.



Warning

Failure to replace an encapsulated bolt could lead to a dangerous riding condition. Always replace encapsulated bolts.

Oil and Grease Seals

Replace any oil or grease seals that are removed. Removal will cause damage to an oil seal which, if re-used, would cause an oil leak.

Ensure the surface on which the new seal is to run is free of burrs or scratches. Renew the component if the original sealing surface cannot be completely restored.

Protect the seal from any surface which could cause damage to the seal lips when it is being fitted. Use a

protective sleeve or tape to cover the relevant surface and avoid touching the sealing lip.

Lubricate the sealing lips with a recommended lubricant. This will help to prevent damage in initial use. On dual lippled seals, smear the area between the lips with appropriate grease.

When pressing in a seal which has manufacturer's marks, press in with the marks facing out.

Seals must be pressed into place using a suitable driver. Use of improper tools will damage the seal.

Press

A part installed using a press or driver, such as a wheel bearing, should first be coated with oil or grease on its outer or inner circumference so that it will locate smoothly.

Ball Bearings

When installing a ball bearing, the bearing race which is an interference fit should be pushed by a suitable driver. This prevents severe stress or damage to the load carrying components. Press a ball bearing until it touches the shoulder in the bore or on the shaft.

Press or drift seals to the depth of its housing, with the sealing lip facing the lubricant to be retained if the housing is shouldered, or flush with the face of the housing where no shoulder is provided.

Chassis Bearing Lubrication

Note:

- **This information relates only to bearing lubrication. For the procedures necessary to replace a bearing, always refer to the relevant section of this service manual.**
- **Bearings installed in engine and transmission applications are not covered by this information. Refer to the lubrication chapter or the relevant engine chapter for additional information.**

General

For a bearing to be serviceable for its anticipated life span it must be checked, adjusted and lubricated at regular intervals, as specified in the service schedules given in the owner's handbook and this service manual.

A correctly lubricated bearing will have a film of lubrication that separates the moving parts, disperses heat and protects the bearing surfaces from corrosion.

Note:

- **In all cases, use the lubricant recommended in the service manual.**
- **Grease the bearing, not the cavity where it is located.**

- A bearing that is not regularly checked and lubricated will have a reduced life span.

New Bearings

New bearings are typically protected with an oil preservative to prevent corrosion etc. during storage. This is NOT the lubrication for the bearing but DOES NOT need to be washed off prior to assembly and in-service lubrication.


When lubricating a new bearing with grease the following steps should be taken:

1. Do not clean off the oil preservative.
2. Grease must be forced between the roller elements and the roller cage.
3. Rotate the bearing to ensure that the grease is distributed over the entire circumference of the internal parts.
4. Any excess grease should be smeared on the outside of the rollers.

Lubrication and Checks While Servicing a Bearing

1. Disassemble parts as necessary to access the bearing. Refer to the relevant service manual.
2. Inspect the old grease covering the bearing, looking for signs of bearing damage, i.e. flakes or specks of metal.
3. Remove the old grease.
4. Check the bearing for smooth operation and visually check for corrosion, dents and flaking in the bearing race, rollers or cage. Replace if necessary. Refer to the relevant service manual.

Below/overleaf several common bearing types and the lubrication procedures for each are identified:




eon

Sealed bearings (wheel bearings & swinging arm, depending on the model)

Note:

- Sealed bearings can be identified by their integrated seals.


- Sealed bearings are lubricated for life by the manufacturer.
- Any attempt to change the grease in a sealed bearing will damage the integrated seals. If the seals are damaged dirt and water will ingress and the life of the bearing will be greatly reduced.



eon

Taper bearings (swinging arm & headstock, depending on the model)

1. Grease must be forced between the inner race and the roller carrier.
2. Rotate the bearing to ensure that the grease is distributed over the entire circumference of the internal parts.
3. Any excess grease should be smeared on the outside of the rollers.




eon

Angular contact and ball bearings (headstock)

1. Grease the bearing races and the ball bearing carrier.

2. Rotate the bearing to ensure that the grease is distributed over the entire circumference of the internal parts.



Needle roller bearings (swinging arm, rear hub, rear suspension linkages, depending on the model)

1. Coat the needle rollers with grease.
2. Ensure the needle rollers turn so that the grease is distributed over the entire circumference of the internal parts.
3. Assemble the parts, adjust and check as necessary.

Metal bushes

1. Disassemble the parts as necessary to access the bush. Refer to the relevant service manual.
2. Remove the old grease.
3. Apply fresh grease to the metal bush.

Fuel Handling Precautions

General

The following information provides basic precautions which must be observed if petrol (gasoline) is to be handled safely. It also outlines other areas of risk which must not be ignored. This information is issued for basic guidance only and, if in doubt, appropriate enquiries should be made of your local Fire Officer.

Petrol - Gasoline

When petrol (gasoline) evaporates it produces 150 times its own volume in vapour which when diluted with air becomes a readily ignitable mixture. The vapour is heavier than air and will always fall to the lowest level. It can readily be distributed throughout any indoor environment by air currents, consequently, even a small spillage of petrol (gasoline) is potentially very dangerous.

! Warning

Petrol (gasoline) is highly flammable and can be explosive under certain conditions. When opening the fuel tank cap always observe all the following items:

Turn the motorcycle ignition switch OFF.

Do not smoke.

Always have a fire extinguisher containing FOAM, CO₂, HALON or POWDER close at hand when handling or draining fuel or fuel systems. Fire extinguishers must also be present in areas where fuel is stored.

Always disconnect the vehicle battery, negative (black) lead first, before carrying out dismantling or draining work on a fuel system.

Whenever petrol (gasoline) is being handled, drained, stored or when fuel systems are being dismantled, make sure the area is well ventilated. All potential forms of ignition must be extinguished or removed (this includes any appliance with a pilot light). Any lead-lamps must be flame-proof and kept clear of any fuel spillage.

Warning notices must be posted at a safe distance from the site of the work to warn others that petrol is being openly handled. The notice must instruct the reader of the precautions which must be taken.

Failure to observe any of the above warnings may lead to a fire hazard which could result in personal injury.

Chassis Repairs

Warning

No one should be permitted to repair components associated with petrol/gasoline without first having specialist training on the fire hazards which may be created by incorrect installation and repair of items associated with petrol/gasoline.

Repairs carried out by untrained personnel could bring about a safety hazard leading to a risk of personal injury.

Warning

Draining or extraction of petrol/gasoline from a vehicle fuel tank must be carried out in a well ventilated area.

The receptacle used to contain the petrol/ gasoline must be more than adequate for the full amount of fuel to be extracted or drained. The receptacle should be clearly marked with its contents, and placed in a safe storage area which meets the requirements of local authority regulations.

When petrol/gasoline has been extracted or drained from a fuel tank, the precautions governing naked lights and ignition sources should be maintained.

Failure to observe any of the above warnings could bring about a safety hazard leading to a risk of personal injury.

Fuel Tank Removal

Fuel tanks should have a 'PETROL (GASOLINE) VAPOUR' warning label attached to them as soon as they are removed from the vehicle. In all cases, they must be stored in a secured, marked area.

Warning

If the motorcycle is involved in an accident or collision it must be taken to an authorised Triumph dealer for repair or inspection. Any accident can cause damage to the motorcycle, which if not correctly repaired, may cause a second accident which may result in injury or death.

The frame must not be modified as any modification to the frame such as welding or drilling may weaken the frame resulting in an accident.

Electrical Precautions

The following guidelines are intended to ensure the safety of the operator whilst preventing damage to the electrical and electronic components fitted to the motorcycle. Where necessary, specific precautions are detailed in the relevant sections of this manual which should be referred to prior to commencing repair operations.

Equipment - Prior to commencing any test procedure on the motorcycle ensure that the relevant test equipment is working correctly and any harness or connectors are in good condition, in particular mains leads and plugs.

Warning

The ignition system produces extremely high voltages. Do not touch any part of the ignition system or any cables while the engine is running.

An electric shock caused by contact with the ignition system may lead to illness, injury or death.

Warning

Wearers of surgically implanted heart pacemaker devices should not be in close proximity to ignition circuits and or diagnostic equipment.

The ignition system and any diagnostic equipment may interrupt the normal operation of such devices causing illness or death.

Warning

The battery contains harmful materials. Always keep children away from the battery whether or not it is fitted in the motorcycle.

Do not jump start the battery, touch the battery cables together or reverse the polarity of the cables as any of these actions may cause a spark which would ignite battery gasses causing a risk of personal injury.

High Voltage Circuits - Whenever disconnecting live High Tension (H.T.) circuits always use insulated pliers. Exercise caution when measuring the voltage on the coil terminals while the engine is running, high voltage spikes can occur on these terminals.

Connectors and Harness - The engine of a motorcycle is a particularly hostile environment for electrical components and connectors. Always ensure these items are dry and oil free before disconnecting and connecting test equipment. Never force connectors apart either by using tools or by pulling on the wiring itself. Always ensure locking mechanisms are disengaged before removal and note the orientation to enable correct reconnection. Ensure that

any protective covers and substances are replaced if disturbed.

Having confirmed a component to be faulty, switch off the ignition and disconnect the battery negative (black) lead first. Remove the component and support the disconnected harness. When replacing the component keep oily hands away from electrical connection areas and push connectors home until any locking mechanism becomes fully engaged.

Battery Disconnecting

Before disconnecting the battery, switch off all electrical equipment.

Warning

To prevent the risk of a battery exploding and to prevent damage to electrical components ALWAYS disconnect the battery negative (black) lead first. When reconnecting the battery, always connect the positive (red) lead first, then the negative (black) lead. Always disconnect the battery when working on any part of the electrical system.

Failure to observe the above warnings may lead to electrical damage and a fire hazard which could cause personal injury.

Always ensure that battery leads are routed correctly and are not close to any potential chafing points.

Disciplines

Switch off the ignition prior to making any connection or disconnection in the system. An electrical surge can be caused by disconnecting 'live' connections which can damage electronic components.

Ensure hands and work surfaces are clean and free of grease, swarf, etc. as grease collects dirt which can cause tracking or high-resistance contacts.

Prior to commencing any test, and periodically during any test, touch a good earth to discharge body static. This is because some electronic components are vulnerable to static electricity.

Electrical Wires

All the electrical wires are either single-colour or two-colour and, with only a few exceptions, must be connected to wires of the same colour. On any of the two-colour wires there is a greater amount of one colour and a lesser amount of a second colour. A two-colour wire is identified by first the primary colour and then the secondary colour. For example, a yellow wire with thin red stripes is referred to as a 'yellow/red' wire; it would be a 'red/yellow' wire if the colours were reversed to make red the main colour.

Electrical Testing

For any electrical system to work, electricity must be able to flow in a complete circuit from the power source (the battery) via the components and back to the battery. No circuit means no electrical flow. Once the power has left the positive side of the battery and run through the component it must then return to the battery on its negative side (this is called earth or ground). To save on wiring, connections and space, the negative side of the battery is connected directly to the frame or engine. Around the frame and engine will be various other ground points to which the wiring coming from components will be connected. In the case of the starter motor it bolts directly to the engine, which is bolted to the frame. Therefore the frame and engine also form part of the earth return path.

Ohm's Law

The relationship between voltage, current and resistance is defined by Ohm's Law.

- The potential of a battery is measured in Volts (V).
- The flow of current in a circuit (I) is measured in Amperes.
- The power rating of a consumer is measured in Watts (W).
- The resistance (R) of a circuit is measured in Ohms (Ω).

Ohms law, for practical work can be described as -

$$\frac{\text{Voltage}}{\text{Current}} = \text{Resistance}$$

Power is calculated by multiplying Volts x Amps -

$$\text{Watts} = \text{Volts} \times \text{Amps}$$

By transposing either of these formulae, the value of any unit can be calculated if the other two values are known.

For example, if a battery of 12V is connected to a bulb of 60W:


- the current flowing in the circuit can be calculated by using -

$$\frac{W}{V} = I \quad \frac{60}{12} = 5$$


- the bulb resistance can be calculated by using -

$$\frac{V}{I} = R \quad \frac{12}{5} = 2.4$$

To use either of the following triangles, put your finger over the value you want to find. Multiply the remaining values if side-by-side, or divide if one is over the other.



Basic Electrical Circuits



Basic Circuit Diagram

In the above circuit an electrical reservoir (the battery) is connected via a cable to a terminal on the controlling device (the switch) whose contacts are either open or closed. The other terminal on the switch is connected via a cable to the consumer (the bulb), and the other side of the bulb filament is connected to ground (earth) by another cable. The ground point is usually a part of the frame or engine, to which the battery negative terminal is also connected.

When the switch contacts are open (as shown in the diagram), the circuit is broken and no current flows. When the switch contacts are closed the circuit is made and current flows from the battery positive terminal through the switch contacts and bulb filament to ground. The frame completes the circuit to the battery negative terminal and the bulb illuminates.

Although some circuits on the circuit diagram may at first seem more complicated, it will generally be found that they can be broken down into sections which do not differ greatly from the basic circuit above.

Circuit Diagrams

Circuit diagrams are created to provide a 'picture' of the electrical system and to identify the route taken by each individual wire through the system, in order to identify which components it feeds and which connectors the wire runs through. Circuit diagrams are an essential tool for fault finding, as it is possible to locate start and finish points for a circuit without having to manually trace the wire through the motorcycle itself. Circuit diagrams may look confusing at first but when they are studied closely they soon become logical.

Due to the complex circuits and the number of individual wires, Triumph uses two types of circuit diagram in its service manuals.

- Within the manual conventional circuit diagrams are used to show the layout of the main circuits of the motorcycle. These are: Engine management/ignition, Lighting, Starting and Charging and Auxiliary and Accessory. In these diagrams no attempt is made to show the components of the system in any particular order or position in relation to the motorcycle.
- At the back of the service manual a full colour layout circuit diagram is used to show the main electrical components in a position similar to the actual position on the motorcycle.

Both of these circuit diagrams use similar symbols to illustrate the various system components and will be accompanied by a key to circuit diagram components and wiring colour codes.

Circuit diagrams also depict the inner workings of a switch cube (I.E. which wire connects to which when a switch is turned from one position to another) so that a test of that switch can be made using the wire terminals in the connector instead of disassembling the switch itself.

Glossary of Circuit Diagram Symbols

The following is a description of the symbols found in the circuit diagrams used in all Triumph service manuals.

Connector



This illustration is used to show all multi-plug type electrical connectors on Triumph circuit diagrams. The numbers in the box relate to the terminal numbers of the connector pins. On ECMs with two connectors, the number would be prefixed with the letters 'A' or 'B' to

identify each connector. An additional number outside the box will identify the component.

Diode




An electrical one-way valve. Diodes allow current to flow in one direction but will not allow it to return. The arrow, which forms part of the diode symbol, indicates the direction of current flow.

Electromagnetic Winding (solenoid)




An electromagnetic winding (or solenoid) is used to convert an electrical current into a lateral movement. This can then be used to operate switches (as used in relays) or other components such as fuel injectors or secondary air injection solenoids.

Fuse




A fuse is a device which protects a circuit in the event of a fault. The fuse will 'blow' should a short circuit occur, protecting that circuit from further damage. The number next to the fuse on the circuit diagram indicates the position of the fuse in the fusebox.

Ground or Earth Point



This symbol is used to show ground points. This is the negative connection to either the frame or engine, and is a common cause of intermittent faults due to loose or corroded connections.

Lamp or Bulb




This symbol is used to show all types of light bulbs. The numbers in the box relate to the terminal numbers of the connector pins. An additional number outside the box will identify the component.

LED (Light Emitting Diode)




Triumph use LEDs for the alarm warning light, instrument illumination and warning lights, gear change lights and rear light/brake lights on various models.

Motor



An electric motor. This could be the starter motor or a motor within an actuator, for example within the ABS modulator.

Relay



A relay is effectively an electromagnetic switch. To close the relay contacts and complete the circuit, an electromagnet in the relay is energised which causes the relay contacts to close, making the circuit complete.

Relays are used when the electrical current is too great for a mechanical switch, usually when the switching must be done quickly to prevent arcing across the switch contacts. If a mechanical switch were used, the mechanical switch contacts would quickly burn away.

Resistor



A device placed in a cable to reduce a voltage or restrict the maximum current a device can draw.

Splice




A hard cable joint where two or more cables are joined in the wiring harness. A potential source of both open and short circuits.

Switches

Normally Open




or



Normally Closed




or



Change Over



or




A mechanical device for completing or breaking a circuit. There are three common types of switch: Normally open, normally closed and change-over.

Tracing Circuits


The following is a description of two types of common electrical failures, and some of the methods which may be used to find them.

Open circuit



A break in an electrical circuit - current cannot flow. Usually caused by a break in a wire or cable or by a loose connection. Open circuits can often be intermittent, making diagnosis difficult.

Short circuit



A 'short cut' in an electrical circuit - current by-passes the intended circuit, either to earth or to another, different circuit. Often caused by failure of the cable insulation due to chafing or trapping of the wire. There are two different types of short circuit - short to ground and short to Vbatt.

A short to ground means that the current is going to earth before it reaches the component it is supposed to feed. These are often caused by chafing of the harness to the frame or wires trapped between a bolted component, and will often blow the fuse on that circuit.

General Information

A short to V_{batt} is a short to battery voltage (12 Volts) and is caused by a live power supply wire contacting an adjacent cable. Note that it is also possible for a 5 Volt sensor reference voltage to short to an adjacent circuit, which can also cause electrical failures and DTCs (Diagnostic Trouble Code) to be stored.

When tracing a wire that is suspect, carefully check the circuit diagram before starting. Remember:

- a wire may diverge at a splice and go off to feed other circuits. If these circuits are working, check for wiring faults from the splice onwards.
- the circuit diagram is not an accurate guide to the actual location of the parts when fitted on the bike. It is a schematic diagram of the circuits.
- particularly where engine management items are concerned, the circuit is only completed by the ECM. If the ECM is not connected, the circuit may register as open.


To Check Continuity:



Caution

Ensure the circuit being tested is switched off before measuring continuity. Damage to the Digital Multi Meter (DMM) may result from testing a 'live' circuit with the meter set to resistance (Ω).

In the example below, the ground circuit continuity is being tested from the battery to the frame.




Continuity (resistance) Check

- Locate each end of the wire.
- Set the Digital Multi Meter (DMM) to resistance check (Ω).
- Probe each end of the wire.
- If there is continuity, the meter will usually beep or register the resistance of the cable.

- A high resistance figure could indicate a dirty or corroded connection.
- If there is a break in the wire, the meter will not beep or register a resistance.
- By probing the wire in various places, the position of a high resistance or break in the wire (open circuit) can be narrowed down until it is found.

To Measure Voltage:

In the example below, the circuit voltage is being measured at the bulb positive (+) terminal.



Voltage Check

- Turn the circuit to be tested 'ON'
- Set the Digital Multi Meter (DMM) to Voltage check (V). Ensure the multi meter is set to dc volts for direct current circuits (most circuits) or ac volts for alternating current circuits (typically alternator output voltage tests).
- Set the range of the DMM to the range best suited to the voltage of the circuit being tested (typically 20 volts for most DMMs). Refer to the DMM manufacturers instructions.
- Connect the black (ground) lead of the DMM to a reliable ground connection (usually the battery or frame ground).
- Locate the positive terminal of the wire or component to be tested.
- connect the red (positive) lead of the DMM to the positive terminal.
- Read the voltage from meter.

Splices

Splices are probably the most common cause of wiring faults after connectors. Splices are made where two or more wires come together and diverge in different directions, usually to feed a different circuit.


To locate a splice, it is necessary to peel back the insulation and examine the splice for its integrity. The most common fault is where one of the wires at the joint has come adrift usually causing the circuit it feeds or earths to become 'dead'.

Switches

To check a switch, set the multimeter to resistance/continuity and probe the two pins that form a closed circuit when the switch is pushed. If the switch is working correctly, the resistance should register or the meter will beep.

Relays

All relay cases have a circuit path engraved on them showing the circuit path across the electromagnet and the switch. Before making any checks, first note the pin designations, current paths, and whether or not there is a diode in either circuit path.



Make continuity checks across the electromagnet first, usually from pin 86 (positive) to pin 85 (negative). If a diode appears in the circuit use the diode check on the multimeter (volts scale) in the direction of current flow. If there is no diode, use the resistance check facility. An open circuit or unusually high resistance value indicates a faulty relay.


To check the switch side, apply a 12 volt supply between pins 86 and 85. With the supply connected the relay should be heard to click and there should be continuity between pins 30 and 87. An open circuit indicates a faulty relay.

CAN (Controller Area Networking)

CAN (sometimes called CANbus) is a protocol for data communication between Electronic Control Modules (ECMs). Each ECM on the network is connected by a single pair of twisted wires (or bus) which are used for the transmission of vehicle sensor data. By using CAN, the overall number of system sensors, and the amount of

cabling required to allow ECMs to communicate with each other is greatly reduced.

This saves cost, weight and space, and makes the system more reliable, as the physical number of wires and connections is reduced.



Extract from the circuit diagram showing CAN connection between ECMs

CAN works by each ECM sending out 'packets' of information (such as engine speed or fuel consumption information) on to the network bus (note that the network must be free of data before any ECM is allowed to transmit). This data is given a priority according to its importance (for example 'engine speed' may have a higher priority than 'low fuel level'), so that even if two ECMs send data at the same time, high priority information is always sent first. Lower priority data is then resent after the high priority data has been received by all ECMs on the network.

The receiving ECM confirms the data has been received correctly and that the data is valid, and this information is then used by the ECM as necessary. Specific data not required by an ECM will still be received and acknowledged as correct but then disregarded (for example if an ECM does not require 'clutch switch position' information, this data packet would be ignored).

This allows for a very high speed system of communication, which is also very reliable. Should one ECM fail or transmit corrupted or otherwise incorrect messages, none of the other ECMs on the network will be affected, and after a certain time that ECM will be prevented from transmitting further messages until the fault is rectified. This stops the ECM from clogging the network with incorrect data and preventing other messages from getting through. The fault would then be reported by a DTC (Diagnostic Trouble Code).

Triumph currently use CAN for communication between the engine ECM and the instruments.

Alternator/Charging System


The charging system consists of an alternator and a rectifier/ regulator assembly and the battery. The alternator is made up of two parts, the stator, which is mounted to the crankcase or the engine cover, and the rotor, mounted to the end of the crankshaft. The stator is an assembly of 18 coils, arranged into 3 phases. The rotor is a series of magnets mounted in the engine flywheel, which are arranged so as to be positioned around the outside of the stator coils. As the engine rotates the alternator produces an ac (alternating current) voltage in each of the three phases of the alternator, typically of around 35 to 40 volts ac at 4000-5000 rpm, although this figure varies between models. As the battery requires dc (direct current) voltage for correct charging, this ac voltage must be first rectified to dc current, and then regulated to the correct voltage for the battery of 14.5 ± 0.5 volts. This is done by the rectifier/regulator, which uses diodes to convert the alternator output to dc volts and limit the resulting output to the correct figure required for optimal battery charging.

If the charging circuit does not operate correctly, the following basic checks must be carried out before further diagnosis is performed:

- Check the battery terminals are clean and tight.
- Check the frame and engine earth connections are clean, tight and free from corrosion.
- Ensure the battery is fully charged and in good condition.
- Check that any fuse in the circuit is not blown and is of the correct rating (See page 17-19).

Rectify any defects as necessary.

Diagnosis - Charging Circuit



Starting Circuit

All Triumph models are equipped with an electric start system. This system consists of a starter relay, starter motor, starter switch, sidestand switch, engine stop switch, clutch switch and the sprag clutch. The starter motor is connected to the starter relay and the battery by heavy duty cables in order to supply the large currents required by the motor to start the engine. When the starter button is pressed the relay is energised, which then allows current to the starter motor. The starter motor will not operate unless the clutch lever is pulled in. Also, the starter will not operate if the sidestand is down, unless the transmission is in neutral. If the starter motor does not operate, the following basic checks must be carried out before further diagnosis is performed:

- Check the engine stop switch is in the 'RUN' position.
- Check the battery terminals are clean and tight.

- Check the frame and engine earth connections are clean, tight and free from corrosion.
- Ensure the battery is fully charged and in good condition.
- Check that any fuse in the circuit is not blown and is of the correct rating.
- Using the triumph diagnostic tool, check the operation of the neutral switch or gear position sensor (if fitted), sidestand and clutch switches.

Note:


- On all new models from Daytona 675 onwards, which use a CAN connection between the instruments and the ECM, the engine will not crank if the instruments are disconnected.

Rectify any defects as necessary.

General Fault Finding - Starter Motor and Relay

Symptom	Possible cause(s)
Starter relay does not click, starter motor does not turn	Battery discharged or defective
	Blown main or starter relay fuse
	Defective starter relay wiring or starter switch
	Check that the sidestand, transmission and clutch lever are positioned for engine starting I.E. transmission in neutral, clutch lever pulled in and the sidestand down
	Defective alarm system - ensure any alarm fitted is working correctly
Starter motor turns slowly	Battery discharged or defective
	Loose, corroded or dirty battery connections
	Loose, corroded or dirty starter motor or starter relay connections
	Defective starter motor
Starter relay clicks but engine does not turn over	Loose, corroded or dirty battery ground connections
	Battery discharged or defective
	Crankshaft does not turn due to engine defect
	Defective starter motor
	Starter cable open circuit
Starter motor turns but engine does not turn over	Defective starter relay
	Defective sprag clutch
	Defective idler gear, reduction gear or starter motor

Diagnosis - Starter Circuit



Inspection

Disassembled parts should be visually inspected and replaced with new ones if there are any signs of the following:

Abrasions, cracks, hardening, warping, bending, dents, scratches, colour changes, deterioration, seizure or damage of any nature.

Replacement Parts



Warning

Only Triumph genuine parts should be used to service, repair or convert Triumph motorcycles. To ensure that Triumph genuine parts are used, always order parts, accessories and conversions from an authorised Triumph dealer. The fitting of non-approved parts, accessories or conversions may adversely affect the handling, stability or other aspects of the motorcycle operation which may result in an accident causing serious injury or death.



Warning

Always have Triumph genuine parts, accessories and conversions fitted by an authorised Triumph dealer. The fitting of parts, accessories and conversions by a dealer who is not an authorised Triumph dealer may affect the handling, stability or other aspects of the motorcycle operation which may result in an accident causing serious injury or death.



Warning

Always have Triumph approved parts, accessories and conversions fitted by a trained technician. To ensure that a trained technician is used, have an authorised Triumph dealer fit the parts. The fitting of parts, accessories and conversions by personnel other than a trained technician at an authorised Triumph dealer may affect the handling, stability or other aspects of the motorcycle operation which may result in an accident causing serious injury or death.

Service Data

The service data listed in this manual gives dimensions and specifications for brand new, original parts. Where it is permissible to allow a part to exceed these figures, then the service limit is given.

The terms of the motorcycle warranty will be invalidated by the fitting of other than genuine Triumph parts.

All genuine Triumph parts have the full backing of the motorcycle warranty. Triumph dealers are obliged to supply only genuine Triumph recommended parts.

Specification

Triumph are constantly seeking to improve the specification, design and production of their motorcycles and alterations take place accordingly.

While every effort has been made to ensure the accuracy of this Manual, it should not be regarded as an infallible guide to current specifications of any particular motorcycle.

Authorised Triumph dealers are not agents of Triumph and have no authority to bind the manufacturer by any expressed or implied undertaking or representation.


General Information

Service Tools and Garage Equipment

Special service tools have been developed to facilitate removal, dismantling and assembly of certain mechanical components in a practical manner without causing damage. Some operations in this Service Manual cannot be carried out without the aid of the relevant service tools. Where this is the case, the tools required will be described during the procedure.

Special Service Tools

T3880105 – Angular Torque Gauge




cbxt

T3880057 – Engine Management Diagnostics




T3880315 – Extractor, Cylinder Liner (use with adaptor T3880101)



gakh


T3880027 – Chain Link Tool Kit




cdob

General Information


3880085-T0301 – Fork Piston Holder




T3880102 – Wrench, CamTurning




3880160-T0301 – Fork Filler / Evacuator




T3880026 – Clutch Holding Tool, Universal



T3880375 – Alternator Rotor Holder




T3880313 – Oil Filter Wrench



General Information

T3880101 – Extractor, Cylinder Liners




gakh

T3880365 – Puller, Alternator Rotor




cczh

T3880106 – Holder, Balancer Gear




ccz11

T3880028 – Holder, Damping Cylinder




cdet

T3880104 – Wrench, Swinging Arm Adjuster



cd0a


T3880103 – Wrench, Engine Mounting Adjuster



cd0a1


General Information

T3880023 – Socket 50 mm




cdtp

T3880003 – Fork Seal and Bush Fitment




ccxb

T3880002 – Support Plate




ccxb

T3880067 – Fork Spring Compressor




ccgw

T3880001 – Fuel Pressure Gauge



cdgh

3880065 – T0301 – Bearing Installer





cczb1

General Information



3880070 – T0301 – Bearing Installer

T3880123 – Extension Cable



BatteryMate Battery Charger - See Latest Parts Catalogue
for Part Number Information

T3880053 - Extraction Kit, Wheel Bearing



Full Specification

Daytona 675

Street Triple/Street Triple R

Engine

Engine Configuration	3 Cylinder 12 valve DOHC	3 Cylinder 12 valve DOHC
Arrangement	Transverse in-line	Transverse in-line
Displacement	674.8 cc	674.8 cc
Bore x Stroke	74x52.3 mm	74x52.3 mm
Compression Ratio	12.65:1	12.65:1
Cylinder Numbering	Left to Right (no.3 adjacent to camchain)	Left to Right (no.3 adjacent to camchain)
Cylinder Sequence	Number 1 at left	Number 1 at left
Firing Order	1-2-3	1-2-3
Maximum Power	125 PS (123 bhp) at 12,500 rpm ¹ 128 PS (126 bhp) at 12,600 rpm ²	108.2 PS (106.7 bhp) at 11,700 rpm
Maximum Torque	72 Nm (53.3 ft.lbf) at 11,750 rpm ¹ 73 Nm (53.3 ft.lbf) at 11,900 rpm ²	68 Nm (50.1 ft.lbf) at 9,200 rpm

Note:

- ¹ For Daytona 675 up to VIN 381274.
- ² For Daytona 675 from VIN 381275.

Cylinder Head & Valves

Valve Head Diameter	In	30.50 mm	30.50 mm
	Ex	25.50 mm	25.50 mm
Valve Lift	In	9.25 mm	8.00 mm
	Ex	8.50 mm	7.25 mm
Valve Stem Diameter	In	3.975-3.990 mm	3.975-3.990 mm
Service Limit		3.965 mm	3.965 mm
Valve Stem Diameter	Ex	3.955-3.970 mm	3.955-3.970 mm
Service Limit		3.945 mm	3.945 mm
Valve Guide Bore Diameter	In	4.000-4.015 mm	4.000-4.015 mm
Service Limit		4.043 mm	4.043 mm
Valve Guide Bore Diameter	Ex	4.000-4.015 mm	4.000-4.015 mm
Service Limit		4.043 mm	4.043 mm
Valve Stem to Guide Clearance	In	0.010-0.040 mm	0.010-0.040 mm
Service Limit		0.078 mm	0.078 mm
Valve Stem to Guide Clearance	Ex	0.030-0.060 mm	0.030-0.060 mm
Service Limit		0.098 mm	0.098 mm
Valve Seat Width (in head)	In	0.80-1.20 mm	0.80-1.20 mm
Service Limit		1.50 mm	1.50 mm
Valve Seat Width (in head)	Ex	1.00-1.40 mm	1.00-1.40 mm
Service Limit		1.70 mm	1.70 mm
Valve Seat Width (valve)	In	1.27-1.56 mm ¹	1.27-1.56 mm
	In	1.05-1.34 mm ²	
	Ex	1.34-1.63 mm	1.34-1.63 mm
Valve Seat Angle		45°	45°
Inlet/Exhaust Valve Spring 'Load at Length'		508 N +/-25 N at 27.5 mm	508 N +/-25N at 27.5 mm
Valve Clearance	In	0.10-0.20 mm	0.10-0.20 mm
	Ex	0.275-0.325 mm ¹	0.275-0.325 mm
	Ex	0.325-0.375 mm ²	

Note:

- ¹ For Daytona 675 up to VIN 381274.
- ² For Daytona 675 from VIN 381275.

Full Specification

Daytona 675

Street Triple/Street Triple R

Cylinder Head & Valves (continued)

Valve Bucket Diameter..... In	26.476-26.490 mm ¹	26.476-26.490 mm
	In	25.376-25.390 mm ²
Service Limit.....	26.468 mm ¹	26.468 mm
	25.368 mm ²	
Valve Bucket Diameter..... Ex.....	24.976-24.990 mm ¹	24.976-24.990 mm
	Ex.....	25.376-25.390 mm ²
Service Limit.....	24.968 mm ¹	24.968 mm
	25.368 mm ²	
Valve Bucket Bore Diameter .. In	26.515-26.535 mm ¹	26.515-26.535 mm
	In	25.415-25.435 mm ²
Service Limit.....	26.549 mm ¹	26.549 mm
	25.449 mm ²	
Valve Bucket Bore Diameter .. Ex.....	25.015-25.035 mm ¹	25.015-25.035 mm
	Ex.....	25.415-25.435 mm ²
Service Limit.....	25.049 mm ¹	25.049 mm
	25.449 mm ²	

Camshafts

Cam Timing..... Inlet	Open 27.49° BTDC @ 1.0 mm lift.....	Open 13.23° BTDC @ 1.0 mm lift
	Close 51.49° ABDC @ 1.0 mm lift.....	Close 37.23° ABDC @ 1.0 mm lift
Duration	258.98°	230.46°
Exhaust	Open 43.09° BBDC ¹ @ 1.0 mm lift.....	Open 25.09° BBDC @ 1.0 mm lift
	Open 43.54 BBDC ² @ 1.0 mm lift	
	Close 23.09° ATDC ¹ @ 1.0 mm lift	Close 13.09° ATDC @ 1.0 mm lift
	Close 23.54 ATDC ² @ 1.0 mm lift	
Duration	246.1° ¹	218.18°
	247.08° ²	
Camshaft Journal Diameter.....	23.900-23.930 mm	23.900-23.930 mm
Camshaft Journal Clearance	0.070-0.121 mm	0.070-0.121 mm
Service Limit.....	0.17 mm	0.17 mm
Camshaft Journal Bore Diameter	24.000-24.021 mm	24.000-24.021 mm
Camshaft End Float	0.23-0.33 mm	0.23-0.33 mm
Service Limit.....	0.40 mm	0.40 mm
Camshaft Run-out	0.15 mm max.....	0.15 mm max

Note:

- ¹ For Daytona 675 up to VIN 381274.
- ² For Daytona 675 from VIN 381275.

General Information

Full Specification

Daytona 675

Street Triple/Street Triple R

Clutch/Primary Drive

Primary Drive Type	Gear	Gear
Reduction Ratio	1.848 (46/85)	1.848 (46/85)
Clutch Type	Wet multi-plate	Wet multi-plate
No. of Friction Plates	9	9
Plate Flatness	Within 0.2 mm	Within 0.2 mm
Friction Plate Thickness	3.00 mm	3.00 mm
Service Limit	2.80 mm	2.80 mm
Clutch Actuation Method	Cable	Cable
Cable Free Play (at lever)	2.0-3.0 mm	2.0-3.0 mm

Pistons

Cylinder Bore Diameter	73.985-74.003 mm	73.985-74.003 mm
Service Limit	74.100 mm	74.100 mm
Piston Diameter (at 90° to gudgeon pin)	73.970-73.980 mm	73.964-73.980 mm
Service Limit	73.920 mm	73.920 mm
Piston Ring to Groove Clearances		
Top	0.04-0.08 mm	0.02-0.06 mm
Service Limit	0.095 mm	0.075 mm
Second	0.02-0.06 mm	0.02-0.06 mm
Service Limit	0.075 mm	0.075 mm
Piston Ring End Gaps		
Top	0.10-0.25 mm	0.10-0.25 mm
Service Limit	0.55 mm	0.55 mm
Second	0.25-0.40 mm	0.25-0.40 mm
Service Limit	0.70 mm	0.70 mm
Oil	0.10-0.35 mm	0.10-0.35 mm
Gudgeon Pin Bore Diameter in Piston	16.004-16.012 mm	16.004-16.012 mm
Service Limit	16.040 mm	16.040 mm
Gudgeon Pin Diameter	15.995-16.000 mm	15.995-16.000 mm
Service Limit	15.985 mm	15.985 mm

Connecting Rods

Connecting Rod Small End Diameter	16.016-16.029 mm	16.016-16.029 mm
Service Limit	16.039 mm	16.039 mm
Connecting Rod Big End Side Clearance	0.15-0.30 mm	0.15-0.30 mm
Service Limit	0.50 mm	0.50 mm

Full Specification

Daytona 675

Street Triple/Street Triple R

Crankshaft

Crankshaft Big End Journal Diameter	32.984-33.000 mm	32.984-33.000 mm
Service Limit	32.960 mm	32.960 mm
Crankshaft Big End Bearing Clearance	0.035-0.065 mm	0.035-0.065 mm
Service Limit	0.070 mm	0.070 mm
Crankshaft Main Bearing Journal Diameter	32.984-33.000 mm	32.984-33.000 mm
Service Limit	32.960 mm	32.960 mm
Crankshaft Main Bearing Clearance	0.020-0.044 mm	0.020-0.044 mm
Service Limit	0.070 mm	0.070 mm
Crankshaft End Float	0.15-0.30 mm	0.15-0.30 mm
Crankshaft Run-out	0.02 mm or less	0.02 mm or less
Service Limit	0.05 mm	0.05 mm

Transmission

Type	6 Speed, Constant Mesh	6 Speed, Constant Mesh
Gear Ratios	1st 2.615 (34/13) ¹	2.615 (34/13)
	1st 2.313 (37/16) ²	
	2nd 1.857 (39/21)	1.857 (39/21)
	3rd 1.565 (36/23)	1.565 (36/23)
	4th 1.350 (27/20)	1.350 (27/20)
	5th 1.238 (26/21)	1.238 (26/21)
	6th 1.136 (25/22)	1.136 (25/22)
Gear Selector Fork Thickness	5.9-6.0 mm	5.9-6.0 mm
Service Limit	5.80 mm	5.80 mm
Gear Selector Groove Width	5.80 mm	5.80 mm
Service Limit	6.27 mm	6.27 mm
Gear Selector Fork to Groove Clearance	0.47 mm max	0.47 mm max

Final Drive

Final Drive	Chain	Chain
Final Drive Ratio	2.937 (16/47)	2.937 (16/47)
Chain Type	RK O-ring	RK O-ring
Number of Links	116	116
20 Link Length	319 mm	319 mm
Drive Chain Play	35-40 mm	20-25 mm
Chain Lubrication	Mobil chain spray	Mobil chain spray

Note:

- ¹ For Daytona 675 up to VIN 381274.
- ² For Daytona 675 from VIN 381275.

General Information

Full Specification

Daytona 675

Street Triple/Street Triple R

Lubrication

Type	Pressure Lubrication, Wet Sump	Pressure Lubrication, Wet Sump
Oil Capacity (dry fill)	3.5 litres	3.5 litres
Oil Capacity (wet fill including filter)	3.1 litres	3.1 litres
Oil Capacity (wet fill excluding filter)	2.9 litres	2.9 litres
Recommended Oil Approval Rating	API SH (or higher) and JASO MA	API SH (or higher) and JASO MA
Viscosity	10W/40 or 15W/50	10W/40 or 15W/50
Type	Semi or fully synthetic	Semi or fully synthetic
Oil pressure (in main gallery)	30.0 lb/in ² min. @ 80°C oil temperature @ 5,000 rpm	30.0 lb/in ² min. @ 80°C oil temperature @ 5,000 rpm
Oil Pump Rotor Tip Clearance	0.15 mm	0.15 mm
Service Limit	0.20 mm	0.20 mm
Oil Pump Body Clearance	0.15-0.22 mm	0.15-0.22 mm
Service Limit	0.35 mm	0.35 mm
Oil Pump Rotor End Float	0.04-0.09 mm	0.04-0.09 mm
Service Limit	0.17 mm	0.17 mm

Ignition System

Type	Digital Inductive	Digital Inductive
Electronic Rev Limiter	14,000 (rpm)	13,000 (rpm)
Pick-up Coil Resistance	0.21 KW +/-10% @ 20°C	0.21 KW +/-10% @ 20°C
Ignition Coil Type	Plug-top	Plug-top
Spark Plug Type	NGK CR9EK	NGK CR9EK
Spark Plug Gap	0.7 mm	0.7 mm

Fuel System

Fuel Type	Unleaded, 95 RON (U.S. 89 CLC/AKI)	Unleaded, 91 RON (U.S. 87 CLC/AKI)
Fuel Tank Capacity	17.4 litres	17.4 litres
Low Level Warning Lamp	4 litres remaining	4 litres remaining
Fuel Pump Type	Submerged	Submerged
Fuel Pressure (nominal)	3.0 bar	3.0 bar
Purge Control System	Electronic, via fuel system ECU	Electronic, via fuel system ECU

Full Specification

Daytona 675

Street Triple/Street Triple R

Coolant System

Note:

- Up to VIN 331531 use Triumph HD4X Hybrid OAT coolant when replacing the coolant.
- From VIN 331532 use Triumph HD4X Hybrid OAT coolant when topping up or replacing the coolant.

Coolant Mixture up to VIN 331531	50/50 Distilled water/anti-freeze	50/50 Distilled water/anti-freeze
Coolant Mixture from VIN 331532	50/50 (pre-mixed as supplied pre-mixed as supplied by Triumph)	50/50 (pre-mixed as supplied pre-mixed as supplied by Triumph)
Anti-Freeze Type up to VIN 331531	Mobil anti-freeze	Mobil anti-freeze
Anti-Freeze Type from VIN 331532	Triumph HD4X Hybrid OAT coolant	Triumph HD4X Hybrid OAT coolant
Freezing point	-35°C	-35°C
Cooling System Capacity	2.4 litres	2.2 litres
Radiator Cap Opening Pressure	1.1 bar	1.1 bar
Thermostat Opening Temperature	71°C (nominal)	71°C (nominal)
Cooling Fan Switch On Temperature	103°C	103°C
Temperature Gauge Sensor Resistance	2.9 – 3.3 KΩ @ 15°C	2.9 – 3.3 KΩ @ 15°C

Suspension

Front Fork Travel	110 mm	120 mm
Recommended Fork Oil Grade	Kayaba KHL15-10	Kayaba KHL15-10
Oil Level (fork fully compressed, spring removed)	72 mm (up to VIN 381274) 89 mm (from VIN 381275)	107 mm for Street Triple 93 mm for Street Triple R
Oil Volume (dry fill)	495 cc (up to VIN 381274) 492 cc (from VIN 381275)	465 cc for Street Triple 484 cc for Street Triple R
Fork Pull Through	4 mm	4 mm
Rear Wheel Travel	130 mm	126 mm
Rear Suspension Bearing Grease	Mobil grease HP 222	Mobil grease HP 222

General Information

Full Specification

Daytona 675

Street Triple/Street Triple R

Fuel Injection System

Type	Electronic, sequential	Electronic, sequential
Idle Speed	1200 RPM	1200 RPM
Injector Type	Twin jet, solenoid operated plate valve	Twin jet, solenoid operated plate valve
Throttle	Cable/twist grip/electronic throttle potentiometer	Cable/twist grip/electronic throttle potentiometer
Control Sensors	Barometric pressure, throttle position, coolant temperature, crankshaft position, vehicle speed, lambda sensor, intake air temperature, gear position, MAP	Barometric pressure, throttle position, coolant temperature, crankshaft position, vehicle speed, lambda sensor, intake air temperature, gear position, MAP

Emissions Controls

Catalysts	1, in down pipe	1, in down pipe
Oxygen sensor	Heated, in down pipe	Heated, in down pipe
Secondary Air injection	Solenoid controlled, reed valve type	Solenoid controlled, reed valve type
Evaporative Control	Activated carbon canister (California only)	Activated carbon canister (California only)

Brakes

Front Type	Two hydraulically actuated four piston radial calipers acting on twin discs ¹	Two hydraulically actuated twin piston sliding calipers acting on twin discs
Caliper Piston Diameter	33.96 mm / 30.23 mm ¹ 4 x 32.03 mm ²	2 x 27.00 mm * 33.96 mm / 30.23 mm ‡
Disc Diameter	308 mm	308 mm
Disc Thickness	4 mm	4 mm
Service Limit	3.5 mm	3.5 mm
Disc Run-out	0.3 mm Max	0.3 mm Max
Master Cylinder Diameter	19.05 mm	14.00 mm for Street Triple 19.05 mm for Street Triple R
Recommended Fluid	Mobil universal brake and clutch fluid DOT4	Mobil universal brake and clutch fluid DOT4

Note:

- ¹ For Daytona 675 up to VIN 381274.
- ² For Daytona 675 from VIN 381275.
- * For Street Triple.
- ‡ For Street Triple R

Full Specification

Daytona 675

Street Triple/Street Triple R

Brakes (continued)

Rear Type	Hydraulically actuated single piston caliper, single disc	Hydraulically actuated single piston caliper, single disc
Caliper Piston Diameter	38.18 mm	38.18 mm
Disc Diameter	220 mm	220 mm
Disc Thickness	5.0 mm	5.0 mm
Service Limit	4.5 mm	4.5 mm
Disc Run-out	0.3 mm Max.	0.3 mm Max
Master Cylinder Diameter	14 mm	14 mm
Recommended Fluid	Mobil universal brake and clutch fluid DOT4	Mobil universal brake and clutch fluid DOT4

Wheels and Tyres

Front Wheel Size	MT 3.5 x 17	MT 3.5 x 17
Front Tyre Size	120/70 ZR 17	120/70 ZR 17
Front Tyre Pressure	2.35 Bar (34 lb/in ²)	2.35 Bar (34 lb/in ²)
Recommended Front Tyre	Option 1 ... Option 2 ... Option 3 ... Option 4 ...	Pirelli Dragon Supercorsa Pro ¹ ... Pirelli Diablo Super Corsa SP ² ... Michelin Pilot Power B ¹ ... Dunlop Sportmax Qualifier * Dunlop Qualifier ² ... Bridgestone BT016 F * Dunlop Sportmax Qualifier * Bridgestone BT015 G ‡ Pirelli Dragon Supercorsa Pro * Metzeler M3 C ² Bridgestone BT015 G *
Front Wheel Rim Axial Run-out	0.5 mm	0.5 mm
Front Wheel Rim Radial Run-out	0.5 mm	0.5 mm
Rear Wheel Size	MT 5.5 x 17	MT 5.5 x 17
Rear Tyre Size	180/55 ZR 17	180/55 ZR 17
Rear Tyre Pressure	2.5 Bar (36 lb/ft ²)	2.9 Bar (42 lb/ft ²)
Recommended Rear Tyres	Option 1 ... Option 2 ... Option 3 ... Option 4 ...	Pirelli Dragon Supercorsa Pro ¹ ... Pirelli Diablo Super Corsa SP ² ... Michelin Pilot Power ... Dunlop Sportmax Qualifier * Dunlop Qualifier ² ... Bridgestone BT016 R * Dunlop Sportmax Qualifier * Bridgestone BT014 E ‡ Pirelli Dragon Supercorsa Pro * Metzeler M3 ² Bridgestone BT015 E *
Rear Wheel Rim Axial Run-out	0.5 mm	0.5 mm
Rear Wheel Rim Radial Run-out	0.5 mm	0.5 mm

Note:

- ¹ For Daytona 675 up to VIN 381274.
- ² For Daytona 675 from VIN 381275.
- * For Street Triple.
- ‡ For Street Triple R.

General Information

Full Specification

Daytona 675

Street Triple/Street Triple R

Frame

Frame Type	Twin-spar aluminium	Twin-spar aluminium
Overall Length	2010 mm (79.1 in)	2000 mm (78.7 in) Street Triple 2030 mm (79.9 in) Street Triple R
Overall Width	700 mm (27.5 in)	750 mm (29.5 in) Street Triple 755 mm (29.7 in) Street Triple R
Overall Height	1120 mm (44.1 in)	1165 mm (45.8 in) Street Triple 1185 mm (46.7 in) Street Triple R
Wheelbase	1395 mm (54.9 in)	1390 mm (54.7 in)
Seat Height	825 mm (32.5 in)	810 mm (31.8 in) Street Triple 805 mm (31.7 in) Street Triple R
Rake	23.9°	24.3° Street Triple 23.9° Street Triple R
Trail	89.1 mm	95.3 mm Street Triple 92.4 mm (3.64 in) Street Triple R
Dry Weight	165 kg	167 kg
Maximum Payload (rider, passenger, luggage and accessories)	195 kg	195 kg

Electrical Equipment

Battery Type	YT 7B - BS ¹ YTX 9 - BS ²	YTX9 - BS
Battery Rating	12V - 6.5 Amp. Hour	12V - 8 Amp. Hour
Alternator Rating	33.5 A at 4,000 rpm	33.5 A at 4,000 rpm
Fuses* #1	Dip and main beam headlights, starter relay	15 Amp
Fuses* #2	Ignition switch, starter circuit	10 Amp
Fuses* #3	Auxilliary lighting	5 Amp
Fuses* #4	Indicators, Alarm, Horn	10 Amp
Fuses* #5	Cooling fan	15 Amp
Fuses* #6	Engine management system	20 Amp

*The starter solenoid has an additional 30 Amp fuse, attached directly to the solenoid, beneath the rider's seat.

Note:

- ¹ For Daytona 675 up to VIN 381274.
- ² For Daytona 675 from VIN 381275.

Torque Wrench Settings

Cylinder Head Area

Application	Torque (Nm)	Notes
Cam cover to cylinder head	10	Fit new bolt seals and lubricate with clean engine oil
Secondary air injection valve covers to cam cover	9	
Cam chain tensioner to cylinder head - All models except Daytona 675 from VIN 381275	9	Use new fixings
Cam chain tensioner to cylinder head - Daytona 675 from VIN 381275	9	
Cam chain tensioner to centre bolt - All models except Daytona 675 from VIN 381275	7	
Camshaft bearing caps and camshaft bearing ladder to head	See section 3	
Camshaft sprocket to camshaft	15	Use new fixings
Cylinder head to crankcase (M6 screws)	10	
Cylinder head to crankcase bolts	See section 3	
Sound suppression bolt in head	12	
Spark plug to cylinder head	12	

Clutch

Application	Torque (Nm)	Notes
Clutch cover to crankcase	9	
Clutch centre nut	98	
Clutch pressure plate to centre	10	
Clutch lever clamp bolts to handlebar	12	
Clutch cable adjuster bracket to crankcase	12	

Crankshaft and Crankcase, Sprag

Application	Torque (Nm)	Notes
Crankcase upper to lower (M8 fixings)	See section 6	
Crankcase upper to lower (M6 fixings)	See section 6	
Connecting rod big end nut	See section 6	
Sprag clutch to crankshaft	See section 7	
Camshaft drive sprocket gear to crankshaft	27	Use new fixing

General Information

Engine Covers

Application	Torque (Nm)	Notes
Clutch cover to crankcase	9	
Sprocket cover to crankcase	9	
Alternator cover to crankcase	9	
Crank cover to crankcase	9	
Balancer cover to crankcase	9	

Transmission

Application	Torque (Nm)	Notes
Output sprocket to output shaft	85	Use new tab washer
Detent wheel to selector drum	12	Use a new fixing
Detent arm bolt	12	Use a new fixing
Input shaft bearing carrier	12	Use new fixings
Selector shaft retainer	12	Use new fixings
Spring abutment bolt	20	
Gear position sensor	5	
Gear pedal pinch bolt	9	
Gear pedal pivot bolt	22	Use a new fixing
Gear change rod adjuster nuts	6	

Lubrication System

Application	Torque (Nm)	Notes
Sump to crankcase	12	
Sump drain plug to sump	25	Use a new washer
Oil pressure relief valve to crankcase	15	Apply ThreeBond 1305 to the threads
Low oil pressure warning light switch to crankcase	13	Use new washers
Oil filter to adapter	10	
Heat exchanger to crankcase	59	Use a new sealing washer
Oil pump drive chain retainer plate	9	Use new fixings
Oil pump to crankcase	12	Use new fixings
Oil pump drive sprocket to pump shaft	14	Apply ThreeBond 1374 to the threads
Oil pump rotor cover to pump body bolts	12	
Transmission oil feed pipes to crankcase	12	Use new fixings

Final Drive

Application	Torque (Nm)	Notes
Rear sprocket to sprocket carrier	55	
Rear sprocket studs to sprocket carrier	30	Use new fixings
Chain guard bolts	9	
Chain rubbing strip to swinging arm	9	

Cooling System

Application	Torque (Nm)	Notes
Water pump/oil pump assembly to crankcase	12	Use new fixings
Upper right hand radiator mounting to frame	6	
Upper left hand radiator mounting to frame/steering damper (if fitted)	12	
Lower radiator mounting to radiator	3	
Lower radiator mounting to engine (Daytona 675)	9	
Lower radiator mounting to engine bracket (Street Triple)	9	
Lower radiator engine bracket to water elbow (Street Triple)	12	
Water inlet elbow to head	12	
Thermostat housing to head	9	
Fan to radiator	2.5	
Radiator bleed screw	1.5	
Top hose bleed screw (Street Triple only)	1	
Radiator cowl to radiator	5	

Fuel System, Exhaust System and Airbox

Application	Torque (Nm)	Notes
Fuel tank to frame (front fixing)	9	
Fuel tank to frame (rear fixing)	9	
Fuel tank front bracket to fuel tank	9	
Fuel cap to fuel tank	4	
Fuel pump mounting plate to fuel tank	9	
Throttle body transition piece to cylinder head	12	
Throttle potentiometer to throttle body	2	
Exhaust downpipe to cylinder head	See section 10	
Exhaust downpipe to frame	19	
Exhaust intermediate pipe to frame	22	
Silencer mounting bracket to subframe (Daytona 675)	27	
Silencer mounting bracket to subframe (Street Triple)	15	
Exhaust clamp - header to intermediate pipe	15	
Exhaust clamp - silencer to intermediate pipe (Daytona 675)	15	

General Information

Fuel System, Exhaust System and Airbox (continued)

Application	Torque (Nm)	Notes
Exhaust clamps - silencers to intermediate pipe (Street Triple)	10	
Exhaust valve actuator bracket to frame (Daytona 675)	9	
Exhaust valve actuator to bracket (Daytona 675)	12	
Exhaust valve actuator pulley wheel to Actuator shaft (Daytona 675)	5	Use new fixing
Airbox upper section to lower	1.5	
Air filter to lower airbox	4	Use new fixings
Airbox lower to frame	3	
Airbox trumpet to throttle body	6	
Carbon canister to bracket	3	
Carbon canister bracket to frame	8	
Carbon canister bracket to frame (upper screw - Street Triple only)	4	

Rear Suspension

Application	Torque (Nm)	Notes
Swinging arm spindle bolt	110	
Swinging arm rubbing strip bolts	9	
Chain adjuster locknut	20	
Rear suspension unit upper mounting bolt	48	
Rear suspension unit upper clevis to frame	52	
Rear suspension unit lower mounting bolt	48	
Drag link pivot at frame	48	
Drop links to swinging arm	48	
Swinging arm end-float adjuster sleeve	6	

Front Suspension

Application	Torque (Nm)	Notes
Upper yoke pinch bolt	26	
Lower yoke pinch bolt	20	
Fork top cap	See text	
Upper yoke centre nut	90	
Damping cylinder bolt	See text	Use a new washer
Handlebar clamp to fork (Daytona 675)	26	
Handlebar clamp to riser (Street Triple and Street Triple R)	26	Lubricate threads with engine oil
Handlebar riser to upper yoke (Street Triple and Street Triple R)	35	
Steering damper to lower yoke (Daytona 675 only)	18	
Steering damper to frame bracket (Daytona 675 only)	18	
Steering damper frame bracket to frame (Daytona 675 only)	12	Use new fixings
Steering damper rod lock nut (Daytona 675 only)	20	

Wheels

Application	Torque (Nm)	Notes
Front wheel spindle / axle bolt	65	
Front wheel spindle pinch bolts	22	
Rear wheel spindle / axle bolt	110	

Front Brakes

Application	Torque (Nm)	Notes
Front brake caliper to fork (Daytona 675 and Street Triple R)	35	
Front brake caliper half to caliper half (Daytona 675 and Street Triple R)	22	Use new fixings
Front brake caliper to fork (Street Triple)	28	
Front brake pad retaining pin	18	
Front brake pad retaining pin plug (Street Triple)	3	
Front brake caliper bleed screw	6	
Front brake hose to caliper	25	
Front brake master cylinder to handlebar	12	
Front brake master cylinder reservoir to mounting (Daytona 675 and Street Triple R)	7	
Front brake master cylinder bleed screw	6	
Front brake hose to master cylinder	25	
Front brake disc to wheel	22	Use new fixings

General Information

Rear Brakes

Application	Torque (Nm)	Notes
Rear brake caliper to carrier (M12 fixing)	27	
Rear brake caliper to carrier (M8 fixing)	22	
Rear brake pad retaining pin	18	
Rear brake pad retaining pin plug	3	
Rear brake caliper bleed screw	6	
Rear brake hose to caliper	25	
Rear brake hose clips to swinging arm	6	
Rear brake master cylinder to control plate (includes heel guard)	18	
Rear brake lever to control plate	22	Apply ThreeBond 1360 to the threads
Rear brake master cylinder reservoir to frame	7	
Rear brake hose to master cylinder	25	
Rear brake disc to wheel	22	Use new fixings

Frame, Footrests, Control Plates and Engine Mountings

Application	Torque (Nm)	Notes
Upper crankcase to frame	See section 9	
Lower crankcase to frame	See section 9	
Cylinder head to frame	See section 9	
Engine mounting bracket to frame	See section 9	
Engine mounting bracket to cylinder head	See section 9	
Control plate to frame	27	Use new fixings
Left hand heel guard to control plate (Daytona 675)	9	Apply ThreeBond 1360 to left hand fixings
Left hand heel guard to control plate (Street Triple)	12	
Rear footrest hanger to frame	27	Apply ThreeBond 1360 to threads on Street Triple and Street Triple R only
Side stand mounting bracket	45	
Side stand pivot	20	Apply ThreeBond 1360 to threads
Bank angle indicator	9	Apply ThreeBond 1360 to threads


Electrical

Application	Torque (Nm)	Notes
Alternator rotor to crankshaft	120	
Alternator stator to cover	12	
Alternator regulator to bracket	3	
Alternator regulator bracket to frame	12	
Starter motor to crankcase	10	
Spark plug to cylinder head	12	


Bodywork

Application	Torque (Nm)	Notes
Mirror (Daytona 675)	9	
Mirror (Street Triple)	25	
Rear panels to frame	3	
Front mudguard to forks	6	
Rear mudguard to subframe	4	
Number plate bracket to silencer (Daytona 675)	12	
Number plate bracket to subframe (Street Triple)	23	
Heat shield to silencer (Daytona 675)	6	
Lower fairing fixings (Daytona 675)	See section 16	
Cockpit fixings (Daytona 675)	See section 16	
Windshield fixings (Daytona 675)	0.5	


Clutch Cable Routing - Daytona 675




Clutch Cable Routing - Street Triple and Street Triple R




Throttle Cable Routing - Daytona 675




Throttle Cable Routing - Street Triple



Throttle Cable Routing - Street Triple R




Main Wiring Harness Routing - Daytona 675 up to VIN 381274





General Information

Main Wiring Harness Routing - Daytona 675 from VIN 381275




Main Wiring Harness Routing - Street Triple and Street Triple R






Front Brake Hose Routing - Daytona 675




General Information


Front Brake Hose Routing - Street Triple




Front Brake Hose Routing - Street Triple R




Rear Brake Hose Routing - All Models (Daytona 675 shown)




Fuel Tank Breather Hose Routing - Daytona 675



Fuel Tank Breather Hose Routing - Street Triple and Street Triple R



Fuel Tank Breather Hose Routing - Models with Evaporative Emissions - Daytona 675




A - Purge Hose to Throttle Bodies

B - Breather Hose to Carbon Canister


C - Breather hose - Fuel Tank Filler Drain

General Information

Fuel Tank Breather Hose Routing - Models with Evaporative Emissions - Street Triple and Street Triple R



Intake Air Flap Vacuum Hose Routing - Daytona 675 only



Introduction

Read the entire manual before attempting to operate the motorcycle. The manual contains important information about the motorcycle, its controls, and its operation. It also contains information about the maintenance and safety of the motorcycle. The manual is divided into several sections, including: Introduction, Scheduled Maintenance, Troubleshooting, and Safety. The Scheduled Maintenance section contains information about the maintenance schedule for the motorcycle, including the frequency of oil changes, filter changes, and other maintenance tasks. The Troubleshooting section contains information about the common problems that can occur with the motorcycle, and the steps to take to diagnose and fix these problems. The Safety section contains information about the safety features of the motorcycle, and the steps to take to ensure the safe operation of the motorcycle.

2 Scheduled Maintenance

Table of Contents

Introduction	2.2
Scheduled Maintenance Chart	2.3

Scheduled Maintenance

Introduction

To maintain the motorcycle in a safe and reliable condition, the maintenance and adjustments outlined in this section must be carried out as specified in the schedule of daily checks, and also in line with the scheduled maintenance chart.

Weather, terrain and geographical location affects maintenance. The maintenance schedule should be adjusted to match the particular environment in which the vehicle is used and the demands of the individual owner. For advice on adjusting the service schedule, consult your authorised Triumph dealer.

Warning

In order to correctly carry out the maintenance items listed in the scheduled maintenance chart, special tools and specialist knowledge will be required. As only an authorised Triumph dealer will have this knowledge and equipment, Triumph strongly recommends that your authorised Triumph dealer carries out all scheduled maintenance.

A dangerous riding condition could result from incorrect maintenance leading to loss of motorcycle control and an accident.

Warning

All maintenance is vitally important and must not be neglected. Incorrect maintenance or adjustment may cause one or more parts of the motorcycle to malfunction. A malfunctioning motorcycle is dangerous and may lead to an accident.

Warning

Triumph Motorcycles cannot accept any responsibility for damage or injury resulting from incorrect maintenance or improper adjustment carried out by the owner.

Since incorrect or neglected maintenance can lead to a dangerous riding condition, always have an authorised Triumph dealer carry out the scheduled maintenance of this motorcycle.

Scheduled Maintenance Chart

Operation Description	Every	Odometer Reading in Miles (Kms) or time period, whichever comes first				
		500 (800) 1 month	6,000 (10,000) 1 year	12,000 (20,000) 2 years	18,000 (30,000) 3 years	24,000 (40,000) 4 years
Engine oil cooler - check for leaks	Day	•	•	•	•	•
Engine oil - renew	-	•	•	•	•	•
Engine oil filter - renew	-	•	•	•	•	•
Valve clearances - check	-			•		•
Air cleaner - renew	-			•		•
Engine ECM - check for stored DTCs	-	•	•	•	•	•
Spark plugs - check	-		•		•	
Spark plugs - renew	-			•		•
Throttle bodies - balance	-		•	•	•	•
Throttle cables - check/adjust	Day	•	•	•	•	•
Cooling system - check for leaks	Day	•	•	•	•	•
Coolant level - check/adjust	Day	•	•		•	
Coolant - renew	-			•		•
Fuel system - check for leaks	Day	•	•	•	•	•
Lights, instruments & electrical systems - check	Day	•	•	•	•	•
Steering - check for free operation	Day	•	•	•	•	•
Headstock bearings - check/adjust	-		•	•	•	•
Headstock bearings - lubricate	-			•		•
Forks - check for leaks/smooth operation	Day	•	•	•	•	•
Fork oil - renew	-					•
Brake fluid levels - check	Day	•	•	•	•	•
Brake fluid - renew	-			•		•
Brake pad wear - check	Day	•	•	•	•	•
Brake master cylinders - check for oil leaks	Day	•	•	•	•	•
Brake calipers - check for leaks and seized pistons	Day	•	•	•	•	•
Rear suspension linkage - check/lubricate	-			•		•
Drive chain - lubricate	Every 200 miles (300 kms)					
Drive chain - wear check	Every 500miles (800kms)					
Drive chain slack - check/adjust	Day	•	•	•	•	•
Drive rubbing strip - check	-		•	•	•	•
Fasteners - inspect visually for security	Day	•	•	•	•	•
Wheels - inspect for damage	Day	•	•	•	•	•
Wheel bearings - check for wear/smooth operation		•	•	•	•	•
Tyre wear/tyre damage - check	Day	•	•	•	•	•
Tyre pressures - check/adjust	Day	•	•	•	•	•
Clutch cable - check/adjust	Day	•	•	•	•	•
Secondary air injection system - check	-			•		•
Stand - check operation	Day	•	•	•	•	•
Exhaust butterfly valve cables - check/adjust (Daytona 675 only)	-		•	•	•	•
Secondary exhaust clamp bolts - check/adjust	-	•	•	•	•	•
Fuel and evaporative loss* hoses - renew	-					•

*Evaporative system fitted to California models only.

3 Cylinder Head


Table of Contents

Exploded View - Cylinder Head and Valves.....	3.3
Exploded View - Camshaft Cover.....	3.4
Exploded View - Camshaft and Camshaft Drive - Daytona 675 up to VIN 381274, Street Triple and Street Triple R all VINs.....	3.5
Exploded View - Camshaft and Camshaft Drive - Daytona 675 from VIN 381275.....	3.6
Cylinder Head Description.....	3.7
Camshaft Cover.....	3.7
Removal.....	3.7
Installation.....	3.8
Camshaft Drive Chain Tensioner - all Models.....	3.9
Removal.....	3.9
Installation.....	3.10
Camshaft Drive Chain Tensioner Blade - Daytona 675 - from VIN 381275.....	3.14
Disassembly.....	3.14
Assembly.....	3.14
Camshafts.....	3.15
Removal.....	3.15
Camshaft and Bearing Cap Inspection.....	3.16
Installation.....	3.17
Stage 1.....	3.17
Stage 2.....	3.17
Valve Clearances.....	3.18
Valve Clearance Measurement.....	3.18
Valve Clearance Adjustment.....	3.19
Camshaft Drive Chain.....	3.20
Removal.....	3.20
Inspection.....	3.20
Installation.....	3.21
Cylinder Head.....	3.22
Removal.....	3.22
Inspection.....	3.23
Installation.....	3.23


Cylinder Head

Valves and Valve Stem Seals	3.24
Removal from the Cylinder Head	3.24
Installation	3.25
Valve to Valve Guide Clearance	3.25
Valve Guides	3.25
Valve Face Inspection	3.25


Exploded View - Cylinder Head and Valves



Exploded View - Camshaft Cover




Exploded View - Camshaft and Camshaft Drive - Daytona 675 up to VIN 381274, Street Triple and Street Triple R all VINs



Cylinder Head

Exploded View - Camshaft and Camshaft Drive - Daytona 675 from VIN 381275



Cylinder Head Description

The engine is fitted with an aluminium alloy cylinder head, which carries the camshafts, valves and spark plugs. The cylinder head is cast as a single entity and various components are permanently added after machining.

The camshafts run directly in the head without separate bearings. Valve clearances are adjusted by changing variable thickness shims which sit between the valve tappet bucket and the valves.

The camshafts are driven by a silent-type chain. The chain is guided by two blades and is tensioned by a spring loaded tensioner for Street Triple, Street Triple R and Daytona 675 up to VIN 381274.

For Daytona 675 from VIN 381275 a hydraulic tensioner is fitted to tension the chain. The Hydraulic tensioner is fed oil via a gallery in the cylinder head. The combination of oil pressure and spring pressure pushes the plunger against the tensioner blade which tensions the camshaft drive chain. The hydraulic tensioner has an oil pressure relief valve located in the plunger that is set to open between 12 - 16 bar and when opens sprays oil through a drilling in the tensioner blade onto the camshaft drive chain.

Oil is supplied to the head by an internal gallery. Once supplied to the head, the oil is distributed along internal drillings within the head casting and camshaft.

Single valve springs are used to close both the inlet and exhaust valves. These valve springs have close wound coils at one end to assist in the prevention of valve bounce at high engine speed and to give a smooth valve actuation. When assembling the cylinder head it is important that the close wound, colour coded ends of the springs are fitted downwards (towards the piston). The tip of the inlet valves are hardened to give a long service life.

Due to the methods used to assemble the valve seat and valve guides to the head, these parts cannot be replaced.




Caution

In any of the following operations which necessitate the removal or disconnection of the camshaft drive chain, NEVER turn the engine without the camshaft drive chain and tensioner correctly fitted and adjusted. In the disassembled condition, the pistons will contact the valves if the crankshaft is turned, causing severe engine damage.

Camshaft Cover


Removal

1. Remove the rider's seat (see page 16-17).
2. Disconnect the battery, negative (black) lead first.
3. **Daytona 675 only:** Remove the lower fairings (see page 16-20).
4. Remove the fuel tank (see page 10-89).
5. Remove the airbox (see page 10-95).
6. Remove the ignition coils from the camshaft cover.



1. Ignition coils

7. Detach the secondary air injection hose from the reed valves on top of the camshaft cover (see page 10-135).



1. Spring-close hose clip
2. Secondary air injection hose
3. Reed valve assembly

Cylinder Head


- Remove the throttle bodies, injectors and fuel rail from the cylinder head (see page 10-106).

Note:

- It is not necessary to disconnect the throttle cables. Instead, lay the assembly over the frame during the period when the engine is separated from the frame.
- Progressively release the camshaft cover bolts in the sequence shown below.

Note:

- Two shorter bolts are fitted at the end adjacent to the camshaft drive chain.



Camshaft Cover Bolt Release Sequence

- Remove the camshaft cover from the motorcycle.



Caution


Never use a lever to remove the camshaft cover from the head.

Using a lever will cause damage to the head and camshaft cover which could lead to an oil leak.

- Remove the camshaft cover gasket. If necessary, recover the three dowels from the secondary air injection holes in the camshaft ladder (these may come away in the camshaft cover or gasket).
- Discard the camshaft cover gasket and bolt seals.
- Remove any residual oil from the front of the head using a syringe or lint free cloth.


Installation

- Refit the three dowels to the camshaft ladder.



1. Dowels

- Fit a new camshaft cover seal to the cylinder head. Ensure the groove in the gasket is correctly seated to the head. Ensure the plug tower seals and the dowels are correctly located.



10v


1. Camshaft cover seal

2. Dowels

3. Plug tower seals


- Fit the camshaft cover, ensuring that the gasket remains in the correct position.
- Lubricate the new camshaft cover screw seals with clean engine oil. Fit the camshaft cover screws and screw seals and tighten until finger tight.
- Finally, tighten the camshaft cover screws, in the same order as for removal, to **10 Nm**.
- Refit the throttle bodies, injectors and fuel rail to the cylinder head (see page 10-108).
- Check the throttle cable adjustment (see page 10-103).

8. Refit the secondary air injection hose to the reed valves (see page 10-136).



1. Spring-close hose clip
2. Secondary air injection hose
3. Reed valve assembly

9. Inspect the ignition coils seal for damage and replace if necessary.
10. Fit the ignition coils and reconnect the electrical connectors.




1. Coils

11. Refit the airbox (see page 10-96).
12. Refit the fuel tank (see page 10-90).
13. **Daytona 675 only:** Refit the lower fairings (see page 16-22).
14. Reconnect the battery, positive (red) lead first.
15. Refit the rider's seat (see page 16-17).

Camshaft Drive Chain Tensioner - all Models


Removal

1. Remove the camshaft cover (see page 3-7).
2. Noting the position of the bolt fitted with the copper washer, remove the right hand crank cover. Discard the gasket.



1. Right hand crank cover
2. Copper washer position

3. Rotate the crankshaft clockwise (the normal direction of rotation), using the bolt fitted to the end of the crankshaft. Stop rotation when number 1 cylinder is at top dead centre (TDC), that is when the 'dot' mark on the primary gear aligns with the line on the crankcase.




1. 'Dot' mark
2. Marker line

Cylinder Head

Note:

- In addition to the 'dot' mark alignment, at TDC, the alignment marks on the camshaft sprockets will point inwards at a point level with the joint face.



gaaa1

Camshaft to Cylinder Head Alignment Marks


- Place a suitable wedge between the camshaft drive chain tensioner blade and crankcase, to hold the camshaft drive chain taut during removal of the tensioner.
- The Daytona 675 from VIN 381275 has a hydraulic tensioner. All other models have a spring loaded tensioner.
For engines fitted with the spring loaded tensioner, continue from step 6 to 7.
For engines fitted with the hydraulic tensioner, continue from step 8 to 9.

Engines Fitted with the Spring Loaded Tensioner

Warning

The tensioner centre nut is under spring tension. Always wear hand, eye and face protection when withdrawing the centre nut and take great care in order to minimise the risk of injury and loss of components.

- Carefully remove the centre nut from the tensioner and withdraw the tensioner spring.



1. Centre nut

2. Spring

- Remove and discard the bolts securing the tensioner to the cylinder head. Remove the tensioner.

Engines Fitted with the Hydraulic Tensioner

Warning

The hydraulic tensioner is under spring tension. Always wear hand, eye, and face protection when withdrawing the tensioner mounting bolts and take great care to minimise the risk of injury and loss of components.

Note:


- Note the orientation of the hydraulic tensioner.
- Evenly release the hydraulic tensioner mounting bolts until the plunger spring tension has been released.
 - Remove the hydraulic tensioner and discard the O-ring and gasket.

Installation

- Check that number 1 cylinder is still at top dead centre (TDC).
- Ensure that the wedge fitted earlier is still holding the camshaft drive chain tensioner blade in contact with the camshaft drive chain. Check that the camshaft timing marks point inwards and are level with the joint face of the head.
- For engines fitted with the spring loaded tensioner, continue from step 4 to step 8. Then continue from step 21.
For engines fitted with the hydraulic tensioner, continue from step 9.

Engines Fitted with the Spring Loaded Tensioner

4. Check that the camshaft drive chain tensioner O-ring is not worn or damaged. If worn or damaged, replace the O-ring.
5. Set the tensioner plunger onto the first tooth of the ratchet (i.e. minimum extension) by manually lifting the tensioner pawl.



gabh

Tensioner Plunger Set-up

6. Fit the tensioner, complete with a new O-ring if necessary, to the cylinder head (ratchet facing upwards) and tighten the new retaining bolts to **9 Nm**.
7. Fit the sealing washer to the centre bolt. Using finger pressure only, push the ratchet section of the tensioner into firm contact with the tensioner blade. Refit the spring and centre nut to the tensioner. Tighten the centre nut to **7 Nm**.
8. Remove the camshaft drive chain tensioner blade wedge, taking care not to move or damage the tensioner blade.


Engines Fitted with the Hydraulic Tensioner

9. To set the hydraulic tensioner onto the first tooth of the ratchet (i.e. minimum extension) carry out the following:

Note:

- If installing a new hydraulic tensioner, do not release the plunger before fitting.
- If installing the original hydraulic tensioner, the engine oil must be drained out of the tensioner to enable the plunger to be set onto the first tooth of the ratchet.

10. Hold the resister ring ends together and pull out the plunger.




ctel_2

1. Resister ring ends

2. Plunger

11. Remove the spring.




cthp

1. Spring

12. While holding the resister ring in place, pour out the engine oil into a suitable container.


13. Ensure the resister ring is correctly located as shown in the illustration below.



cfho

1. Resister ring


14. Refit the spring.
15. Hold the resister ends together and push the plunger through the resister ring until the groove for the snap ring aligns with the snap ring.



clel_2

1. Resister ring
2. Plunger
3. Groove for snap ring
4. Snap ring

16. When the groove aligns with the snap ring, release the resister ring and move one end of the snap ring into the groove. Slowly release the plunger to ensure that it is held in place.



clej

1. Groove for snap ring

2. Snap ring

17. Fit a new O-ring and gasket to the hydraulic tensioner.
18. Fit the tensioner to the cylinder head as noted for removal. Tighten the bolts to **9 Nm**.
19. Remove the camshaft drive chain tensioner blade wedge, taking care not to move or damage the tensioner blade.
20. To release the hydraulic tensioner, rotate the crankshaft 1/4 of a turn anti-clockwise using the bolt fitted to the end of the crankshaft. Then rotate the crankshaft clockwise until the 'dot' mark on the primary gear aligns with the line at the bottom of the cover.
21. Check that there is tension in the camshaft drive chain and the timing marks at the camshaft sprockets are correctly aligned.


Note:

- After fitting to the engine, the hydraulic tensioner will be empty of engine oil. After starting the engine, the camshaft drive chain and tensioner blade will be noisy until full pressure is felt at the tensioner plunger. This could take up to 5 seconds.

All Engines

22. Check that the tensioner plunger is correctly located in the middle of the camshaft drive chain tensioner blade when viewed from above.


23. Rotate the engine through 4 full revolutions, and reset number 1 cylinder to TDC. Ensure that the 'dot' mark on the primary gear aligns with the line at the bottom of the cover.



cdrd

1. 'Dot' mark
2. Marker line


24. Check that the camshaft timing marks align as illustrated below.



gaaa1

Camshaft to Cylinder Head Alignment Marks

25. Re-check the tensioner plunger location against the camshaft drive chain tensioner blade.
26. Refit the camshaft cover (see page 3-8).
27. Fit a new gasket to the right hand crank cover.
28. Noting the position of the bolt fitted with the copper washer, refit the crank cover, tightening the fixings to **9 Nm**.



1. Right hand crank cover
2. Copper washer position

Cylinder Head


Camshaft Drive Chain Tensioner Blade - Daytona 675 - from VIN 381275

Disassembly

Note:

- For the purpose of this instruction, the top of the tensioner blade is where the pad is located.

- Release the clips and remove the pad.




cfee

1. Pad

2. Clip (one side shown)

- Detach the top hook from the tensioner blade.




cfeh

1. Top hook

2. Tensioner blade

- Release the three side locating devices.




cleg

1. Locating devices

2. Facing blade

- Release the three hooks and remove the facing blade.



cfeh

1. Hooks

Assembly

- Assembly is the reverse of disassembly.


Camshafts

Removal

1. Remove the camshaft drive chain tensioner (see page 3-9).

Note:


- It is not necessary to remove the camshaft drive chain completely.
 - Each camshaft and sprocket is removed as an assembly.
 - Before commencing work, ensure the crankshaft 'dot' mark is in alignment with the line in the crankcase.
2. Note the orientation of the camshaft ladder in relation to the head.
 3. Progressively release the bolts securing the camshaft ladder to the head in the sequence shown below.



Camshaft Ladder Bolt Release Sequence

4. Remove the camshaft ladder and top pad, and collect the dowels (if loose) and spark plug tower O-rings.
5. Lift the camshaft drive chain from the exhaust camshaft sprocket and remove the exhaust camshaft.



6. Repeat the procedure for the inlet camshaft.



1. Camshaft drive chain
2. Inlet camshaft

Note:

- The inlet and exhaust camshafts are different. They can be identified by a raised feature in the centre of the exhaust camshaft, which is machined off on the inlet camshaft. The camshafts can be further identified a letter 'I' for inlet or 'E' for exhaust stamped on the end of the sprocket boss.



1. Inlet camshaft
2. Machined section
3. Exhaust camshaft
4. Raised section

Cylinder Head

Camshaft and Bearing Cap Inspection


1. Inspect the camshaft sprockets for damaged and worn teeth. Replace as necessary.



Caution

The same sprocket is used for both inlet and exhaust camshafts. To attach the sprocket to the different camshafts, different bolt holes are used.

Never fit a camshaft sprocket to a camshaft using incorrectly identified bolt holes. Severe engine damage will result from incorrect attachment.




1. Inlet camshaft bolt holes
2. Exhaust camshaft bolt holes

2. Measure the camshaft journals with a micrometer. If any journal is outside the specified tolerance, replace the camshaft.

Standard Journal Diameters

Standard:	23.900 - 23.930 mm
-----------	--------------------



gabi


1. Standard journal

3. Examine the camshaft and camshaft ladder for excessive wear and damage.

4. Check the journal-to-head clearances, using 'Plastigage' (Triumph part number 3880150-T0301) as follows:
 - a) Ensuring that the camshaft sprocket alignment marking is located as for removal, assemble one camshaft to the head and progressively tighten the camshaft ladder in the sequence shown overleaf (see page 3-17).
 - b) Remove the camshaft ladder using the bolt release sequence given earlier. Wipe the exposed areas of both the camshaft journal and a single cap area of the ladder.
 - c) Apply a thin smear of grease to the journal and a small quantity of silicone release agent to the camshaft cap area of the ladder.
 - d) Size a length of the Plastigage to fit across the camshaft journal. Fit the Plastigage to the camshaft journal using the grease to hold the strip in place.
 - e) Refit the camshaft ladder then evenly and progressively tighten all the camshaft ladder bolts in the correct sequence (see camshaft installation).
 - f) Release the bolts and remove the camshaft ladder. Using the gauge provided with the Plastigage kit, measure the width of the now compressed Plastigage.

Note:

- The camshaft ladder is unique to each cylinder head and is, therefore, not available individually. If the camshaft ladder is worn or damaged, the complete cylinder head must be replaced.



Measuring the Compressed Plastigage.

5. Calculate the journal clearance using the Plastigage chart supplied with the Plastigage kit.

Camshaft journal clearance

Standard:	0.070 - 0.121 mm
Service limit:	0.170 mm

- If the clearance measured is within the specified tolerance, remove the ladder and clean off all traces of Plastigage. Assemble the camshafts (see page 3-17).

Note:

- If the measured clearance is outside the tolerance, and the camshaft journals are within tolerance, the cylinder head must be replaced.




Caution

Although Plastigage is oil soluble, all traces of the material must be removed to prevent blockage of the oil drillings and resultant engine damage.

Installation

- Thoroughly clean the camshafts and journals. Inspect the ends of the camshafts for correct fitment of the sealing plugs. Lubricate the camshafts with clean engine oil before fitting to the head.
- Locate each camshaft to the head ensuring the camshafts are correctly identified (inlet and exhaust) and are also correctly located over their respective valve banks.
- Working on one camshaft at a time, locate the camshaft drive chain over the camshaft sprocket. Position the camshaft in the same position as for removal before attempting to fit the ladder (that is, with the timing marks on the camshaft sprockets level and pointing inwards, and with the 'dot' mark on the primary gear in alignment with the line on the crankcase).



carv1
1. Camshaft drive chain
2. Inlet camshaft

- Repeat the procedure for the other camshaft.



Caution

If the camshafts and ladder are fitted without first aligning the timing marks on both the crankshaft and camshaft sprockets, the inlet and exhaust valves will contact each other causing damage to both the head and the valves.


- Lubricate the camshaft bearing areas of the camshaft ladder with a 50/50 solution of engine oil and molybdenum disulphide grease.
- Assemble the dowels, camshaft ladder and top pad in the same location and orientation as prior to removal.

Note:

- The bolts for the camshaft cap ladder are tightened in stages.

Stage 1

- Lubricate the threads of the camshaft cap ladder bolts with clean engine oil, then fit and evenly tighten the bolts to **5 Nm**, in the sequence shown below.




Camshaft Cap Ladder Bolt Tightening Sequence

Stage 2

- In the sequence shown above, tighten the bolts to **10 Nm**.

Cylinder Head

9. Before fitting the camshaft drive chain tensioner, ensure that each camshaft rotates freely using service tool T3880102. Do not rotate either camshaft by more than 5°.




1. Exhaust camshaft
2. Tool T3880102



Caution


If any components have been renewed, the valve clearances must be checked and adjusted. Running with incorrectly adjusted valve clearances may cause excess engine noise, rough running and engine damage.

10. Refit the camshaft drive chain tensioner (see page 3-10).
11. Rotate the engine through 4 full revolutions, and reset number 1 cylinder to TDC. Ensure that the 'dot' mark on the primary gear aligns with the line on the crankcase.



1. 'Dot' mark
2. Marker line

12. Check that the camshaft timing marks align as illustrated below. Rectify any misalignment before proceeding.



gaaa1

Camshaft to Cylinder Head Alignment Marks

13. Check the valve clearances. Adjust as necessary (see page 3-19).

Valve Clearances

Camshaft, valve, valve shim and valve seat wear affects the valve clearances. The effect of this wear is to change the gap between the camshaft and tappet bucket, causing engine noise and improper running. If the valve clearances become too small, permanent damage to the valve and valve seat will take place. If the valve clearance becomes too great, the engine will become noisy and will not run correctly.

Valve Clearance Measurement

Note:

- Valve clearance measurement must be carried out with the engine cold.

1. Remove the camshaft cover (see page 3-7).
2. Remove the spark plugs to reduce compression resistance when turning the engine.
3. Select a high gear and, using the rear wheel, turn the engine until a pair of camshaft lobes are positioned pointing away from the valves.
4. Using feeler gauges, measure and record the clearances for this pair of valves only.
5. Repeat the process until the valve clearances for all valves have been checked.

Note:

- If the measurement does not fall within the specified range, adjustment must be made.
- The correct valve clearances are in the range given below:

All models except Daytona 675 from VIN 381275

Inlet:	0.10 - 0.20 mm
Exhaust:	0.275 - 0.325 mm

Daytona 675 from VIN 381275 only

Inlet:	0.10 - 0.20 mm
Exhaust:	0.325 - 0.375 mm



Caution

If the valve clearances are not checked and corrected, wear could cause the valves to remain partly open, which lowers performance, burns the valves and valve seats and may cause serious engine damage.

- Record the measured valve clearances on a chart similar to the example shown.

Typical Valve Clearance Chart


Inlet Valve No.	Gap Measured
1	as measured (mm)
2	as measured (mm)
3	as measured (mm)
4	as measured (mm)
5	as measured (mm)
6	as measured (mm)
Exhaust Valve No.	Gap Measured
1	as measured (mm)
2	as measured (mm)
3	as measured (mm)
4	as measured (mm)
5	as measured (mm)
6	as measured (mm)

Valve Clearance Adjustment

Note:

- To adjust the valve clearances the camshafts must be removed. Follow the camshaft removal procedure.

- Remove the camshafts (see page 3-15).
- Remove the tappet bucket from the cylinder head.
- Remove the shim from the valve head.



1. Tappet bucket

2. Shim

Note:

- The shim may withdraw with the tappet bucket.

- Measure the original shim, using a micrometer and select the appropriate new shim as required.

Clearance too small:

- Fit a thinner shim.

Clearance too large:

- Fit a thicker shim.

Note:

- Shims are available ranging from 1.70 mm to 3.00 mm in increments of 0.025 mm.


- Fit the new shim to the valve head.
- Lubricate the tappet bucket(s) with a 50/50 solution of engine oil and molybdenum disulphide grease.
- Refit the tappet bucket.
- Refit the camshafts (see page 3-17).
- Re-check all valve clearances.
- Repeat the procedure if the valves require further adjustment.

Cylinder Head

Camshaft Drive Chain

Removal

1. Remove the camshafts (see page 3-15).
2. Remove the bolt from the centre of the camshaft drive chain housing in the cylinder head.




1. Centre bolt

3. Raise the front camshaft drive chain rubbing blade and detach the camshaft drive chain from the crankshaft gear.
4. The camshaft drive chain is removed from inside the head-space.

Inspection

Visual in-situ checks can also be made as follows:

1. Check for significant blue discolouration of the chain plates indicating excessive heat build-up.
2. Examine all pins for signs of rotation.
3. Check for cracking or deep scratching of the chain plates.
4. Check for severe wear of the inner plates as indicated in the diagram below.




For a more thorough check, proceed as follows:

1. Remove the chain from the engine.
2. Suspend the chain from a pin or hook with a 13kg weight attached at the lower end.




- Measure across 23 links as shown in the diagram below. If the chain is within limits, the measurement should be no longer than 149.48 mm. Measurements beyond 149.48 mm indicate that the chain must be replaced.



cajt


- Check for severe wear of the inner surface of the outer plates at the side-contact points with the sprocket teeth.



ccru

- Check for signs of stiffness or kinking.

- Check for severe wear of the plates in the area shown below.



caju

If any of these symptoms are evident, the camshaft drive chain must be replaced.

Installation

- Fit the camshaft drive chain and locate the lower end around the crankshaft gear.
- Incorporating a new seal, refit the bolt to the centre of the camshaft drive chain housing in the cylinder head, tightening to **12 Nm**.
- Refit the camshafts (see page 3-17).

Cylinder Head


Cylinder Head

Removal

Note:

- Removal of the cylinder head is not possible with the engine in the frame.

1. Remove the engine from the frame (see page 9-3).
2. Remove the camshafts (see page 3-15).
3. Remove the camshaft drive chain (see page 3-20).
4. Remove the camshaft drive chain tensioner blades.
5. Note the position of all tappet buckets and shims such that they can be refitted in the same positions. Remove all the tappet buckets and shims.




1. Tappet bucket
2. Shim

Note:

- To prevent the tappet buckets and shims from becoming mixed, place the shim and tappet together in a marked container. The components must be refitted in their original positions.
6. Disconnect the coolant bypass hose from the rear of the cylinder head.


7. Release the screws securing the outside of the cylinder head to the upper crankcase.



1. Cylinder head to upper crankcase screws

Note:

- Up to engine number 327506, the cylinder head bolts are coloured grey.
 - From engine number 327507, the cylinder head bolts silver coloured bolt and are fitted with a hardened washer.
8. Progressively release the cylinder head bolts in the order shown below.




Cylinder Head Bolt Release Sequence

9. Lightly tap the cylinder head with a rubber mallet to break the seal of the gasket.
10. Remove the cylinder head. Discard the cylinder head bolts and gasket.

Inspection

1. Thoroughly clean the surface of the head and check for damage and pitting of the combustion chambers.
2. Using a straight edge, check the cylinder head gasket face for warp which could lead to gasket failure. Replace the head if warped.




1. Cylinder head gasket face
2. Straight edge

3. Check the camshaft drive chain tensioner blades. Renew if worn or damaged.

Installation

1. Thoroughly clean the upper faces of the crankcase, taking care not to damage the mating surfaces.
2. Fit a new cylinder head gasket ensuring that the head to crankcase location dowels are correctly in place.



1. Cylinder head gasket
3. Ensure that the cylinder head face is completely clean.
4. Carefully lower the cylinder head over the camshaft drive chain and locate the head onto the dowels.



Caution

Using the correct procedure to fit and tighten the cylinder head bolts will ensure the long term reliability of the cylinder head gasket.

Clean each bolt, paying particular attention to the threads and under-bolt-head areas. If any of the threads or bolt-head areas are damaged, replace the bolt(s).


Lubricate the threads with engine oil, and then wipe clean with a lint-free cloth leaving minimal oil on the threads (that is, almost dry to touch).

Tighten the bolts using the three-stage procedure given below.

Failure to observe these important items may lead to engine damage through a damaged head gasket.

Note:

- Up to engine number 327506, new cylinder head bolts and washers must be fitted.
 - From engine number 327507, new cylinder head bolts must be fitted with the original washers.
5. Fit new bolts and washers to the head and tighten until finger tight.
 6. The cylinder head bolts must be tightened in the following sequence:



Cylinder Head Bolt Tightening Sequence

7. The head bolts are finally tightened in three stages, all using the above sequence. This is to ensure that the cylinder head gasket seals correctly to the head and crankcase. The three stages are as follows:

Note:


- For stages A and B of the head bolt tightening operation, a torque wrench of known, accurate calibration must be used.
- A: Tighten the head bolts, in the sequence shown above, to 15 Nm.

- B:** Tighten the head bolts in the sequence shown on the previous page, to 20 Nm.
- For the final torque operation, Stage C, (see below) which is carried out in the sequence shown on the previous page, a 'torque turn' method is used. The bolts must be turned through 120° to reach the final setting. To accurately gauge the 120° turn, use service tool 3880105-T0301 as follows:
- C:** Fit the tool between the Torx socket and the drive handle and locate the Torx drive to the head bolt. Pick an increment point on the torque turn gauge which aligns with a suitable reference point on the head. Tighten the bolts until 12 of the 10° (i.e. 120°) gauge increments have rotated past the chosen point on the head.



Tool T3880105-T0301

6. Fit the screws securing the side of the cylinder head to the crankcase and tighten to 10 Nm.




1. Cylinder head to upper crankcase screws

- Install the camshaft drive chain tensioner blades.
- Clean and lubricate the tappet buckets with a 50/50 solution of engine oil and molybdenum disulphide grease and refit the buckets and shims in the same locations from which they were removed.
- Refit the camshaft drive chain (see page 3-21).
- Refit the camshafts (see page 3-17).
- Install the engine to the frame (see page 9-4).

Valves and Valve Stem Seals


Removal from the Cylinder Head

- Remove each valve from the head using a valve spring compressor. The compressor must act on the top cup to allow removal of the valve collets.



Valve removal


- Once the collets are released, remove the following items:
 - valve spring retainer
 - valve spring
 - valve spring base
 - valve stem oil seal
 - valve (de-burr before removal)



1. Valve stem seal

Note:

- Ensure inlet and exhaust valve components do not become mixed.



1. Collets
2. Valve spring retainer
3. Valve spring
4. Valve spring base
5. Valve stem oil seal
6. Valve

Installation

1. Lubricate the valve stems with a 50/50 solution of engine oil and molybdenum disulphide grease.
2. Install the valve into the valve guide and refit the spring base to the valve spring recess in the head.
3. Fit the valve stem seal over the valve stem and, using a suitable tool, press down fully until the seal is correctly seated over the valve guide.

Note:

- During fitment of the valve stem seal, two distinctly different degrees of resistance will be noted when the seal is correctly fitted.
- Firstly, press the seal down the valve stem until the lower side of the seal comes into contact with the valve guide. Greater resistance is felt at this contact point and further gentle pressure is then required to locate the seal over the top end of the valve guide.
- On application of this pressure, the seal can be felt to positively locate over the top face of the valve guide. Once correctly positioned, the seal cannot be pushed down any further.

**Caution**

Incorrect fitment of the valve stem oil seals could lead to high oil consumption and blue smoke emissions from the exhaust system. Do not use excessive force in fitting the seal as this may break the seal ring.

4. Install the valve spring over the valve stem. Ensure the close wound, colour coded ends of the springs are fitted downwards (towards the piston).
5. Fit the valve spring retainer.
6. Compress the valve spring ensuring that the spring is compressed squarely to prevent damage to the valve stem and cylinder head.
7. Fit the valve collets ensuring correct collet location in the spring retainer and valve as the spring compressor is released.

**Caution**

Always check for correct location of the valve collets during and after assembly. If not fitted correctly, the collets may become dislodged when the engine is running allowing the valves to contact the pistons. Any such valve to piston contact will cause severe engine damage.

Valve to Valve Guide Clearance

If the valve guides are worn beyond the service limit given below, the cylinder head must be replaced.

Valve Stem to Guide Clearance

Inlet:	0.010 - 0.040 mm
Service limit	0.078 mm

Exhaust:	0.030 - 0.060 mm
Service limit	0.098 mm

Valve Guides

If a valve guide is found to be worn beyond the service limit, the complete cylinder head must be renewed.

Valve Face Inspection

Remove any carbon build-up from the valve head area. Examine the valve seat face, checking in particular for signs of cracking or pitting.


4 Clutch

Table of Contents


Exploded View - Clutch Cover	4.2
Exploded View - Clutch Assembly	4.3
Exploded View - Clutch Controls	4.4
Clutch Cable	4.5
Removal	4.5
Inspection	4.5
Assembly	4.6
Clutch	4.6
Disassembly	4.6
Friction Plate Inspection	4.8
Thickness	4.8
Bend/warp	4.8
Assembly	4.9

Clutch


Exploded View - Clutch Cover



Exploded View - Clutch Assembly




Exploded View - Clutch Controls



Clutch Cable

Removal


1. Remove the rider's seat (see page 16-17).
2. Disconnect the battery, negative (black) lead first.
3. Slacken the cable locknut and release the adjuster at the clutch cover end to give maximum play in the cable.



cdpe

1. Clutch cable
2. Adjuster


4. Release the clutch cable from the actuating arm by pushing the inner cable nipple through the arm and sliding the cable out of the slot. Detach the cable from the bracket.



1. Actuating arm
2. Inner cable nipple

5. Align the cable adjuster and lever bracket slots.

6. Pull in the clutch lever and turn the inner cable, anti-clockwise through the slots in the adjuster and locknut, until the cable can be detached from the lever by pushing downwards.



gaau

1. Cable adjuster/lever bracket slots
2. Cable release point

7. Remove the cable from the motorcycle noting the cable routing.

Inspection


1. Check the inner cable for free movement through the outer cable.
2. Examine the inner cable for frayed strands.
3. Examine the two inner cable nipples for signs of looseness and damage. Replace the cable if necessary.

Assembly

1. Position the cable to the motorcycle using the same routing as noted during removal.
2. Attach the inner cable to the clutch lever and actuating arm using a reversal of the removal process.
3. Refit the outer cable to the adjuster bracket at the clutch end.

Note:

- **Ensure that the two adjuster nuts are positioned one either side of the bracket.**
4. Set the lever adjuster to a point where an equal adjustment is possible in both directions.
 5. Set the adjuster at the clutch end to give a preliminary setting of 2-3 mm of free play as measured at the lever. Tighten the locknut.
 6. Operate the clutch lever several times and recheck the amount of free-play present.
 7. Set the final adjustment of the cable to give 2-3 mm of free-play at the lever by turning the adjuster nut and locknut at the lever end.



ccpe1

1. Clutch lever


2. Correct setting, 2-3 mm

8. Reconnect the battery, positive (red) lead first.
9. Refit the rider's seat (see page 16-17).

Clutch

Disassembly

1. Remove the rider's seat (see page 16-17).
2. Disconnect the battery, negative (black) lead first.
3. **Daytona 675 only:** Remove the lower fairings (see page 16-20).
4. Release the clutch cable from the actuating arm (see page 4-5).
5. Remove the clutch cover, noting the copper washer position. Discard the clutch cover gasket.




cdpd

1. Clutch cover

2. Copper washer position

6. Undo the bolts and remove the springs and clutch pressure plate.
7. Remove the clutch pull-rod.



cdoo


1. Clutch pull-rod

2. Clutch pressure plate

8. Remove the clutch friction plates and steel plates together with the anti-judder spring and anti-judder seat washer.

Note:

- Record the orientation of all components as they are removed. The plates must be assembled in the same order.




dpb

1. Steel plate
2. Inner friction plate
3. Anti-judder spring
4. Anti-judder seat washer
5. Clutch inner drum

Note:

- The inner and outermost friction plates are different to the remainder and are also different to each other. They must be fitted in their noted positions.
- The two outer steel plates are different to the other plates. They must be fitted in their noted positions.
- Store all plates in their correct fitted order to avoid confusion on installation.
- Refer to the following page of this section for details of clutch friction plate checking.
- It is not normally necessary to disassemble the clutch further, but if the clutch inner and outer drums are to be removed, proceed as follows:


9. Insert service tool T3880026 into the splines of the clutch inner drum. Using finger pressure only, tighten the adjuster screw to allow the tool to grip the splines. Do not overtighten the adjuster screw.



dpc

1. Service Tool T3880026
2. Adjuster screw


10. Retain the service tool to prevent the clutch inner drum from turning, then release the centre nut. Remove the tool.
11. Remove the centre nut, Belleville washer, flat washer, clutch inner drum and thrust washer.



iml

1. Centre nut
2. Belleville washer
3. Flat washer
4. Inner drum
5. Thrust washer

- Slide the clutch outer drum assembly gently backwards and forwards to dislodge the inner bearing sleeve. Carefully remove the bearing sleeve while supporting the clutch drum.




- Outer drum
- Bearing sleeve

- Remove the clutch outer drum leaving the oil pump drive sprocket, bearing and sleeve in place on the input shaft.

Friction Plate Inspection

Thickness

- If any friction plate thickness is outside the service limit, replace the friction plates as a set.



- Clutch friction plate


Friction plate thickness - all plates

Standard	3.00 mm
Service limit	2.80 mm

Bend/warp

Check all plates for bend and warp as follows:

- Place the plate being checked on a clean surface plate and attempt to pass a feeler gauge of the maximum specified thickness between the friction plate and surface plate at several points around the plate. If the feeler gauge can be passed beneath the friction plate at any point, renew the plates as a set.




- Friction plate
- Feeler gauge
- Surface plate

Friction plate bend/warp

Standard	up to 0.15 mm
Service limit	0.20 mm


Assembly

1. To fully engage the outer drum, insert a suitable tool to preload and align the primary gear and backlash eliminator gear through the hole shown in the illustration below.




1. Alignment hole
2. Outer drum

2. Position the clutch outer drum assembly to the input shaft and align the oil pump drive pegs with the corresponding holes in the rear of the clutch outer drum.



1. Clutch outer drum
2. Oil pump sprocket drive pegs
3. Oil pump drive holes


3. While holding the clutch outer drum in position and ensuring correct engagement with the oil pump drive, refit the bearing sleeve and bearing.



1. Outer drum
2. Bearing sleeve


Note:

- When the bearing sleeve is correctly fitted, it will be a flush fit with the clutch drum face.
4. Fit the thrust washer to the shaft.
 5. Fit the clutch inner drum.
 6. Fit the flat washer, a new Belleville washer ('OUT' mark facing outwards), and refit the centre nut.



Belleville Washer 'OUT' Mark

7. Using service tool T3880026, prevent the clutch inner drum from turning, and tighten the clutch centre nut to **98 Nm**. Remove the service tool.




1. Service tool T3880026

8. Coat all clutch friction plates in clean engine oil before fitting the friction plates, steel plates, anti-judder spring and anti-judder seat washer to the clutch basket in the same order and orientation as noted during removal.

Note:

- The inner and outermost friction plates are different to the remainder and are also different to each other. They must be fitted in their noted positions.
- The two outer steel plates are different to the other plates. They must be fitted in their noted positions.




1. Steel plate
2. Inner friction plate
3. Anti-judder spring
4. Anti-judder seat washer
5. Clutch inner drum

9. Refit the clutch pull-rod.

10. Refit the clutch pressure plate together with the springs and bolts. Tighten the bolts to **10 Nm**.

Note:

- The pull-rod should be free to move in and out and also it should be free to turn.
11. Clean and refit the clutch cover incorporating a new gasket. Install the bolt with the copper washer in the position shown below. Tighten the clutch cover bolts to **9 Nm**.



1. Clutch cover

2. Copper washer position

12. Refit the outer cable to the adjuster bracket at the clutch end (see page 4-6).
13. Set the clutch adjustment (see page 4-6).
14. Refit the lower fairings (see page 16-22).
15. Reconnect the battery positive (red) lead first.
16. Refit the rider's seat (see page 16-17).


5 Crankshaft, Connecting Rods and Pistons

Table of Contents


Exploded View - Crankshaft, Connecting Rod, Piston and Liner.....	5.2
Exploded View - Crankcase.....	5.3
Crankcases.....	5.4
Disassembly.....	5.4
Assembly.....	5.4
Crankshaft.....	5.6
Removal.....	5.6
Installation.....	5.6
Connecting Rods.....	5.8
Removal.....	5.8
Installation.....	5.8
Connecting Rod Big End Bearing Selection/Crankpin Wear Check.....	5.10
Checking the Measured Clearance.....	5.10
Connecting Rod Bearing Selection.....	5.11
Crankshaft main bearing/journal wear.....	5.12
Pistons.....	5.13
Disassembly.....	5.13
Piston Wear Check.....	5.13
Cylinder Wear.....	5.16
Cylinder Liners.....	5.16
Removal.....	5.16
Installation.....	5.17
Crankcase Breather.....	5.18

Crankshaft, Connecting Rods and Pistons

Exploded View - Crankshaft, Connecting Rod, Piston and Liner



Exploded View - Crankcase



Crankshaft, Connecting Rods and Pistons

Crankcases

Caution

The upper and lower crankcases are machined as a matched set and must never be assembled to non-matching halves. Doing so may cause seizure of the engine.


1. Remove the engine from the frame (see page 9-3).
2. Remove the sump (see page 8-15).
3. Remove the engine covers (see page 7-23).
4. Remove the clutch (see page 4-6).
5. Remove the oil pump (see page 8-9).

Disassembly

Caution

Failure to follow the correct screw release sequence may result in permanent crankcase damage.

1. Invert the engine to give access to the lower crankcase bolts.
2. Release the lower crankcase bolts in the sequence shown in the diagram below. Note the position of the hardened washers under bolts 19 to 26.



Crankcase Bolt Release Sequence

3. Separate the lower and upper crankcases ensuring that the 3 locating dowels remain in the upper crankcase.

Caution

Do not use levers to separate the upper and lower sections of the crankcase or damage to the crankcases could result.

Note:


- At this point the transmission shafts, balancer, crankshaft, bearings etc. can be removed.

Note:

- The position of each individual bearing shell prior to removal.
- Collect the piston cooling jets from below the upper main bearings.

Assembly


1. Use high flash-point solvent to clean the crankcase mating faces. Wipe the surfaces clean with a lint-free cloth.
2. Fit the gearbox shafts (if removed), ensuring the locating ring and dowels on the output shaft bearings are positioned correctly in the crankcase.
3. Ensure that the transmission is in neutral.
4. Ensure that the 3 locating dowels are in position in the upper crankcase.



1. Locating dowels

Crankshaft, Connecting Rods and Pistons

5. Apply a thin bead of silicone sealant (At the factory, ThreeBond 1215 is used) to the lower crankcase mating faces.



cdmy


Sealer areas



Caution

Do not use excessive amounts of sealer. The extra sealer may become dislodged and could block the oil passages in the crankcases causing severe engine damage.

6. If removed, insert the three piston cooling jets into the main bearing housings in the upper crankcase.



1. Piston cooling jet



Caution

Ensure the three piston cooling jets are installed. If the piston cooling jets are omitted, oil pressure will be reduced. Running the engine with low oil pressure will cause severe engine damage.

Note:

- The piston cooling jet for number 3 cylinder is longer and has a larger diameter drilling than the piston cooling jets for number 1 and 2 cylinders. It can also be identified by its smaller outside diameter and a groove around its circumference. Piston cooling jets cannot be installed incorrectly.
7. Install and lubricate the crankshaft bearing shells with clean engine oil (see bearing selection before proceeding).
 8. Lubricate the crankshaft journals with clean engine oil.
 9. Position the lower crankcase to the upper. An assistant may be required to support the crankcase during alignment.
 10. Fit the screws into the lower crankcase and hand tighten until the bolt heads are near contact with the crankcase. Note the position of the hardened washers under bolts 1 to 8.

Note:

- The crankcase screws are tightened in stages.
- Two different sizes of crankcase screw are used. All screws are tightened through the first stage of the tightening procedure but only the M8 size screws are tightened at the second stage.




Caution

Failure to follow the correct screw tightening sequence may result in permanent crankcase damage.

Stage 1 - all screws

1. In the sequence shown below, tighten all crankcase screws to 12 Nm.




Crankcase Bolt Tightening Sequence

Crankshaft, Connecting Rods and Pistons

Stage 2 - M8 screws only

1. In the correct sequence, tighten only the M8 size crankcase screws (numbers 1 to 8) to **32 Nm**.
2. In the correct sequence, tighten only the M8 size crankcase screws (number 9 to 14) to **32 Nm**.



M8 Crankcase Bolt Tightening Sequence

3. Rotate the crankshaft clockwise. Check for tight spots and rectify as necessary.
4. Refit the oil pump (see page 8-13).
5. Refit the clutch (see page 4-9).
6. Refit the engine covers (see page 7-24).
7. Refit the sump (see page 8-16).
8. Install the engine in the frame (see page 9-4).

Crankshaft

Removal

1. Remove the alternator rotor from the crankshaft (see page 17-32).
2. Separate the two halves of the crankcase (see page 5-4).
3. Remove the connecting rods (see page 5-8).
4. Remove the camshaft drive chain (see page 3-20).
5. Release and remove the crankshaft from the upper crankcase.

Note:

- Identify the location of each bearing shell.
 - Remove all bearings and inspect for damage, wear, overheating (blueing) and any other signs of deterioration. Replace the bearings as a set if necessary.
 - Collect the piston jets from below the upper main bearings.
 - If the camshaft drive chain sprocket is removed from the crankshaft for any reason, always install a new fixing. Tighten to 27 Nm.
6. Remove the balancer (see page 6-3).


Installation



Caution

Always check the bearing journal clearance (see page 5-12), before final assembly of the crankshaft. Failure to correctly select crankshaft bearings will result in severe engine damage.

1. If removed, insert the three piston cooling jets into the main bearing housings in the upper crankcase.



1. Piston cooling jet

Crankshaft, Connecting Rods and Pistons




Caution

Ensure the three piston cooling jets are installed. If the piston cooling jets are omitted, oil pressure will be reduced. Running the engine with low oil pressure will cause severe engine damage.

Note:

- The piston cooling jet for number 3 cylinder is longer and has a larger diameter drilling than the piston cooling jets for number 1 and 2 cylinders. It can also be identified by its smaller outside diameter and a groove around its circumference. Piston cooling jets cannot be installed incorrectly.
2. Select and fit new main and big end shell bearings using the selection processes detailed later in this section.




cdmx

1. Big end shells

3. Lubricate all bearings with a 50/50 solution of engine oil and molybdenum disulphide grease.
4. Ensure that the crankshaft is clean, and that the oilways within the crank are clean and free from blockages and debris.
5. Refit the balancer (see page 6-4).

6. Install the crankshaft ensuring that the crank pins align with the big ends and that the crankshaft and balancer gear markings align as shown in the next illustration.



cdmz

1. Balancer backlash and drive gear markings

2. Crankshaft markings

7. Refit the connecting rods (see page 5-8).
8. If removed, refit the transmission shafts.
9. Assemble the crankcases (see page 5-4).
10. Assemble the alternator rotor (see page 17-34).
11. Refit the camshaft drive chain (see page 3-21).


Crankshaft, Connecting Rods and Pistons

Connecting Rods

Removal

Connecting rods may be removed from the engine after first removing it from the frame. The cylinder head must be removed and the crankcase halves separated.

1. Mark each big end cap and connecting rod to identify both items as a matched pair and to identify the correct orientation of the bearing cap to the connecting rod.
2. Release the connecting rod bolts and remove the big end cap. Ensure that the bearing shell remains in place in the cap.



1. Big end cap
2. Connecting rod bolt

Note:

- It may be necessary to gently tap the big end cap with a rubber mallet to release the cap.
3. Push the connecting rod up through the crankcase and collect the piston and connecting rod from the top.
 4. Label the assembly to identify the cylinder from which it was removed.



Caution

Never re-use connecting rod bolts. If the connecting rod cap is disturbed, always renew the bolts. Using the original bolts may lead to severe engine damage.

5. Remove the liner using tool T3880101 (see page 5-16).
6. Detach the piston from the connecting rod (see page 5-13).

Installation

Note:

- Connecting rod bolts are treated with an anti-rust solution which must not be removed.
- Clean the connecting rod with high flash-point solvent.
- Remove all bearings and inspect for damage, wear and any signs of deterioration and replace as necessary.




Warning

Connecting rod bolts MUST only be used once. If the bolts are removed or undone for any reason, new bolts MUST always be used.

Re-using bolts can cause connecting rods and their caps to detach from the crankshaft causing severe engine damage, loss of motorcycle control and an accident.

Note:

- Ensure the piston is fitted correctly to the connecting rod.
 - If a previously run engine is being rebuilt, always ensure that the piston and con-rod are assembled in the same orientation, and to the same cylinder, as prior to strip-down.
1. Fit the piston onto the connecting rod (see page 5-15).
 2. Apply silicone sealer to the liner-to-crankcase mating face (At the factory, Three Bond 1215 is used).




1. Liner

2. Sealer area


3. Fit the piston and connecting rod assembly into the liner from the bottom.
4. Fit the liner into the crankcase ensuring that the arrow/'dot' on the piston faces forward.

5. The liners must be positioned such they do not touch each other - it must be possible to pass a 0.1 mm feeler gauge between the centre liner and its adjacent liner on either side. If the liners touch at any point, rotate the liners until there is a minimum 0.1 mm clearance.



Note:

- Ensure that the piston/liner/connecting rod assembly aligns correctly with the crankpin during assembly into the crankcase.
6. Select the big end bearing shells (see page 5-10).
 7. Fit the bearing shells to the connecting rod and big end cap and lubricate with a 50/50 solution of engine oil and molybdenum disulphide grease.
 8. Align the connecting rod to the crankshaft and fit the big end cap.



Caution

The torque characteristics of the connecting rod bolts are sensitive to the correct lubrication being applied. If the threads and under head areas are not lubricated with molybdenum disulphide grease, the bolts may be stretched and may become loose when in service resulting in an expensive engine failure.


9. Lubricate the threads and under-head area of the new bolts with molybdenum disulphide grease. Tighten the bolts evenly and progressively in five stages as follows:



Caution

The torque characteristics of the connecting rod bolts are sensitive to the rate at which they are tightened. If all the torque is applied in one action, the bolt may be stretched and may become loose when in service resulting in an expensive engine failure.

- a) Tighten to 22 Nm
- b) Release 120°
- c) Tighten to 10 Nm
- d) Tighten to 14 Nm
- e) Tighten through 120° of bolt rotation as measured using the Triumph torque turn gauge 3880105-T0301.




Service Tool 3880105-T0301

Connecting Rod Big End Bearing Selection/Crankpin Wear Check

1. Measure the bearing and crankpin clearance as follows.

Note:

- The crankpin clearances are measured using 'Plastigage' (Triumph part number 3880150-T0301).
 - Do not turn the connecting rod and crankshaft during the clearance measurement as this will damage the 'Plastigage'.
- a) Remove the big end cap from the journal to be checked.
 - b) Wipe the exposed areas of the crankpin, and the bearing face inside the cap.
 - c) Apply a thin smear of grease to the journal and a small quantity of silicone release agent to the bearing.
 - d) Trim a length of the Plastigage to fit across the journal. Fit the strip to the journal using the grease to hold the Plastigage in place.
 - e) Lubricate the threads and under-head of the bolt with molybdenum disulphide grease. Refit the bearing and cap and tighten the big end bolts (see page 5-9).
 - f) Release the bolts and remove the cap being measured. Using the gauge provided with the Plastigage kit, measure the width of the compressed Plastigage.



gagd

Checking the Measured Clearance

Con rod big end bearing/crankpin clearance

Standard:	0.035 - 0.065 mm
Service limit:	0.070 mm

Note:

- If the measured clearance exceeds the service limit, measure the crankpin diameter.

Crankpin diameter

Standard:	32.984 - 33.000 mm
Service limit:	32.960 mm

Note:

- If any crankpin has worn beyond the service limit, the crankshaft must be replaced. Due to the advanced techniques used during manufacture, the crankshaft cannot be reground and no oversize bearings are available.

Crankshaft, Connecting Rods and Pistons

Connecting Rod Bearing Selection

Minor differences in crankshaft dimensions are compensated for by using selective bearings. For further information on bearing part number to colour cross-references, see the latest parts information.

1. Select the correct big end bearing shell as follows:
 - Measure each crankpin diameter.
 - Select the correct bearings by matching the information found with the chart below.

Note:

- All dimensions in millimetres.

Big end bearing selection chart

Shell Colour	White	Red
Con-rod Big End Bore Dia.	36.009 36.000	36.009 36.000
Crankpin Dia.	33.000 32.992	32.991 32.984
Running Clearance	0.065 0.035	


For instance:

Con-rod Big End Diameter 36.002
Crankpin Diameter 32.987
Required Bearing Red

Note:

- Repeat the measurements for all connecting rods and their respective crankpins.
- It is normal for the bearings selected to differ from one connecting rod to another.

2. Install the new bearings in the connecting rod.



odmx

1. Big end bearings



Caution

Always confirm, using the Plastigage method, that the running clearance is correct before final assembly. Severe engine damage could result from incorrect clearance.


Crankshaft, Connecting Rods and Pistons

Crankshaft main bearing/journal wear

Main Bearing Selection Chart (all dimensions in millimetres)						
Shell Colour	White	Red	Red	Blue	Blue	Green
Crankcase Bore	35.982 35.973	35.981 35.973	35.989 35.981	35.988 35.981	35.997 35.989	35.997 35.989
Journal Dia.	33.000 32.993	32.992 32.984	33.000 32.993	32.992 32.984	33.000 32.993	32.992 32.984
Running Clearance	0.044 0.020	0.044 0.020	0.043 0.021	0.043 0.020	0.043 0.020	0.044 0.020

Minor differences in crankshaft and crankcase dimensions are compensated for by using selective bearings. For further information on bearing part number to colour cross-references, see the latest parts information.

- Measure the bearing to crankshaft main journal clearance using Plastigage (Triumph part number 3880150-T0301) (see page 5-10).



gagc

Checking Crankpin Clearance using Plastigage

Crankshaft main bearing/journal clearance

Standard:	0.020 - 0.044 mm
Service limit:	0.07 mm

If the clearance exceeds the service limit, measure the diameter of the crankshaft main journal.

Crankshaft main journal diameter

Standard:	32.984 – 33.000 mm
Service limit:	32.960 mm

Note:

- If any journal has worn beyond the service limit, the crankshaft must be replaced. Due to the techniques used during manufacture, the crankshaft cannot be reground and no oversize bearings are available.

Select bearings as follows:

1. Measure and record the diameter of each crankshaft main bearing journal.
2. Measure and record each main bearing bore diameter in the crankcase (bearings removed).

Compare the data found with the chart above to select bearings individually by journal.

For example:

Crankshaft Journal diameter	32.995 mm
Crankcase Bore	35.997 mm
Bearing Required	Blue

Note:

- It is normal for the bearings selected to differ from one journal to another.
- It is also normal for there to be two options of bearing shell colour. In such cases, pick the shell size which gives the greater running clearance.

! Caution

Always confirm, using the Plastigage method, that the running clearance is correct before final assembly. Severe engine damage could result from incorrect clearance.

Crankshaft End Float

Standard	0.15 - 0.30 mm
----------	----------------

Note:

- Crankshaft end float is controlled by the tolerances in crankshaft and crankcase machining. No thrust washers are used. If the crankshaft end float is outside the specified limit, the crankshaft and/or the crankcases must be replaced.

Pistons

Disassembly

Note:

- It is not necessary to remove the connecting rods from the crankshaft.

- Remove the cylinder head (see page 3-22).
- Remove the liner, using the frame from tool T3880315, and tool T3880101 (see page 5-16).
- Remove and discard the gudgeon pin circlip from one side of the piston.



Removing the Gudgeon Pin Circlip

- Remove the gudgeon pin by pushing the pin through the piston and rod toward the side from which the circlip was removed.



Caution

Never force the gudgeon pin through the piston. This may cause damage to the piston which may also damage the liner when assembled.

Note:


- If the gudgeon pin is found to be tight in the piston, check the piston for a witness mark caused by the circlip. Carefully remove the mark to allow the pin to be removed.
- Piston rings must be removed from the piston using hand pressure only. Do not over-extend the piston rings during removal.

Note:

- If the piston rings are to be re-used, note the orientation of the oil control rings prior to removal.

Piston Wear Check

- Measure the piston outside diameter, 8 mm up from the bottom of the piston and at 90° to the direction of the gudgeon pin.



- Piston outside diameter
- Measurement point
- Circlip removal groove

Daytona 675

All Cylinders	73.970 – 73.980 mm
Service limit	73.920 mm

Street Triple and Street Triple R

All Cylinders	73.964 – 73.980 mm
Service limit	73.920 mm

Replace the piston if the measured diameter falls outside the specified limit.

Crankshaft, Connecting Rods and Pistons

Piston Rings/Ring Grooves

Check the pistons for uneven groove wear by visually inspecting the ring grooves.

If all the rings do not fit parallel to the groove upper and lower surfaces, the piston must be replaced.

Clean the piston ring grooves.

Fit the piston rings to the pistons. Check, using feeler gauges, for the correct clearance between the ring grooves and the rings. Replace the piston and rings if outside the specified limit.



capg

Piston Ring to Ring Groove Clearance Check

Piston Ring Gap

Note:

- The piston ring gap, with the piston ring fitted in the liner, must be checked before final assembly.

- Place the piston ring inside the liner.
- Push the ring into the top of the cylinder, using the piston to hold the ring square with the inside of the bore. Continue to push the ring into the bore until the third groove of the piston is level with the cylinder top, around the full circumference of cylinder.



ccuo

Piston ring/Groove Clearance

Top ring	0.040 - 0.080 mm
Service limit	0.095 mm
Second	0.020 - 0.060 mm
Service limit	0.075 mm

Aligning Piston Rings using the Piston

- Remove the piston and measure the gap between the ends of the piston ring using feeler gauges.

Piston Ring End Gap Tolerances

Top	0.10 - 0.25 mm
Service limit	0.37 mm
Second	0.25 - 0.40 mm
Service limit	0.52 mm
Oil Control	0.10 - 0.35 mm
Service limit	0.49 mm

Note:


- If the end gap is too large, replace the piston rings with a new set
- If the gap remains too large with the new piston rings, both the pistons and barrels must be replaced
- If the gap is too small, check the cylinder bore for distortion, replacing as necessary. **Do not file piston rings!**

Piston Assembly

1. Clean the piston ring grooves and fit the piston rings to the piston.

Note:

- The top ring upper surface is marked 'T1' and can be identified by a chamfer on the inside edge. When new, the top ring also has a blue paint marking on its outer edge.
- The second ring upper surface is marked 'T2', is plain on the inside edge and has a bronze appearance. When new, the second ring also has a yellow paint marking on its outer edge.
- When new, the oil control rings can be fitted with either face upward. Used oil control rings must be refitted in the same orientation as noted prior to removal. When new, the oil control rings have white paint markings on their outside edge.



Piston Ring Identification

1. Fit the piston onto the connecting rod.


Note:

- Connecting rods may be fitted either way around. However, ensure all three are fitted the same way.
2. Lubricate the piston, small end and gudgeon pin with a 50/50 solution of engine oil and molybdenum disulphide grease.
 3. Align the small end in the connecting rod with the gudgeon pin hole in the piston and fit the gudgeon pin.
 4. Fit new circlips on both sides of the gudgeon pin ensuring the circlips are correctly fitted in the grooves.

Warning

Failure to use new gudgeon pin circlips could allow the pin to detach from the piston. This could seize the engine and lead to an accident.

5. The piston ring gaps must be arranged as shown in the diagram below.



1. Top ring
2. Second ring
3. First steel oil control ring
4. Oil control ring expander
5. Second steel oil control ring

Note:

- The top ring gap should be positioned in the 12 o'clock position, and the second ring gap in the 6 o'clock position. The first steel oil control ring gap should be in the 12 o'clock position and the second steel oil control ring should be in the 6 o'clock position. The oil control ring expander should be in the 7 o'clock position.
6. Fit the piston into the liner from below using a gentle rocking motion to engage the rings in the bore.


Crankshaft, Connecting Rods and Pistons

Cylinder Wear

Measure the inside diameter of each cylinder using an internal micrometer or similar accurate measuring equipment.

Cylinder bore diameter

Standard:	73.985 – 74.003 mm
Service limit:	74.100 mm




Test Position For Bore Wear Check (bore shown in section)

1. Measure the inside diameter 10 mm from the top of the bore as shown above.
2. If the reading is outside the specified limits, replace the liner and piston as an assembly.


Cylinder Liners

Removal

1. Assemble the frame from tool T3880315 to Tool T3880315 as shown below.



1. Frame from tool T3880315
2. Tool T3880101




1. Paint mark

2. Mark each liner to identify correct orientation and the cylinder number from which it has been removed.

Crankshaft, Connecting Rods and Pistons

3. Turn the crankshaft until the piston in the liner to be removed is at the bottom of its stroke.
3. Apply silicone sealer to the liner to crankcase mating face (at the factory, ThreeBond 1215 is used).



gajw

1. Tool T3880315 and T3880101

2. Extraction nut

3. Locking nut

4. Check that the locking nut on tool T3880101 is loose, then fully unscrew the extraction nut.
5. Carefully fit the tool fully into the cylinder bore, positioning the tool legs on the crankcase. Turn the locking nut clockwise until the rubber sleeve on the tool tightly grips the bore of the liner.
6. Check that the tool legs are positioned to allow withdrawal of the liner, then turn the extraction nut clockwise to extract the liner. Take care to ensure that the piston/connecting rod is not allowed to fall against the inside of the crankcase.
7. Turn the locking nut counter-clockwise to release the liner.


Note:

- The tool must be used to release the seal between the liner and the crankcase.
- It is not intended that the tool is used to fully extract the liner. Once the seal is released, the tool must be removed and the liner extracted by hand.

Installation

1. Thoroughly clean the liner removing all traces of old silicone sealer.
2. Remove all traces of sealer from the crankcase bores.

4. Fit each liner over the piston using a gentle rocking motion to allow compression of the piston rings.



cbef

1. Liner

2. Sealer area

3. Chamfer

Note:

- The liners have a large chamfer at the bottom of the bore enabling fitting of the piston without need for a piston ring compressor.



Caution

Fit each liner over whichever piston is at TDC. When turning the engine, do not allow the pistons to contact the inside of the crankcase and also do not allow fitted liners to lift off the crankcase base.


- Continue fitting each liner in turn until all are fitted and sealed.

Note:

- When the liners have been fitted, they should not be disturbed. If it is necessary to remove the liner after fitting, the sealer must be re-applied.

Crankcase Breather

The upper crankcase is fitted with a labyrinth type breather system, which requires no maintenance. During engine disassembly and overhaul, check the oil drain tube for blockage and contamination.




6 Balancer

Table of Contents

Exploded View - Balancer Shaft	6.2
Balancer	6.3
Removal	6.3
Inspection	6.3
Assembly/Installation	6.4

Balancer

Exploded View - Balancer Shaft



Balancer

The balancer is fitted to control 'pulsing' within the engine. Without any form of balancer, the engine would 'pulse' each time the crankshaft rotated. This 'pulsing' would be felt as a vibration which would amplify as the engine speed was increased.

The balancer has the effect of a pair of counterbalance weights which create an equal amount of energy in the opposite direction, and at the same time as that produced by the crankshaft, pistons and connecting rods. Because the opposing pulses occur at the same point of crankshaft rotation, and are of an equal magnitude, a state of equilibrium or balance is reached.


Removal

1. Separate the crankcase halves (see page 5-4).
2. With the crankcase halves separated, lift out the balancer shaft complete with the shaft bearings/circlips.

Note:

- **As the shaft is released from the crankcase, the backlash eliminator gear will spring out of alignment with the crankshaft.**
3. To remove the left hand bearing, slide the bearing, circlip and bearing sleeve from the balancer shaft. Note the orientation of the bearing prior to removal.
 4. To remove the right hand bearing, remove the circlip and washer, and, using a press and press bars remove the bearing race from the shaft, ensuring the inner bearing race is supported. Note the orientation of the bearing prior to removal. DO NOT remove the drive gear from the shaft.

5. To strip the backlash eliminator from the drive gear, release the circlip and remove the wave-washer, backlash gear and spring.



1. Balancer shaft
2. Wave washer
3. Circlip

Inspection

1. Inspect all gears for chipped or missing teeth.
2. Inspect all bearings for signs of overheating (blue discolouration), seized or damaged rollers, and any other damage.
3. Inspect the backlash spring for deformities, damage etc.
4. Inspect the gear teeth for overheating (blue discolouration).

Warning

When using a press, always wear overalls, eye face and hand protection. Objects such as bearings frequently break-up under load and the debris caused during break-up may cause damage and injury to unprotected parts of the body.

Never wear loose clothing, which could become trapped in the press and cause crushing injury to the hand, arms or other parts of the anatomy.

Caution


Do not remove the drive gear from the balancer shaft. The drive gear is aligned to the shaft. If the balancer and drive gear are not correctly aligned, severe engine vibration will occur leading to damage to components.

Assembly/Installation

Note:


- Before assembling the backlash gear to the balancer shaft, lubricate all contact surfaces of the balancer drive gear, backlash spring and backlash gear with a 50/50 solution of engine oil and molybdenum disulphide grease.

- If the backlash gear was disassembled, fit the backlash spring over the shaft and position to the balancer drive gear, positioning the spring ends on either side of the peg.
- Fit the backlash gear, ensuring its peg is located anti-clockwise (viewed from the left hand bearing end of the shaft) of the balancer gear peg and also between the spring ends.



- Balancer shaft
- Backlash gear
- Backlash spring

- Fit the wave washer and secure all components in position with the circlip.



- Balancer shaft
- Wave washer
- Circlip

- Using a press and press bars, fit the right hand bearing to the shaft, with the circlip positioned nearest to the drive gear. Ensure the inner race of the bearing is supported when installing the bearing.

Warning


When using a press, always wear overalls, eye face and hand protection. Objects such as bearings frequently break-up under load and the debris caused during break-up may cause damage and injury to unprotected parts of the body.

Never wear loose clothing, which could become trapped in the press and cause crushing injury to the hand, arms or other parts of the anatomy.

- Refit the washer and a new circlip to the shaft.
- Lubricate and fit the left hand bearing and install a new circlip in the same orientation as noted prior to removal.

Note:

- Prior to installation in the crankcase, it is essential that the markings on the backlash eliminator and drive gears are brought into alignment against the tension of the spring. This will facilitate correct positioning of the balancer in relation to the crankshaft when both are installed in the crankcase.




- Drive gear 'dot'
- Backlash gear line

- Using tool T3880106, bring the backlash and drive gear marks into alignment against the backlash spring as follows:

- Engage the peg of tool T3880106 into a tooth of the backlash gear. Rotate the backlash gear against the spring until the marks align.

Note:

- When in alignment, the line on the backlash gear must be located directly above the drive gear tooth marked with a 'dot'.
 - Since the drive gear 'dot' cannot be seen when the backlash gear is in alignment, always mark the 'dot'-marked gear tooth with a paint mark in order that it can always be identified.
8. Secure the backlash gear in position with the fixture supplied with the tool by placing the fixture pegs across two gear teeth (ensure that the fixture will not be in the way when assembling the balancer to the crank).



cdon


1. Tool T3880106
2. Securing fixture
3. Balancer backlash gear marking



Caution

If the balancer and crankshaft are not correctly aligned, severe engine vibration will occur leading to damage to components.


9. With the drive and backlash eliminator gears still correctly aligned, locate the balancer to the crankcase. Align the balancer gears and crankshaft as shown in the illustration below.



cdmz

1. Balancer gear marking
2. Crankshaft markings


10. Ensure that the right hand bearing circlip and dowel locate correctly in the corresponding groove in the crankcase.



lol

1. Balancer shaft (right hand bearing)
2. Circlip
3. Dowel

11. Ensure that the left hand bearing circlip and dowel locate correctly in the corresponding groove in the crankcase



cdok

1. Balancer shaft (left hand bearing)
2. Circlip
3. Dowel

12. Remove the securing fixture.
13. Check that the balancer and crankshaft are correctly aligned before continuing to assemble the crankcase halves.
14. Assemble the crankcase halves (see page 5-4).


7 Transmission

Table of Contents


Exploded View, Input and Output Shafts - up to Engine Number 330118	7.2
Exploded View, Input and Output Shafts - from Engine Number 330119	7.3
Exploded View, Sprag Clutch and Starter Gears	7.4
Exploded View, Gear Selectors and Drum	7.5
Exploded View, Gear Change Mechanism	7.6
Selector Shaft, Selector Forks and Drum	7.7
Removal	7.7
Inspection	7.9
Installation	7.9
Input and Output Shafts Assemblies	7.12
Removal	7.12
Installation	7.13
Input Shaft	7.14
Disassembly	7.14
Inspection	7.15
Exploded View - Input Shaft	7.16
Output Shaft	7.19
Disassembly	7.19
Exploded View - Output Shaft	7.20
Assembly	7.21
Starter Drive Gears/Sprag Clutch	7.23
Removal	7.23
Inspection	7.24
Installation	7.24

Transmission


Exploded View, Input and Output Shafts - up to Engine Number 330118




Exploded View, Input and Output Shafts - from Engine Number 330119




Exploded View, Sprag Clutch and Starter Gears






Exploded View, Gear Change Mechanism



Selector Shaft, Selector Forks and Drum

Removal


1. Remove the engine from the frame (see page 9-3).
2. Separate the two halves of the crankcase (see page 5-4).
3. Remove the output shaft from the crankcase (see page 7-12).
4. Release the two fixings and remove the baffle plate from the crankcase breather. Discard the fixings.



1. Crankcase breather baffle plate


2. Fixings

5. If not already removed, note the position and orientation of the gear pedal crank in relation to the shaft, then remove the crank.
6. Remove the E-clip and washer from the gear pedal end of the gear change shaft.



1. Gear change shaft
2. E-clip
3. Washer

7. Withdraw the gear change shaft from the clutch end of the crankcase.




1. Gear change shaft

Note:


- The detent arm is held in position under spring pressure. Prior to removal, note the orientation of the detent arm, fixing and spring, relative to the selector drum detent wheel. The same orientation must be retained on assembly.

8. Remove and discard the fixing securing the detent arm.
9. Withdraw the detent arm complete with its flanged sleeve, spring and washer.



1. Detent arm
2. Fixing
3. Spring
4. Detent wheel

10. Remove and discard the two selector shaft retaining fixings, noting the position of the washer and the selector drum keeper plate.



1. Selector drum keeper plate
2. Input selector shaft fixing
3. Output selector shaft fixing and washer




Caution

The two output shaft selector forks can be fitted incorrectly. Ensure the position and orientation of the selector forks are marked prior to removal. Incorrect fitting of the selector forks will cause gearbox damage.

Note:


- All models except the Daytona 675 from VIN 381275: The fifth gear selector fork, located nearest to the clutch, has a special molybdenum coating on the selector forks. This special coating is identified by its dull grey colour, when compared to the sixth gear selector fork which is chromed.
- Daytona 675 from VIN381275: The fifth and sixth gear selector forks have a special molybdenum coating on the selector forks.

11. Slide the output selector shaft from the crankcase in the direction of the clutch. Collect the two selector forks as they are released by the selector shaft.




1. Output selector shaft
2. Sixth gear selector fork
3. Fifth gear selector fork

12. Noting the position of the selector fork, remove the input selector shaft, leaving the selector fork in the gearbox.



1. Input selector shaft
2. Selector fork

13. Withdraw the selector drum from within the crankcase.



1. Selector drum removal

14. Collect the input shaft selector fork from the crankcase.

Inspection

1. Examine all components for damage and/or wear, paying particular attention to the selector forks and selector drum. Replace any parts that are damaged and/or worn.

Gear selector fork thickness

Standard	5.90 - 6.00 mm
Service limit	5.80 mm

Gear selector groove width

Standard	6.10 - 6.17 mm
Service limit	6.27 mm


Selector fork to groove clearance

Service limit	0.47 mm max
---------------	-------------

2. Examine the gear change shaft seal for damage and/or wear. Replace the seal if damaged and/or worn.

Installation


1. Position the input shaft selector fork into the crankcase, locating the forks into the selector groove on the input shaft. Ensure the fork is fitted in the position noted during removal.



1. Input shaft selector fork

2. Input shaft

2. Using clean engine oil, lubricate the selector drum bearings. Lubricate the selector drum tracks with a 50/50 solution of engine oil and molybdenum disulphide grease.
3. Position the selector drum into the crankcase.



1. Selector drum


4. Rotate the selector drum and ensure a smooth movement. Rectify as necessary.



Caution

The selector forks can be fitted incorrectly. Ensure the position and orientation of the selector forks are the same as noted during removal. Incorrect fitting of the selector forks will cause gearbox damage.

5. Push the input selector shaft into the crankcase from the clutch end. As the shaft is inserted locate the selector fork onto the shaft. Ensure the fork is fitted in the position noted during removal.




1. Input selector shaft
2. Selector fork

Note:


- For Daytona 675 up to VIN 381274, Street Triple and Street Triple R all VINs: The fifth gear selector fork, located nearest to the clutch, has a special molybdenum coating on the selector forks. This special coating is identified by its dull grey colour, when compared to the sixth gear selector fork which is chromed.
- For Daytona 675 from VIN381275 only: The fifth and sixth gear selector forks have a special molybdenum coating on the selector forks.

6. Push the output selector shaft into the crankcase from the clutch end. As the shaft is inserted, locate the selector forks. Ensure the selector forks are fitted in the positions noted during removal.




1. Output selector shaft
2. Sixth gear selector fork
3. Fifth gear selector fork

7. Fit two new selector shaft retaining fixings, ensuring the washer and the selector drum keeper plate are fitted in the positions noted during removal. Tighten the fixings to **12 Nm**.




1. Selector drum/shaft keeper plate
2. Fixing
3. Output selector shaft fixing and washer

8. Assemble the detent arm as noted on removal with a new fixing and place up to the crankcase.




1. Spring
2. Washer
3. Detent arm
4. Flanged sleeve
5. Fixing

9. Hold the detent arm assembly in position and insert a new fixing. Start the thread and push the detent arm, using finger pressure only, to locate on the selector drum detent wheel.
Ensure the detent arm remains correctly located on the detent wheel and the spring is correctly seated in the recess in the crankcase. Ensure the shoulder of the flanged sleeve is located in the bore of the detent arm and tighten the fixing to **12 Nm**.




1. Detent arm
2. Fixing
3. Spring
4. Selector drum detent wheel

10. Rotate the selector drum to the neutral position. Ensure that the detent arm locates in the raised profile in the detent wheel (neutral position).



1. Detent arm
2. Neutral position

11. Using clean engine oil, lubricate the lip of the seal on the gear change shaft.



1. Gear change shaft seal
2. Gear change shaft bearing


12. Lubricate, with a 50/50 solution of engine oil and molybdenum disulphide grease, both sides of the forks and the slider plates of the selector mechanism on the gear change shaft.



Caution

Take care to avoid damaging the lip of the seal when inserting the gear change shaft into the crankcase. A damaged seal will lead to oil loss and could result in engine damage.


13. Insert the gear change shaft into the crankcase. Gently push the gear pedal end of the shaft through the bearing and lip seal at the clutch side of the crankcase, and the sealed bearing, located at the gear pedal side of the crankcase.



1. Gearchange shaft
2. Abutment bolt
3. Spring

14. Ensure that the gear change shaft fingers locate in the detent wheel/arm and that the spring fits either side of the abutment bolt.

15. Fit the washer and E-clip to the gear pedal end of the gear change shaft.



kakht1

1. Gear change shaft
2. E-clip
3. Washer

16. Fit the gear pedal crank to the shaft in the same orientation as noted prior to removal. Ensure the 'dot' mark on the shaft aligns with the split line on the gear pedal crank. Tighten the fixing to **9 Nm**.
17. Incorporating new fixings, refit the baffle plate to the crankcase breather. Tighten the fixings to **9 Nm**.
18. Refit the output shaft (see page 7-13).
19. Assemble the two halves of the crankcase (see page 5-4).
20. Refit the engine to the frame (see page 9-4).

Input and Output Shafts Assemblies

Removal

Note:

- The input and output shafts may be removed from the upper crankcase after first separating the lower crankcase from the upper.


Note:

- The rear needle roller bearing on the input shaft remains in the crankcase on removal of the shaft.

1. Remove the engine from the frame (see page 9-3).
2. Separate the two halves of the crankcase (see page 5-4).
3. Lift the output shaft from the upper crankcase, noting the orientation of each bearing, their circlips and dowels.
4. Remove the selector shafts and forks (see page 7-7).


Note:

- The input shaft bearing housing fixings may not be re-used but should be retained for use during installation of the input shaft.
5. **Up to engine number 330118:** Release the three fixings securing the input shaft bearing housing to the upper crankcase.




1. Fixings
2. Bearing housing

6. **From engine number 330119 only:** Release the three fixings securing and remove the retaining plate.



- cdmb_4
1. Fixings
 2. Retaining plate
 3. Bearing housing

7. **All engines:** Insert two M6 bolts into the two threaded holes at the periphery of the bearing housing. Evenly and progressively tighten both bolts to draw the bearing housing and input shaft from the crankcase.




- cdmb_3
1. Bearing housing
 2. M6 threaded holes
 3. Transmission oil tube

8. If required, the transmission oil tube can now be removed. Remove and discard the three oil tube O-rings.

Installation


1. If removed, check the transmission oil tube for blockages and contamination. Carefully fit new O-rings to the transmission oil tube and insert the tube into the crankcase, ensuring the tag on the tube locates in the slot in the crankcase.

2. Locate the input shaft to the upper crankcase, installing it through the aperture for the bearing housing.
3. Fit the bearing housing into the aperture, by hand, as deeply as possible.
4. Using the old fixings, evenly and progressively tighten them to draw the bearing housing into the upper crankcase until fully home. Remove and discard the fixings.



- cdmb
1. Bearing housing
 2. Fixings
 3. M6 threaded holes
 4. Transmission oil tube


5. **Up to engine number 330118:** Install new fixings to the bearing housing and tighten to **12 Nm**.
6. **From engine number 330119:** Fit the retaining plate. Install new fixings and tighten to **12 Nm**.



- cdmb_4
1. Fixings
 2. Retaining plate
 3. Bearing housing


7. Refit the selectors and shafts (see page 7-9).

8. Refit the output shaft to the crankcase ensuring the snap-ring locates in the corresponding groove in the crankcase, and the dowel locates in the slot in the upper crankcase.
9. Ensure the output shaft seal aligns with its recess in the crankcase.



1. Groove in crankcase
2. Snap ring
3. Dowel
4. Seal

10. Ensure the hole in the output shaft needle roller bearing outer race is positioned to locate onto the dowel provided in the upper crankcase.



1. Roller bearing
2. Dowel

11. Assemble the two halves of the crankcase (see page 5-4).
12. Refit the engine to the frame (see page 9-4).

Input Shaft

Disassembly

Note:

- The numbers in brackets in the following text refer to the exploded view on page 7-16.

Working from the opposite end to where the clutch assembly is fitted, dismantle the input shaft as follows:

1. Slide off the plain thrust washer (1).
2. Mark one side of second gear to denote its correct orientation. Remove second gear (2).
3. Remove the splined lock washers (3 and 4).
4. Mark one side of sixth gear to denote its correct orientation. Remove sixth gear (6), complete with the splined bush (5) which runs inside the gear.
5. Remove the splined thrust washer (7) from in front of the circlip between sixth and third/fourth gear.
6. Remove the circlip (8) from the shaft.
7. Mark one side of the combined third/fourth gear to denote its correct orientation. Remove the combined third/fourth gear (9).
8. Remove the circlip (10) from in front of fifth gear.
9. Remove the splined thrust washer (11) adjacent to fifth gear.
10. Mark one side of fifth gear to denote its correct orientation. Remove fifth gear (12), complete with the plain bush (13) which runs inside the gear.

Note:

- Unless the bearing at the clutch end of the input shaft is damaged or worn, it is not normally necessary to remove it from the shaft. The bearing is pressed onto the shaft and is also pressed into its housing. The bearing and housing are removed from the shaft together and are then separated.
 - Up to engine number 330118, the bearing is retained in the bearing housing with a circlip.
11. Up to engine 330118 only: Remove the circlip (15) from the bearing housing.




Warning

When using a press, always wear overalls, eye face and hand protection. Objects such as bearings frequently break-up under load and the debris caused during break-up may cause damage and injury to unprotected parts of the body.

Never wear loose clothing, which could become trapped in the press and cause crushing injuries to the hand, arms or other parts of the anatomy.


12. Support the bearing and housing (16 and 17) on press bars, then press the shaft (14) through the bearing and housing as shown below.




1. Press bars
2. Bearing/housing

13. **All engines:** Support the outer circumference of the bearing housing on press bars, then press the bearing through the housing.

Up to engine
number 330118



From engine
number 330119




Pressing out the Bearing

Inspection

1. Examine all gears, bearings and bushes and thrust washers for damage, distortion, chipped teeth and wear beyond the service limits. Replace all defective components and always use new circlips to assemble the shaft.
2. Thoroughly clean the bearing housing and inspect for damage, scoring and cracks. Replace the housing if necessary.

Exploded View - Input Shaft



1. Thrust washer
2. Second gear
3. Lock washer
4. Splined washer
5. Splined bush
6. Sixth gear
7. Splined thrust washer
8. Circlip
9. Third/fourth gear

10. Circlip
11. Splined thrust washer
12. Fifth gear
13. Plain bush
14. Input shaft
15. Circlip
16. Bearing
17. Bearing housing
18. Bearing retainer

Assembly

Note:

- The numbers in brackets in the following text refer to the exploded view on page 7-16.
- Lubricate each gear, thrust washer and bush with clean engine oil during assembly.

Warning

When using a press, always wear overalls, eye face and hand protection. Objects such as bearings frequently break-up under load and the debris caused during break-up may cause damage and injury to unprotected parts of the body.

Never wear loose clothing, which could become trapped in the press and cause crushing injuries to the hand, arms or other parts of the anatomy.

Caution

Bushes and gears with oil holes must always be MISALIGNED with the corresponding oil holes in the input shaft. Reduced oil pressure and gear lubrication may result from alignment of the oil holes, which would cause premature wear of engine and transmission components.

Caution

Removing the input shaft bearing from the shaft and its housing will damage the bearing and snap ring. Never re-use removed bearings or snap rings as use of damaged or weakened components could lead to engine and transmission damage. Also, check for damage to the housing itself.

1. **Up to engine number 330118 only:** Apply approximately 1 gram of ThreeBond 1375B to the circumference of a new bearing and position the bearing to the housing, ensuring the bearing dowel aligns with the slot in the housing. Ensure no ThreeBond enters the bearing.


Caution

Press only on the bearing outer race to prevent bearing damage.

2. Support the housing on press bars as shown below and press the bearing fully into the housing in the direction of the arrow.

Up to engine
number 330118

From engine
number 330119



1. Bearing housing


2. Bearing

3. **Up to engine number 330118 only:** Retain the bearing with a new circlip.

Caution

Press only on the bearing inner race to prevent bearing damage.

4. Locate the bearing and housing to the input shaft. Carefully support the shaft on the press bed, and using a suitable sleeve over the input shaft to ensure the bearing is pressed only on the inner race, press the bearing onto the shaft.



1. Sleeve

2. Bearing/housing


3. Press bars

4. Input shaft

5. Fit the plain bush (13) to the shaft.
6. Fit fifth gear (12) to the input shaft as noted during disassembly, with the dog teeth pointing away from the input shaft bearing.

Transmission

7. Slide on the splined thrust washer (11).
8. Fit a new circlip (10) to the input shaft ensuring that the clip is located in the circlip groove as shown below.



admno


1. Fifth gear
2. Thrust washer
3. Circlip

9. Fit the combined third/fourth gear (9) as noted during disassembly, with the larger gear facing toward fifth gear. Ensure that the oil hole in the input shaft DOES NOT align with the oil hole in the gear.

Warning

If the oil hole in the third/fourth gear is aligned with the corresponding hole in the input shaft, engine oil pressure and gear lubrication will be reduced. Reduced oil pressure and gear lubrication will cause engine damage and could also lead to engine seizure resulting in loss of motorcycle control and an accident


10. Fit a new circlip (8) to the input shaft ensuring that the circlip is located in the circlip groove as shown below.



odmp

1. Sixth gear
2. Thrust washer
3. Circlip

11. Fit the splined thrust washer (7) to the input shaft and slide up the shaft until in contact with the circlip.
12. Fit the splined bush (5) from sixth gear. Ensure that the oil hole in the input shaft DOES NOT align with the oil hole in the gear.
13. Fit sixth gear (6) as noted during disassembly, with the dog teeth facing third/fourth gear.
14. Fit the splined and lock washers (4 and 3), ensuring the tabs in the smaller washer (3) locate in the slots in the larger (4) washer.



odmq

1. Second gear
2. Large splined lock washer
3. Small splined lock washer

15. Fit second gear (2) to the shaft as noted during disassembly.
16. Fit the plain thrust washer (1) adjacent to second gear.

Output Shaft

Note:

- The numbers in brackets in the following text refer to the exploded view on page 7-20.

Working from the opposite end to the drive sprocket, dismantle the output shaft as follows.

Disassembly


1. Remove the output shaft bearing (1) and plain thrust washer (2).
2. Mark one side of first gear to denote its correct orientation. Remove first gear (3) from the shaft, complete with the plain bush (4) which runs inside the gear.
3. Remove the plain thrust washer (5).
4. Mark one side of fifth gear to denote its correct orientation. Remove fifth gear (6) from the shaft.
5. Remove the circlip (7) and splined thrust washer (8) from in front of fourth gear.
6. Mark one side of fourth gear to denote its correct orientation. Remove fourth gear (9) complete with the splined bush which runs inside the gear (10).
7. Remove the splined lock washers (11 and 12).
8. Mark one side of third gear to denote its correct orientation. Remove third gear (14) off the shaft complete with the splined bush (13) which runs inside the gear.
9. Remove the splined thrust washer (15).
10. Remove the circlip (16) from in front of sixth gear.
11. Mark one side of sixth gear to denote its correct orientation. Remove sixth gear (17) from the shaft.
12. Remove the circlip (18) from in front of second gear.
13. Remove the splined thrust washer (19).
14. Mark one side of second gear to denote its correct orientation. Remove second gear (21) from the shaft, complete with the plain bush (20) which runs inside the gear.
15. Position the output shaft (22) in a vice with soft jaws fitted. Tighten the vice to prevent the shaft from turning and release the tab washer (28) from the output sprocket nut (29), then release the nut.
16. Remove the output sprocket nut (29), tab washer (28) and sprocket (27).
17. Collect the output shaft seal (26).
18. If it is found necessary to replace the large bearing (24) at the end of the shaft, use a press to remove both the bearing and output shaft sprocket spacer (25) together.



Warning

When removing the output shaft bearing, always wear overalls, eye, face and hand protection. The bearing races are hardened and are liable to splinter if broken. Debris from broken bearings could cause injury to eyes, face and any unprotected parts of the body.

Exploded View - Output Shaft



1. Bearing
2. Thrust washer
3. First gear
4. Plain bush
5. Thrust washer
6. Fifth gear
7. Circlip
8. Splined thrust washer
9. Fourth gear
10. Splined bush
11. Lock washer
12. Splined washer
13. Splined bush
14. Third gear
15. Splined washer

16. Circlip
17. Sixth gear
18. Circlip
19. Splined thrust washer
20. Plain bush
21. Second gear
22. Output shaft
23. Snap ring
24. Bearing
25. Sprocket spacer
26. Output shaft seal
27. Output sprocket
28. Tab washer
29. Output sprocket nut

Assembly

Note:

- The numbers in brackets in the following text refer to the exploded view on page 7-20.
- Lubricate each gear and bush with clean engine oil during assembly.
- Examine all gears, bearings and sleeves for damage, chipped teeth and wear beyond the service limits. Replace all suspect components and always use new circlips, a new output shaft seal and a new sprocket tab washer to assemble the shaft.

Warning

When using a press, always wear overalls, eye face and hand protection. Objects such as bearings frequently break-up under load and the debris caused during break-up may cause damage and injury to unprotected parts of the body.

Never wear loose clothing, which could become trapped in the press and cause crushing injuries to the hand, arms or other parts of the anatomy.

Caution

Bushes and gears with oil holes must always be MISALIGNED with the corresponding oil holes in the output shaft. Reduced oil pressure and gear lubrication may result from alignment of the oil holes, which would cause premature wear of engine and transmission components.


Caution

Removing the output shaft bearing from the shaft will damage the bearing and snap ring. Never re-use removed bearings or snap rings as use of damaged or weakened components could lead to engine and transmission damage.

Caution

Press only on the bearing inner race to prevent bearing damage.

1. Working from the output sprocket end of the shaft, fit a new bearing (24) and a new sprocket spacer (25) to the shaft using a press and press bars. Fit the sleeve with the large chamfer facing outwards.




1. Output shaft

2. Bearing

3. Press bars

2. Lubricate and fit a new output shaft seal (26).
3. Transfer the shaft to the vice and secure between soft jaws. Fit the output sprocket (27), new tab washer (28) and nut (29). Tighten the nut to **85 Nm**. Close the tab washer.
4. Withdraw the shaft from the vice and continue to assemble from the opposite end to the output sprocket.
5. Fit the plain bush (20) to the shaft.
6. Locate second gear (21) to the shaft as noted during disassembly, with the large step side facing towards the output sprocket end. Fit the splined thrust washer (19) and retain with a new circlip (18) as shown below.




1. Second gear

2. Thrust washer


3. Circlip

7. Fit sixth gear (17) as noted during disassembly, with the selector fork groove facing away from the output sprocket end. Ensure that the oil holes in the gear DO NOT align with the corresponding oil hole in the output shaft.
8. Fit a new circlip (16) to retain sixth gear. Fit the splined thrust washer (15) to the rear of third gear as shown below.



1. Third gear
2. Splined thrust washer
3. Circlip


9. Fit the splined bush (13) for third gear. Ensure that the oil holes in the gear DO NOT align with the corresponding oil hole in the output shaft. Fit third gear (14) to the shaft with the large step side facing away from the output sprocket.
10. Fit the splined lock washers (12 and 11), ensuring the tabs in the smaller washer (11) locate in the slots in the larger washer (12) as shown below.



1. Third gear
2. Large splined lock washer
3. Small splined lock washer


11. Fit the splined bush (10) from fourth gear. Ensure that the oil holes in the gear DO NOT align with the corresponding oil hole in the output shaft.

12. Fit fourth gear (9) as noted during disassembly, with the larger step side facing towards the output sprocket.
13. Fit the splined thrust washer (8) and retain with a new circlip (7) as shown below.



1. Fourth gear
2. Splined thrust washer
3. Circlip

14. Fit the fifth gear (6) to the shaft with the groove facing towards the output sprocket. Ensure that the oil holes in the gear DO NOT align with the corresponding oil hole in the output shaft.
15. Fit the first gear thrust washer (5) and plain bush (4).
16. Fit first gear (3) to the shaft as marked during disassembly as shown below.



1. First gear
2. Thrust washer
3. Thrust washer
4. Needle roller bearing

17. Finally fit the thrust washer (2) and needle roller bearing (1) to the end of the shaft.


Starter Drive Gears/Sprag Clutch

Removal

Note:


- The sprag clutch may be detached after first removing the rider's seat and the battery (disconnect the negative (black) lead first). The left hand lower fairing (Daytona 675 only) and the alternator must also be removed. Refer to the relevant sections for removal procedures.

1. Remove the rider's seat (see page 16-17).
2. Disconnect the battery, negative (black) lead first.
3. **Daytona 675 only:** Remove the left hand lower fairing (see page 16-20).
4. Release the bolts securing the left hand engine cover noting the position of the copper washer under the head of one of the upper bolts. Collect the solenoid/fairing bracket from under the front two bolts.
5. Remove the left hand engine cover and position aside.




1. Left hand engine cover
2. Copper washer position
3. Solenoid/fairing bracket

6. Withdraw the starter idler gear and shaft, noting the fitted position of the components.



1. Idler gear
2. Idler shaft


7. Remove the alternator rotor (see page 17-33).
8. Withdraw the starter drive gear from the sprag clutch.



1. Starter drive gear
2. Sprag clutch/housing
3. Alternator rotor

9. Remove and discard the fixings securing the sprag clutch housing to the alternator rotor. Withdraw the sprag clutch housing.

10. Remove the sprag clutch from the housing.




1. Sprag clutch housing
2. Sprag clutch assembly

Inspection

1. Check the sprag clutch bearings for overheating, wear and/or non-smooth operation. Replace the sprag clutch if overheating, wear and/or non-smooth operation is found.
2. Examine all gears for chipped teeth, overheating (going blue) and for any other damage.
3. With the sprag clutch mounted in the housing, check the sprag clutch for smooth, free movement in one direction only (as indicated by the arrow marked on the sprag clutch body).

Installation


1. Locate the sprag clutch to the housing as shown below. Push firmly until the lip seats in the recess provided in the housing.



1. Sprag clutch housing
2. Sprag clutch assembly


2. Fit the housing to the alternator rotor.

3. Ensure that the housing is squarely seated and is not jammed on the rotor. Install new fixings.
4. Working in the sequence shown, tighten the bolts to **16 Nm**. Once all six bolts have been tightened, go around again in sequence and recheck each bolt is correctly torqued, if any bolt moves, go around again. Repeatedly check the bolts in sequence until all are correctly torqued and do not move when checked, this will ensure the sprag clutch housing is correctly seated on the rotor.




Bolt Tightening Sequence

5. Fit the starter drive gear to the sprag clutch.



1. Starter drive gear
2. Sprag clutch housing
3. Alternator rotor


6. Refit the alternator rotor (see page 17-34).
7. Lubricate the idler gear shaft with a 50/50 solution of engine oil and molybdenum disulphide grease.
8. Fit the starter idler gear and shaft to the crankcase.



1. Idler gear
2. Idler shaft

9. Thoroughly clean the left hand engine cover.
10. Position a new gasket to the crankcase dowels then refit the left hand engine cover.

11. Ensure the bolt with the copper washer is correctly located. Refit the solenoid/fairing bracket to the front two bolts. Tighten the cover bolts to **9 Nm**.



1. Left hand engine cover
2. Copper washer position
3. Solenoid/fairing bracket

12. **Daytona 675 only:** Refit the left hand lower fairing (see page 16-22).
13. Reconnect the battery, positive (red) lead first.
14. Refit the rider's seat (see page 16-17)


8 Lubrication

Table of Contents


Exploded View - Sump	8.2
Exploded View - Oil Pump/Water Pump, Gears and Heat Exchanger	8.3
Engine Oil Circuit	8.4
Engine Oil Circuit Description	8.5
Heat Exchanger	8.5
Engine Oil	8.6
Specification	8.6
Triumph Engine Oil	8.6
Oil Level Inspection	8.6
Oil and Oil Filter Change	8.7
Disposal of Used Engine Oil	8.8
Oil Pump	8.9
Removal	8.9
Inspection	8.12
Assembly	8.13
Installation	8.13
Low Oil Pressure Warning Light Switch	8.15
Installation	8.15
Sump	8.15
Removal	8.15
Installation	8.16
Heat Exchanger	8.18
Removal	8.18
Inspection	8.18
Installation	8.19

Lubrication


Exploded View - Sump



Exploded View - Oil Pump/Water Pump, Gears and Heat Exchanger



Engine Oil Circuit



Engine Oil Circuit Description

Oil is collected from the sump and is drawn through a mesh strainer into the oil pump rotor. The oil pump is fitted with a single pumping rotor which supplies pressurised oil to the lubrication circuit via the oil pressure relief valve. The relief valve is set to open at 5.1 bar (75 lb/in²) and when open, returns high pressure oil direct to the sump.

Pressurised oil is delivered to the oil to water heat exchanger (mounted on the front of the engine), where it is cooled.


The cooled oil is then delivered to the outside rim of the oil filter, where it is filtered by passing through the filter membrane. Filtered oil is then fed into the lower crankcase gallery. From here it is distributed around the engine:

- Oil is delivered to the crankshaft main bearings and, via drillings in the crankshaft, to the big end bearings.
- Spray jets located in the upper crankcase, behind the main bearing shells, lubricate the pistons and connecting rod small ends. These jets are fed oil from the crankshaft oil feed. A low oil pressure warning light switch is also located in the upper crankcase gallery.
- Some oil is sent directly to the cylinder head via an internal gallery. Oil that arrives at the cylinder head is fed to both cams via a gallery in the cylinder head casting that delivers oil directly to the sprocket end of the camshafts. Oil is then fed through the hollow camshafts to the other camshaft bearings, the tappet buckets and the valves.
- Oil is fed to the gearbox via internal oil pipes and drillings that supply oil directly to the end of each shaft. Oil is circulated along the gearbox shafts to exit holes that feed directly to the bearings, gears and selectors.

On the Daytona 675, Street Triple and Street Triple R, oil is also fed to the alternator to aid cooling of the alternator components. The oil is taken from the crankshaft oil feed and directed to the alternator via a jet, located above the alternator rotor, in the upper crankcase.

Heat Exchanger

The heat exchanger is used to transfer heat from the engine oil into the coolant. Oil is delivered to the heat exchanger via a hollow centre bolt, after which it flows around the end tank and into the heat exchanger core, where it is circulated. Coolant is pumped around the outside of the heat exchanger core to cool the oil. The cooled oil then exits the heat exchanger and flows to the oil filter. An additional benefit of the heat exchanger is that, as the engine coolant reaches its operating temperature more quickly than the engine oil, the oil is heated by the engine coolant at lower engine temperatures; this allows the engine oil to reach its optimum operating temperature more quickly, thereby helping to improve engine oil life, reduce exhaust emissions and reduce engine wear.



Heat Exchanger Circuit

Engine Oil

Specification

Use semi or fully synthetic 10W/40 or 15W/50 motorcycle engine oil which meets specification API SH (or higher) and JASO MA, such as Mobil 1 Racing 4T.



Caution

Triumph high performance fuel injected engines are designed to use semi or fully synthetic motorcycle engine oil which meets specification API SH (or higher) AND JASO MA.

Do not add any chemical additives to the engine oil. The engine oil also lubricates the clutch and any additives could cause the clutch to slip.

Do not use mineral, vegetable, non-detergent oil, castor based oils or any oil not conforming to the required specification. The use of these oils may cause instant, severe engine damage.

Ensure no foreign matter enters the crankcase during an oil change or top-up.

Triumph Engine Oil

Your Triumph Motorcycle is a quality engineered product which has been carefully built and tested to exacting standards. Triumph Motorcycles are keen to ensure that you enjoy optimum performance from your machine and with this objective in mind have tested many of the engine lubricants currently available to the limits of their performance.

Mobil 1 Racing 4T consistently performed well during our tests and has become our primary recommendation for the lubrication of all current Triumph motorcycle engines.

Mobil 1 Racing 4T, specially filled for Triumph, is available from your authorised Triumph dealer.

Oil Level Inspection


In order for the engine, transmission, and clutch to function correctly, maintain the engine oil at the correct level, and change the oil and oil filter in accordance with scheduled maintenance requirements.



Warning

Motorcycle operation with insufficient, deteriorated, or contaminated engine oil will cause accelerated engine wear and may result in engine or transmission seizure. Seizure of the engine or transmission may lead to loss of motorcycle control and an accident.

1. Start the engine and run at idle for approximately five minutes.
2. Stop the engine, then wait for at least three minutes to allow the oil to settle.
3. Remove the dipstick, wipe clean and screw fully home in the crankcase.



1. Filler
2. Dipstick location in crankcase
3. Dipstick
4. Upper marking
5. Lower marking

Note:

- The actual level is indicated when the motorcycle is level and upright, not on the side stand, and when the filler has been screwed fully home.
 - Do not add oil through the dipstick hole in the crankcase.
4. Remove the dipstick.
 5. The oil level is indicated by lines on the dipstick. When full, the indicated oil level must be level with the upper marking on the dipstick.
 6. If the oil level is too low, remove the filler plug and add oil a little at a time through the filler plug hole in the clutch cover, until the correct level is reached.
 7. Once the correct level is reached, fit the dipstick and the filler plug.

Oil and Oil Filter Change



Warning

Prolonged or repeated contact with engine oil can lead to skin dryness, irritation and dermatitis. In addition, used engine oil contains potentially harmful contamination which can cause cancer. Wear suitable clothing and avoid skin contact.

The engine oil and filter must be replaced in accordance with scheduled maintenance requirements.


1. Warm up the engine thoroughly, and then stop the engine.
2. **Daytona 675 only:** Remove the lower fairings (see page 16-20).
3. Place an oil pan beneath the engine.



Warning

The oil may be hot to the touch. Contact with hot oil may cause the skin to be scalded or burned.

4. Remove the oil drain plug.




1. Oil drain plug

2. Oil filter

5. With the motorcycle on level ground, and on the sidestand, allow the oil to completely drain.

6. Unscrew and remove the oil filter using Triumph service tool T3880313.



1. Oil filter

2. Tool T3880313

7. Discard the oil filter.
8. Apply a smear of clean engine oil to the sealing ring of the new oil filter.
9. Fit the oil filter and tighten to **10 Nm** using Triumph service tool T3880313.
10. After the oil has completely drained out, fit a new sealing washer to the drain plug. Fit and tighten the plug to **25 Nm**.
11. Fill the engine with new oil of the type and grade listed previously and in the specification section.
12. Start the engine and allow to idle.
13. Ensure that the oil pressure warning light extinguishes shortly after starting.
14. Stop the engine and check the oil level. Adjust if necessary.
15. **Daytona 675 only:** Refit the lower fairings (see page 16-22).



Caution

Racing the engine before the oil reaches every part can cause engine damage or seizure.



Caution

If the engine oil pressure is too low, the low oil pressure warning light will illuminate. If this light stays on when the engine is running, stop the engine immediately and investigate the cause. Running the engine with low oil pressure will cause engine damage.

Disposal of Used Engine Oil

To protect the environment, do not pour oil on the ground, down sewers or drains, or into water courses. Dispose of used oil sensibly. If in doubt contact your local authority.

Oil Pump

Warning

Prolonged or repeated contact with engine oil can lead to skin dryness, irritation and dermatitis. Furthermore, used engine oil contains potentially harmful contaminants which can cause cancer.

When handling used engine oil, always wear protective clothing and avoid any skin contact with the oil.

Caution

Do not pour engine oil on the ground, down sewers or drains, or into water courses. To prevent pollution of water courses etc., dispose of used oil sensibly. If in doubt contact your local authority.

Removal

Note:

- The oil pump and water pump are supplied as an assembly and cannot be separated. This procedure covers the removal of the oil and water pump assembly.

- Remove the rider's seat (see page 16-17).
- Disconnect the battery, negative (black) lead first.
- Drain the coolant (see page 11-6 for Daytona 675, or page 11-8 for Street Triple and Street Triple R).
- Drain the engine oil (see page 8-7).


Warning

The oil may be hot to the touch. Contact with hot oil may cause the skin to be scalded or burned.

Warning


Prolonged or repeated contact with engine oil can lead to skin dryness, irritation and dermatitis. In addition used engine oil contains potentially harmful contaminants which can cause cancer. Wear suitable clothing and avoid skin contact.

- Remove the sump (see page 8-15).
- Remove the clutch (see page 4-6).
- Release and discard the two fixings and remove the oil transfer pipe. Remove and discard the two O-ring seals.




- Oil transfer pipe
- Fixings

- Release and discard the two fixings and remove the oil pick-up. Remove and discard the O-ring seal.




- Oil pick-up
- Fixings

9. Remove and discard the bolt securing the coolant inlet elbow to the crankcase and withdraw the elbow. Remove and discard the O-ring from the elbow.




1. Coolant inlet elbow
2. Fixing

10. Remove and discard the bolt securing the coolant outlet pipe to the crankcase and withdraw the pipe. Remove and discard the three O-rings from the pipe.




1. Coolant outlet pipe
2. Fixing

11. Release the fixings securing the drive chain guide to the crankcase and remove the guide.




1. Oil pump drive chain guide
2. Fixings

12. Slide the oil pump drive sprocket gently backwards and forwards to dislodge the inner needle roller bearing.




1. Oil pump drive sprocket
2. Needle roller bearing

13. Carefully remove the bearing while supporting the oil pump drive sprocket.




- 1. Needle roller bearing**
2. Oil pump drive sprocket

14. Release the fixings securing the drive chain cover to the oil pump. Remove the drive chain cover.




- 1. Oil pump**
2. Fixings
3. Drive chain cover

15. Using a suitable tool, slide the dowel upwards to release the oil pump from the crankcase. It is not necessary to remove the dowel completely from the oil pump.



- 1. Oil pump**
2. Dowel

16. Detach the drive chain from the oil pump.




- 1. Oil pump**
2. Drive chain

17. Carefully withdraw the oil pump from the crankcase.
18. Remove and discard the O-ring from the inlet sleeve on the water pump body.


Inspection

1. Release the fixing and remove the drive sprocket and spacer washer.



1. Oil pump
2. Spacer washer
3. Drive sprocket
4. Fixing

2. Release the three fixings and withdraw the oil pump body.



1. Oil pump body
2. Fixings




Caution

If any part of the oil pump is found to be outside the service limit, the complete pump must be replaced. Severe engine damage may result from the continued use of a faulty oil pump.

3. Measure the rotor tip clearance using feeler gauges.


Rotor Tip Clearance

Standard:	0.15 mm
Service limit:	0.20 mm



Rotor Tip Clearance

4. Measure the pump body clearance using feeler gauges.



Pump Body Clearance

Pump Body Clearance

Standard:	0.15 - 0.22 mm
Service limit:	0.35 mm


5. Measure the pump end clearance.

Pump End Clearance

Standard:	0.04 - 0.09 mm
Service limit:	0.17 mm

Assembly

1. If all clearances are within service limits, liberally apply clean engine oil to all internal components and refit the oil pump body to the oil pump rotor. Refit the fixings and tighten to **12 Nm**.
2. If any clearance measured is outside the service limits, renew the complete pump.
3. Inspect the sprockets and chain for wear and/or damage. Replace the sprockets and chain if wear and/or damage is found.
4. Check the water pump shaft and shaft bearings for side and end float. Renew if necessary.
5. Check for corrosion and scale build-up around the impeller and in the pump body. Renew if necessary.
6. Check the oil pump location dowel for damage. Renew if necessary.
7. Refit the spacer washer and drive sprocket. Apply ThreeBond 1374 to the fixing and tighten to **14 Nm**.



1. Oil pump
2. Spacer washer
3. Drive sprocket
4. Fixing


3. Position the oil pump to the crankcase and insert the water pump inlet sleeve into the opening in the crankcase.
4. Fit the oil pump to the crankcase, ensuring the oil pump dowel correctly locates into the bolt hole in the crankcase.



Caution

Do not use excessive force to insert the dowel into the crankcase. Severe dowel or crankcase damage may result from the use of excessive force.

5. Using a suitable pin punch, gently tap the dowel downwards into the crankcase until it seats.
6. Feed the drive chain over the transmission input shaft and fit to the sprocket.
7. Fit the drive chain to the sprocket on the oil pump.
8. Support the oil pump drive sprocket and carefully refit the needle roller bearing.



1. Needle roller bearing
2. Oil pump drive sprocket

Installation




Caution

Before fitting the oil pump to the crankcase ensure the pump internal surfaces have been 'wetted' with clean engine oil. The pump may fail to pick-up oil from the sump if the surfaces have not been 'wetted'. This will cause the engine to run without engine oil pressure and will lead to severe engine damage.


1. Install a new O-ring to the inlet sleeve on the water pump body.
2. Fill the oil pump with new engine oil, turning the pump rotor as the oil is poured in to ensure all surfaces are coated with oil.

9. Refit the oil pump drive chain cover to the oil pump and fit new bolts. Tighten the bolts to **12 Nm**.




1. Oil pump
2. Fixings
3. Drive chain cover

10. Refit the oil pump drive chain guide. Install new fixings and tighten to **9 Nm**.
11. Install a new O-ring to the coolant inlet elbow and position the elbow to the water pump inlet. Fit a new bolt and tighten to **9 Nm**.



1. Coolant inlet elbow
2. Fixing

12. Install three new O-rings to the coolant outlet pipe and position the pipe through the crankcase, locating it to the water pump outlet. Install a new fixing and tighten to **9 Nm**.




1. Coolant outlet pipe
2. Fixing

13. Install a new O-ring to the oil pick-up and refit the oil pick-up. Fit new bolts and tighten to **12 Nm**.
14. Install two new O-rings to the oil transfer pipe and refit the oil transfer pipe. Fit new bolts and tighten to **12 Nm**.
15. Refit the clutch (see page 4-9).
16. Refit the sump, ensuring the water pump drain tube is correctly installed (see page 8-16).
17. Reconnect the battery, positive (red lead) first.
18. Refit the rider's seat (see page 16-17).
19. Refill the engine with oil (see page 8-7).
20. Refill the cooling system (see page 11-7 for Daytona 675, or page 11-9 for Street Triple and Street Triple R).

Low Oil Pressure Warning Light Switch

The low oil pressure warning light switch is located in the upper crankcase, behind the cylinder head.



1. Low oil pressure warning light switch
2. Electrical connection

1. Remove the rider's seat (see page 16-17).
2. Disconnect the battery, negative (black) lead first.
3. Disconnect the electrical connection to the switch.
4. Remove the switch and collect the copper washer.

Installation

1. Incorporating a new copper washer, fit the switch and tighten to **13 Nm**.
2. Refit the electrical connection.
3. Reconnect the battery, positive (red) lead first.
4. Refit the rider's seat (see page 16-17).

Sump

Removal

1. Remove the rider's seat (see page 16-17).
2. Disconnect the battery, negative (black) lead first.
3. Drain the engine oil (see page 8-7).

Warning

The oil may be hot to the touch. Contact with hot oil may cause the skin to be scalded or burned.

Warning

Prolonged or repeated contact with engine oil can lead to skin dryness, irritation and dermatitis. In addition used engine oil contains potentially harmful contaminants which can cause cancer. Wear suitable clothing and avoid skin contact.


4. Remove the exhaust system (see page 10-116 for Daytona 675 or page 10-122 for Street Triple and Street Triple R).

Warning

The exhaust system will be hot if the engine has recently been running. Always allow sufficient time for the exhaust to cool before working on or near the exhaust system.

Contact with a hot exhaust could result in burn injuries.

5. Release the bolts securing the sump to the lower crankcase.




1. Sump
2. Fixings

Lubrication

6. Detach the sump and collect the water pump drain tube. Remove and discard the four drain tube O-rings.

Note:


- The water pump drain tube may remain attached to the water pump or become detached with the sump.



1. Water pump drain tube
2. O-rings

Note:


- From engine number 395930 a new sump gasket/baffle was introduced and is retrofitable.



1. Gasket
2. Gasket/baffle


7. **Up to engine number 395929 only:** Remove and discard the sump gasket.
From engine number 395930 only: Remove the sump gasket/baffle.

8. If necessary, release and discard the oil transfer pipe fixings and remove the oil transfer pipe. Remove and discard the two O-rings from the crankcase.



1. Oil transfer pipe
2. Fixings


Installation



1. Oil transfer pipe
2. Fixings

1. If removed, fit the oil transfer pipe incorporating new O-rings. Fit new fixings and tighten to **12 Nm**.


2. Incorporating new O-rings, position the water pump drain tube to the oil pump.



1. Water pump drain tube

2. O-rings

3. **Up to engine number 395929 only:** Incorporating a new sump gasket/baffle, position the sump to the lower crankcase.
From engine number 395929 only: Check the sump gasket/baffle for wear or damage, replace if necessary. Position the sump to the lower crankcase.
4. Tighten the sump fixings to **12 Nm**.



1. Sump

2. Fixings

5. Refit the exhaust system (see page 10-119 for Daytona 675 or page 10-124 for Street Triple and Street Triple R).

Note:

- **Use new exhaust gaskets at the downpipe connections with the cylinder head.**
6. Fill the engine with the correct grade of engine oil (see page 8-6).
 7. Reconnect the battery, positive (red) lead first.
 8. Start the engine and ensure that the low oil pressure warning light goes out shortly after starting.
 9. Stop the engine and check the engine oil level. Adjust if necessary (see page 8-6).
 10. **Daytona 675 only:** Refit the lower fairings (see page 16-20).
 11. Refit the rider's seat (see page 16-17).

Heat Exchanger

Removal

Note:

- Prior to disassembly of the coolant hoses, note the orientation and position of the hose clips to help ensure that they are returned to the same positions and orientation on assembly.

1. Position the motorcycle on level ground on the sidestand.
2. Remove the rider's seat (see page 16-17).
3. Disconnect the battery, negative (black) lead first.
4. **Daytona 675 only:** Remove the lower fairings (see page 16-20).
5. Drain the coolant (see page 11-6 for Daytona 675, or page 11-8 for Street Triple and Street Triple R).
6. Drain the engine oil (see page 8-7).



Warning

The oil may be hot to the touch. Contact with hot engine oil may cause skin to be scalded or burnt.




Warning

Prolonged or repeated contact with engine oil can lead to skin dryness, irritation and dermatitis. In addition used engine oil contains potentially harmful contaminants which can cause cancer. Wear suitable clothing and avoid skin contact.

7. Disconnect the coolant hoses from the heat exchanger.

8. Remove the centre bolt from the heat exchanger and withdraw it from the crankcase. Remove and discard the heat exchanger O-ring and the centre bolt sealing washer.




1. Heat exchanger
2. Centre bolt
3. Coolant hose clips

Inspection

1. Check the heat exchanger body for corrosion and/or damage.

Installation

1. Fit a new O-ring to the heat exchanger, and a new sealing washer to the centre bolt.



cdpq

1. Centre bolt
2. Sealing washer
3. Heat exchanger
4. O-ring


Note:

- To ensure correct positioning, ensure that the tab on the heat exchanger locates in the boss provided in the crankcase.



Caution

Do not rely on the tab to hold the heat exchanger in position while tightening the centre bolt. The tab will bend and will not prevent the heat exchanger from turning. Instead, firmly hold the heat exchanger in position by hand.




cdum

1. Heat exchanger tab
2. Crankcase boss

2. Fit the heat exchanger to the crankcase and tighten the centre bolt to **59 Nm**.

3. Fit the coolant hoses to the heat exchanger and tighten the coolant hose clips.



cdpl


1. Heat exchanger
2. Centre bolt
3. Coolant hoses

4. Refill the cooling system (see page 11-7 for Daytona 675 and page 11-9 for Street Triple and Street Triple R).
5. Refill the engine with oil (see page 8-7).
6. **Daytona 675 only:** Refit the lower fairings (see page 16-22).
7. Reconnect the battery, positive (red) lead first.
8. Start the engine and check for oil leaks. Once a leak check has been made, stop the engine and allow to stand for 3 minutes.
9. Adjust the engine oil level (see page 8-6).
10. Refit the rider's seat (see page 16-17).

Table of Contents

Engine Removal/Refit

Exploded View - Frame Fixings



Engine Removal/Refit

Removal

1. Remove the seat(s) (see page 16-17).
2. Disconnect the battery, negative (black) lead first and remove the battery (see page 17-14).
3. Place the motorcycle on a paddock stand.



Warning

Before starting work, ensure the motorcycle is stabilised and adequately supported. This will help prevent it from falling and causing injury to the operator or damage to the motorcycle.

4. Remove the rear panel(s) (see page 16-18 for Daytona 675 or page 16-19 for Street Triple and Street Triple R).
5. **Daytona 675 only:** Remove the lower fairings (see page 16-20).
6. Remove the fuel tank (see page 10-89).
7. Remove the airbox (see page 10-95).
8. Remove the throttle bodies (see page 10-106).
9. Drain the engine oil (see page 8-7).
10. Drain the coolant (see page 11-6 for Daytona 675 or page 11-8 for Street Triple and Street Triple R).
11. Remove the radiator (see page 11-13 for Daytona 675, or page 11-15 for Street Triple and Street Triple R).

Note:

- **Secure the coolant hoses to prevent damage as the engine is removed.**

12. Remove the exhaust system completely (see page 10-116 for Daytona 675 or page 10-122 for Street Triple and Street Triple R).
13. Set the drive chain adjustment to allow maximum free play in the chain (see page 12-7).
14. Disconnect the gearchange linkage at the gearbox shaft.
15. Remove the sprocket cover.




Caution

To prevent chain damage, do not allow the chain to come into contact with dirt, road grit etc.

16. Disconnect all electrical connections from the main harness to the engine.
17. Disconnect the clutch cable (see page 4-5).
18. Place a support beneath the engine and ensure that the frame is still adequately and securely supported.

19. Note the position of the two spacers installed to the lower gearbox bolt, one on either side of the engine.
20. Release the nuts securing the rear gearbox mounting bolts and remove the two bolts. Collect the two spacers from the lower bolt.



1. Rear gearbox bolt
2. Right hand spacer




1. Left hand spacer

Engine Removal/Refit


Note:

- The frame is fitted with four frame adjuster sleeves, located on the left hand side of the frame, as shown below.



1. Front frame adjuster position
2. Centre frame adjuster position
3. Rear upper frame adjuster position
4. Rear lower frame adjuster position


21. Using tool T3880103, slacken the two rear frame adjuster sleeves.



1. Tool T3880103
2. Rear upper frame adjuster
3. Rear lower frame adjuster

22. Release the nuts securing the left hand centre and front engine mounting bolts and remove the bolts.

23. Using tool T3880103, slacken the centre and front frame adjuster sleeves.



1. Tool T3880103
2. Front frame adjuster
3. Centre frame adjuster

24. Remove the two remaining (right hand) engine mounting bolts and lower the engine sufficiently to allow the drive chain to be detached from the output sprocket.
25. Remove the engine from the frame.



Caution

To prevent damage to components, lower the engine very carefully.

Installation

1. Position the engine beneath the frame.
2. Raise the engine, looping the drive chain over the output sprocket as it is raised.




Caution


Unless the following engine mounting bolt installation/tightening sequence is precisely followed, severe frame damage can occur.

3. Align the engine to the frame and carefully fit the right hand centre engine mounting bolt (located at the rear of the cylinder head) ensuring the engine is still adequately and securely supported.
4. Align the left hand centre engine mounting and using tool T3880103, tighten the frame adjuster to **3 Nm**. Carefully fit the bolt but do not fully tighten at this stage.

5. Temporarily insert the lower rear (gearbox) bolt from the left hand side, ensuring the two spacers are installed as noted during removal.
The bolt should only be inserted far enough to support the two spacers, as fully inserting the bolt will restrict access to the frame adjuster sleeve. Do not fit the nut.




1. Rear gearbox bolt
2. Right hand spacer



1. Left hand spacer


Note:

- The frame is fitted with four frame adjuster sleeves, located on the left hand side of the frame, as shown below.



1. Front frame adjuster position
2. Centre frame adjuster position
3. Rear upper frame adjuster position
4. Rear lower frame adjuster position


6. Using tool T3880103, tighten the two rear frame adjuster sleeves to **10 Nm**.



1. Tool T3880103
2. Rear upper frame adjuster
3. Rear lower frame adjuster

7. Fit the right hand front bolt (located at the front of the cylinder head), fit a new nut and tighten to **48 Nm**.


8. Remove the left hand centre engine mounting bolt fitted earlier and recheck the torque on the frame adjuster, using tool T3880103. Re-tighten the adjuster to **3 Nm**. Refit the bolt, and tighten to **48 Nm**.



1. Tool T3880103

2. Centre frame adjuster

9. Tighten the right hand centre bolt to **48 Nm**.
10. Remove the lower rear (gearbox) bolt from the right hand side and insert it from the left hand side. Fit a new nut and tighten to **48 Nm**.
11. Using tool T3880103, tighten the front frame adjuster to **3 Nm**.




1. Tool T3880103

2. Front upper frame adjuster

12. Fit the upper rear (gearbox) bolt from the left hand side. Fit a new nut and tighten to **48 Nm**.
13. Fit the left hand front bolt and fit a new nut. Tighten to **48 Nm**.
14. Remove the support from beneath the engine.
15. Refit the clutch cable (see page 4-6).
16. Reconnect all electrical connections to the engine.
17. Set the drive chain adjustment (see page 12-7).
18. Refit the gearchange linkage.

19. Refit the sprocket cover and tighten the bolts to **9 Nm**.
20. Fit new seals to the cylinder head. Ensure that the face of the seal with the tab is facing the cylinder head.



1. Cylinder head

2. Seal

3. Seal tab

21. Refit the exhaust system (see page 10-119 for Daytona 675 or page 10-124 for Street Triple and Street Triple R).
22. Refit the radiator (see page 11-14 for Daytona 675 or page 11-16 for Street Triple and Street Triple R).
23. Fill the engine with oil of the correct grade and viscosity (see page 8-7).
24. Refit the throttle bodies (see page 10-108).
25. Check the throttle cable adjustment (see page 10-103).
26. Refit the airbox (see page 10-96).
27. Refit the fuel tank (see page 10-90).
28. **Daytona 675 only:** Refit the lower fairings (see page 16-22).
29. Refit the rear panel(s) (see page 16-18 for Daytona 675 or page 16-19 for Street Triple and Street Triple R).
30. Refit the battery to the battery box and reconnect, positive (red) lead first (see page 17-15).
31. Refill the cooling system (see page 11-7 for Daytona 675, or page 11-9 for Street Triple and Street Triple R).
32. Remove the motorcycle from the paddock stand and place on the side stand.
33. Refit the seats (see page 16-17).

10 Fuel System/Engine Management

Exploded View - Fuel Tank and Fuel Pump	10.7
Exploded View - Fuel Rail, Throttles and Injectors	10.8
Exploded View - Airbox - Daytona 675	10.9
Exploded View - Airbox - Street Triple and Street Triple R	10.10
Exploded View - Exhaust System - Daytona 675	10.11
Exploded View - Exhaust System - Street Triple and Street Triple R	10.12
Exploded View - Evaporative System	10.13
Exploded View - Secondary Air Injection	10.14
Fuel Requirements	10.15
Fuel Requirements - all countries except USA	10.15
Fuel Requirements - USA	10.15
Oxygenated Gasoline	10.15
Ethanol	10.15
Methanol	10.15
MTBE (Methyl Tertiary Butyl Ether)	10.15
Glossary of Terms	10.16
Air temperature	10.16
Air temperature sensor	10.16
ATDC	10.16
Barometric pressure	10.16
Battery voltage	10.16
BTDC	10.16
Catalyst	10.16
Closed throttle position	10.16
Coolant temperature	10.16
Coolant temperature sensor	10.16
Cooling fan status	10.16
DTC	10.16
ECM	10.16
Engine speed	10.16
EXBV	10.16
Fall detection	10.16
Freeze frame	10.16
Gear position sensor	10.16
Idle fuel trim	10.16
Idle fueling	10.16
Idle reference speed	10.16
Ignition advance	10.16
Ignition switch position	10.16
Ignition timing	10.17
Injector pulse time	10.17
Lambda O2 Sensor	10.17
Long term fuel trim	10.17
MAP sensor	10.17

MIL	10.17
Open circuit	10.17
Over temp	10.17
Primary throttle position sensor	10.17
Primary throttle stepper motor	10.17
Purge valve duty cycle	10.17
Road speed sensor	10.17
Secondary air injection	10.17
Sensor supply voltage	10.17
Short circuit	10.17
Short term fuel trim	10.17
Sidestand status	10.17
Target dwell time	10.17
Throttle position	10.17
Throttle voltage	10.17
TDC	10.17
Vbatt	10.17
Engine Management System	10.18
System Description	10.18
System Sensors	10.18
Sensor Locations	10.19
System Actuators	10.20
Actuator Locations	10.21
Engine Management Circuit Diagram - Daytona 675 - up to VIN 300525 - without the Fuel Pump Relay	10.22
Engine Management Circuit Diagram - Daytona 675 - up to VIN 300525 - without the Fuel Pump Relay	10.23
Fuel Pump Circuit Diagram - Daytona 675 - from VIN 300526 to VIN 323544 - with the Fuel Pump Relay	10.24
Fuel Pump Circuit Diagram - Daytona 675 - from VIN 300526 to VIN 323544 - with the Fuel Pump Relay	10.25
Circuit Diagram - Engine Management System - Daytona 675 - from VIN 323545 to VIN 381274 ...	10.26
Circuit Diagram - Engine Management System - Daytona 675 - from VIN 323545 to VIN 381274 ...	10.27
Circuit Diagram - Engine Management System - Daytona 675 - from VIN 381275	10.28
Circuit Diagram - Engine Management System - Daytona 675 - from VIN 381275	10.29
Engine Management Circuit Diagram - Street Triple and Street Triple R	10.30
Engine Management Circuit Diagram - Street Triple and Street Triple R	10.31
System Diagnostics	10.32
On-board Fault Detection System	10.32
Diagnostic Tool Connection	10.32
Triumph Diagnostic Software	10.33
Build Data	10.33
Current Data	10.34
Sensor Data	10.35
Adaption Status	10.37

Fuel System/Engine Management

Function Tests	10.38
Adjust Tune.	10.39
Freeze-frame Data	10.39
Diagnostic Trouble Codes	10.40
Electrical Connectors	10.43
Before Disconnection:	10.43
When Disconnecting a Connector:	10.43
When Inspecting a Connector:	10.43
When Connecting a Connector:	10.43
Disconnection of ECM connectors	10.43
Reconnection of ECM connectors	10.44
Further Diagnosis	10.44
Crankshaft Sensor	10.45
Pinpoint Tests	10.45
Idle Speed Control	10.46
Pinpoint Tests	10.46
Fuel Injectors	10.48
Pinpoint Tests	10.48
Throttle Position Sensor	10.50
Pinpoint Tests	10.50
Purge Valve	10.52
Pinpoint Tests	10.52
Ignition Coils	10.54
Pinpoint Tests	10.54
Coolant Temperature Sensor	10.56
Pinpoint Tests	10.56
Intake Air Temperature Sensor	10.58
Pinpoint Tests	10.58
System Voltage	10.60
Pinpoint Tests	10.60
Cooling Fan Relay	10.61
Pinpoint Tests	10.61
Lambda Sensor	10.62
Pinpoint Tests	10.62
Lambda Sensor Heater	10.63
Pinpoint Tests	10.63
EEPROM Error	10.64
Fall Detection Switch	10.65
Pinpoint Tests	10.65
Vehicle Speed Sensor	10.66
Pinpoint Tests	10.66
Instrument Communication (CAN)	10.67
Pinpoint Tests	10.67

Fuel System/Engine Management

Fuel Level Sensor	10.68
Pinpoint Tests	10.68
Ambient (Barometric) Pressure Sensor	10.69
Pinpoint Tests	10.69
Manifold Absolute Pressure (Map) Sensor	10.70
Pinpoint Tests	10.70
Gear Position Sensor	10.71
Pinpoint Tests	10.71
Secondary Air Injection Valve	10.72
Pinpoint Tests	10.72
Fuel Pump - up to VIN 300525 - without Fuel Pump Relay	10.74
Pinpoint Tests	10.74
Fuel Pump - from VIN 300526 - with Fuel Pump Relay	10.76
Pinpoint Tests	10.76
Intake Air Flap Solenoid - Daytona 675 only	10.78
Pinpoint Tests	10.78
Exhaust Butterfly Valve (EXBV) Position Sensor - Daytona 675 only	10.80
Pinpoint Tests	10.80
Exhaust Butterfly Valve (EXBV) Motor - Daytona 675 only	10.81
Pinpoint Tests	10.81
EMS Main Relay Circuit	10.82
Pinpoint Tests	10.82
EMS Ignition Voltage Input Circuit	10.84
Pinpoint Tests	10.84
5 Volt Sensor Supply Circuit	10.85
Pinpoint Tests	10.85
Tune Lock	10.86
ECM or Tune ID Incorrect	10.87
Pinpoint Tests	10.87
Fault Finding - Non Electrical	10.88
Fuel Tank	10.89
Removal	10.89
Installation	10.90
Fuel Tank - Raising and Supporting - Street Triple and Street Triple R only	10.91
Fuel Tank - Lowering and Securing - Street Triple and Street Triple R only	10.91
Fuel Pump, Fuel Filter and Low Fuel Level Sensor	10.92
Removal	10.92
Installation	10.92
Fuel Pressure Checking	10.93
Fuel Delivery System	10.95
Airbox	10.95


Fuel System/Engine Management

Removal	10.95
Inspection	10.96
Installation.....	10.96
Air Filter Element.....	10.97
Removal	10.97
Installation.....	10.97
Intake Air Temperature Sensor	10.98
Removal	10.98
Installation.....	10.98
Map Sensor	10.98
Removal	10.98
Installation.....	10.98
Barometric Pressure Sensor - Daytona 675 only	10.99
Removal	10.99
Installation.....	10.99
Barometric Pressure Sensor - Street Triple and Street Triple R only	10.99
Removal	10.99
Installation.....	10.99
Fall Detection Switch - Daytona 675 only.....	10.100
Removal	10.100
Installation.....	10.100
Fall Detection Switch - Street Triple and Street Triple R only.....	10.100
Removal	10.100
Installation.....	10.100
Intake Air Duct - Daytona 675 only	10.101
Removal	10.101
Installation.....	10.101
Intake Air Flap Actuator - Daytona 675 only	10.101
Operation	10.101
Removal	10.101
Installation.....	10.102
Crankshaft position sensor.....	10.103
Throttle Cable	10.103
Adjustment.....	10.103
Removal	10.104
Inspection	10.105
Installation.....	10.105
Throttle Bodies/Injectors.....	10.106
Removal	10.106
Inspection	10.107
Installation.....	10.108
Throttle Body Balancing	10.109
Throttle Position Sensor	10.110
Removal	10.110


Fuel System/Engine Management

Installation	10.110
Idle Speed Control Stepper Motor	10.112
Removal	10.112
Installation	10.112
Engine Management Adaption	10.115
General Information	10.115
Adaption Status	10.115
Terminology	10.115
Typical Values	10.115
Forcing adaption to take place	10.115
Exhaust System - Daytona 675	10.116
Removal	10.116
Inspection	10.119
Assembly	10.119
Exhaust System - Street Triple and Street Triple R	10.122
Removal	10.122
Assembly	10.124
Exhaust Butterfly Valve Actuator - Daytona 675 only	10.126
Removal	10.126
Installation	10.127
Exhaust Butterfly Valve Cables - Daytona 675 only	10.128
Removal	10.128
Inspection	10.129
Installation	10.129
Exhaust Butterfly Valve Cable Adjustment - Daytona 675 only	10.131
Secondary Air Injection	10.134
System Purpose and Operation	10.134
Secondary Air Injection Solenoid Valve	10.135
Removal	10.135
Installation	10.135
Secondary Air Injection Reed Valves	10.135
Removal	10.135
Inspection	10.136
Installation	10.136
Evaporative Emissions Control System	10.137
California Models Only	10.137
Component Locations	10.137
Evaporative Control System - Engine Off	10.138
Evaporative Control System - Engine Running	10.139


Exploded View - Fuel Tank and Fuel Pump




Exploded View - Fuel Rail, Throttles and Injectors




Exploded View - Airbox - Daytona 675




Exploded View - Airbox - Street Triple and Street Triple R




Exploded View - Exhaust System - Daytona 675




Exploded View - Exhaust System - Street Triple and Street Triple R



Exploded View - Evaporative System



Exploded View - Secondary Air Injection



Fuel Requirements

Fuel Requirements - all countries except USA

Outside of America, Daytona 675 must be run on 95 RON (or higher) unleaded fuel, and Street Triple and Street Triple R must be run on 91 RON (or higher) unleaded fuel.

Fuel Requirements - USA

In the United States of America where the octane rating of fuel is measured in a different way, the following information may be applied:

Daytona 675 is designed to run on unleaded gasoline with a CLC or AKI octane rating $(R+M)/2$ of 89 or higher.

Street Triple and Street Triple R are designed to run on unleaded gasoline with a CLC or AKI octane rating $(R+M)/2$ of 87 or higher.

Note:

- If 'knocking' or 'pinking' occurs at a steady engine speed under normal load, use a different brand of gasoline or a higher octane rating.



Caution

The use of leaded gasoline is illegal in some countries, states or territories and will invalidate the vehicle and emissions control warranties. Additionally, leaded gasoline will cause damage to emissions control components.

Oxygenated Gasoline

To help in meeting clean air standards, some areas of the U.S. use oxygenated gasoline to help reduce harmful emissions. This model will give best performance when using unleaded gasoline. However, the following should be used as a guide to the use of oxygenated fuels.



Caution

Because of the generally higher volatility of oxygenated fuels, starting, engine response and fuel consumption may be adversely affected by their use. Should any of these difficulties be experienced, run the motorcycle on normal unleaded gasoline.

Ethanol

Ethanol fuel is a mixture of 10% ethanol and 90% gasoline and is often described under the names 'gasohol', 'ethanol enhanced', or 'contains ethanol'. This fuel may be used in Triumph motorcycles.

Methanol



Caution

Fuels containing methanol should not be used in Triumph motorcycles as damage to components in the fuel system can be caused by contact with methanol.

MTBE (Methyl Tertiary Butyl Ether)

The use of gasolines containing up to 15% MTBE (Methyl Tertiary Butyl Ether) is permitted in Triumph motorcycles.

Glossary of Terms

The following terms and abbreviations will be found in this section. Below is given a brief explanation of what some of the more common terms and abbreviations mean.

Air temperature

The air temperature in the air box and intake system.

Air temperature sensor

Sensor located in the airbox to detect the temperature of the incoming air.

ATDC

After Top Dead Centre (TDC).

Barometric pressure

Pressure of the ambient air.

Battery voltage

The voltage at the input to the Electronic Control Module (ECM).

BTDC

Before Top Dead Centre (TDC).

Catalyst

Device placed in the exhaust system which reduces exhaust emissions by stimulating secondary combustion of the exhaust gases.

Closed throttle position

Throttle position at idle (i.e. against end stop), measured as a voltage and expressed as percentage.

Coolant temperature

The coolant temperature in the cylinder head.

Coolant temperature sensor

Sensor which detects coolant temperature.

Cooling fan status

The 'on' or 'off' condition of the cooling fan.

DTC

Diagnostic Trouble Code.

ECM

Engine Control Module.

Engine speed

The crankshaft revolutions per minute.

EXBV

Exhaust Butterfly Valve.

Fall detection

The fall detection switch will detect if the motorcycle is on its side and will cut power to the ECM immediately.

Freeze frame

A data set captured at the time a Diagnostic Trouble Code (DTC) is set.

Gear position sensor

Gearbox mounted sensor which delivers information to the ECM. This is converted to the gear position value that is displayed on the instrument's gear position indicator and/or neutral lamp.

Idle fuel trim

The percentage above or below the nominal fuel requirement for the volume of air entering at idle.

Idle fueling

Adjustment of fueling at idle to suit the actual air inducted.

Idle reference speed

The target idle speed as determined by the Electronic Control Module (ECM). (It should be the same as the actual idle speed if the motorcycle is operating correctly.)

Ignition advance

The timing of the ignition at the spark plug relative to top dead centre (TDC).

Ignition switch position

The 'ON' or 'OFF' position of either or both the ignition switch and the engine stop switch.

Ignition timing

Same as 'ignition advance'.

Injector pulse time

The time during which an injector remains open (i.e. delivering fuel).

Lambda O₂ Sensor

The Lambda sensor measures the Oxygen levels in the exhaust gases and feeds this information to the ECM. Based on this information, adjustments to air/fuel ratio are made.

Long term fuel trim

Fueling after adapting to the engine's long term fueling requirements (closed loop only). See also short term fuel trim.

MAP sensor

Manifold Absolute Pressure (the air pressure in the intake system). Measured after the throttle valves. This reading is compared to the ambient pressure reading to allow the ECM to calculate engine load.

MIL

Malfunction Indicator Lamp.

Illuminates when most Diagnostic Trouble Codes (DTCs) are set.

Open circuit

A break in an electrical circuit - current cannot flow.

Over temp

High temperature within the Electronic Control Module (ECM) caused by an internal or external failure.

Primary throttle position sensor

Sensor for the primary (lower) throttle position.

Primary throttle stepper motor

Stepper motor used to vary throttle opening at idle and when the engine is cold.

Purge valve duty cycle

The time the purge valve is open in an open/close cycle, expressed as a percentage of the cycle time.

Road speed sensor

Gearbox mounted sensor which delivers information to the ECM. This is converted to the road speed value that is then displayed on the speedometer.

Secondary air injection

The secondary air injection system helps reduce levels of pollutants in the exhaust gases. It does this by introducing a small amount of air into each exhaust port which promotes further combustion of the fuel mixture in the exhaust system after it has left the combustion chamber.

Sensor supply voltage

Supply voltage to the system sensors (nominally 5 Volts).

Short circuit

A 'short cut' in an electrical circuit - current by-passes the intended circuit (usually to earth).

Short term fuel trim

A correction applied to the fuel mixture during closed loop catalyst operation. This, in turn has an effect on the long term fuel trim in that, if an engine constantly requires mixture correction, the long term fuel trim will adapt to this requirement thus reducing the need for constant short term adjustment.

Sidestand status

The 'up' or 'down' position of the side stand.

Target dwell time

The actual time from coil 'on' to coil 'off'.

Throttle position

The position of the throttle butterfly given as a percentage of the movement range. When the data is displayed on the diagnostic software, fully open need not be 100% nor fully closed 0%.

Throttle voltage

Voltage at the throttle potentiometer.

TDC

Top Dead Centre.

Vbatt

Battery voltage.

Engine Management System

System Description


The Daytona 675, Street Triple and Street Triple R models are fitted with an electronic engine management system which encompasses control of both ignition and fuel delivery. The electronic control module (ECM) draws information from sensors positioned around the engine, cooling and air intake systems and precisely calculates ignition advance and fueling requirements for all engine speeds and loads.

In addition, the system has an on-board diagnostic function. For additional information, see page 10-32.

System Sensors

- **Intake air temperature sensor** - situated in the top of the airbox. As the density of the air (and therefore the amount of oxygen available to ignite the fuel) changes with temperature, an intake air temperature sensor is fitted. Changes in air temperature (and therefore air density) are compensated for by adjusting the amount of fuel injected to a level consistent with clean combustion and low emissions.
- **Barometric pressure sensor - Daytona 675** - situated behind the cockpit and below the instrument pack. **Street Triple and Street Triple R** - situated on the rear subframe, forward of the rear light unit. The barometric pressure sensor measures atmospheric air pressure. With this information, the amount of fuel injected is adjusted to suit the prevailing conditions.
- **Manifold Absolute Pressure (MAP) sensor** - situated to the left side of the airbox, connected to each of the three throttle bodies by equal length tubes. The MAP sensor provides information to the ECM which is used at shallow throttle angles (very small throttle openings) to provide accurate engine load indications to the ECM. This degree of engine load accuracy allows the ECM to make very small adjustments to fuel and ignition which would otherwise not be possible from throttle angle data alone.
- **Clutch switch** - situated on the clutch lever. The clutch must be pulled in for the starter motor to operate.
- **Crankshaft position sensor** - situated in the alternator cover. The crankshaft position sensor detects movement of teeth attached to the alternator rotor. The toothed rotor gives a reference point from which the actual crankshaft position is calculated. The crankshaft position sensor information is used by the ECM to determine engine speed and crankshaft position in relation to the point where fuel is injected and ignition of the fuel occurs.
- **Engine coolant temperature sensor** - situated at the rear of the cylinder head. Coolant temperature information, received by the ECM, is used to optimise fueling at all engine temperatures and to calculate hot and cold start fueling requirements.
- **Throttle position sensor** - situated at the right end of the throttle body. Used to relay throttle position information to the ECM. Throttle opening angle is used by the ECM to determine fueling and ignition requirements for all throttle positions.
- **Road speed sensor** - situated in the upper crankcase, in front of the engine breather. The road speed sensor provides the ECM with data from which road speed is calculated and displayed on the speedometer.
- **Lambda sensor** - situated in the exhaust header system upstream of the catalyst. The lambda sensor constantly feeds information to the ECM on the content of the exhaust gases. Based on this information, adjustments to the air/fuel ratio are made.
- **Side stand switch** - situated at the top of the sidestand leg. If the sidestand is in the down position, the engine will not run unless the transmission is in neutral.
- **Gear position sensor** - situated in the upper crankcase, behind the gearbox output sprocket cover, on the left hand side of the engine. The gear position sensor provides the ECM with selected gear information. This is used to prevent the engine from starting if the transmission is in gear. The sensor also provides information to the gear position indicator and the neutral lamp in the instruments.
- **Fall detection switch - Daytona 675** - situated below the instrument pack. **Street Triple and Street Triple R** - situated on the relay and fuse box bracket below the fuel tank. The fall detection switch will detect if the motorcycle is on its side and will cut power to the ECM immediately. This prevents the engine from running and the fuel pump from delivering fuel. In the event of a fall, the switch is reset by returning the bike to an upright position and switching the ignition off then back on again.

Sensor Locations



System Actuators

In response to signals received from the sensors, the ECM controls and directs messages to a series of electronic and electro-mechanical actuators. The function and location of the actuators is given below.


- **Throttle stepper motor** - situated between cylinders two and three of the throttle bodies. The throttle stepper actuates a cam/lever which causes variations in the closed throttle position. Although used primarily to ensure target idle speed is maintained, it also increases throttle opening when the engine is cold.
- **Canister purge valve (California models only)** - situated in the vapour return line between the carbon canister and the throttle bodies. The purge valve controls the return of vapour which has been stored in the carbon canister during the period when the engine is switched off. The valve is 'pulsed' by the ECM to give control over the rate at which the canister is purged.
- **Injectors** - located on the throttle body. The engine is fitted with three injectors. The spray pattern of the injectors is fixed but the length of time each injector can remain open is variable according to operating conditions. The duration of each injection is calculated by the ECM using data received from the various sensors in the system.
- **Ignition coils** - plug-top coils are located in the cam cover. There are three coils fitted, one for each spark plug. The ECM controls the point at which the coils are switched on and off. In calculating the switch-on time, the ECM allows sufficient time for the coils to charge to a level where a spark can be produced. The coils are switched off at the point of ignition, the timing of which is optimised for good engine performance.
- **EMS main relay - Daytona 675** - situated forward of the fuse box. **Street Triple and Street Triple R** - situated on the relay and fuse box bracket below the fuel tank. When the ignition is switched on, the EMS main relay is powered up to provide a stable voltage supply for the ECM. When the ignition is turned off, the ECM carries out a power down sequence during which the EMS main relay remains powered by the ECM for 1 minute. The ECM power down sequence includes: writing the adaption data to ECM memory and referencing the position of the throttle stepper motor.
- **Fuel pump** - located inside the fuel tank. The electric pump delivers fuel into the fuel system, via a pressure regulator, at a constant 3 bar pressure. The pump is run continuously when the engine is operating and is also run briefly when the ignition is first switched on to ensure that 3 bar is available to the system as soon as the engine is cranked. Fuel pressure is controlled by a regulator also situated inside the fuel tank.
- **Cooling fan** - located behind the radiator. The ECM controls switching on and off of the cooling fan in response to a signal received from the coolant temperature sensor. When the coolant temperature rises to a level where the cooling effect of natural airflow is insufficient, the cooling fan is turned on by the ECM. When the coolant temperature falls sufficiently, the ECM turns the cooling fan off. The fan only becomes operational when the engine is running. It will not operate at any other time.
- **Secondary air injection solenoid** - located forward of the airbox, on the left hand side of the air intake. The secondary air injection solenoid controls airflow through the secondary air injection system.
- **Intake air flap - Daytona 675 only** - located in the air intake, between the headlamps. The purpose of the intake air flap is to improve low down power delivery. The intake air flap is closed up to 4500 rpm and 12 degrees of throttle, above which it opens.
- **Exhaust butterfly valve - Daytona 675 only** - located in the exhaust headers downstream of the Lambda sensor. The purpose of the exhaust valve is to improve low down power delivery. At idle, the exhaust valve is 30% open, rising to approximately 50% open at 4500 rpm, and fully open at 7000 rpm and above. The profile that the exhaust valve follows has been designed to give no reduction of torque at full throttle.

Note:

- In this system, the starter lockout system (clutch switch, gear position sensor, sidestand switch) all operate through the engine management ECM.

Fuel System/Engine Management

Actuator Locations



Engine Management Circuit Diagram - Daytona 675 - up to VIN 300525 - without the Fuel Pump Relay


Key To Wiring Circuit Diagram

Key	Item Description
1	Engine Control Module
2	Diagnostic Connector
3	Instrument Assembly
4	Vehicle Speed Sensor
5	Clutch Switch
6	Starter Relay
7	Sidestand Switch
8	Gear Position Sensor
9	Lambda Sensor
10	Barometric Pressure Sensor
11	Intake Air Temperature Sensor
12	MAP Sensor
13	Coolant Temperature Sensor
14	Fall Detection Switch
15	Throttle Position Sensor
16	Exhaust Butterfly Valve Actuator
17	Low Fuel Sensor
18	Idle Speed Control Stepper Motor
19	Cooling Fan
20	Cooling Fan Relay
21	Fuse Box (fuse 5)
22	Intake Air Flap Solenoid
23	Ignition Coils
24	Secondary Air Injection Solenoid
25	Engine Stop Switch
26	Fuel Pump
27	Heated Lambda Sensor
28	Purge Valve
29	Fuel Injectors
30	Crankshaft Position Sensor
31	Engine Management System (EMS) Main Relay

Key To Wiring Colour Codes

Code	Wiring Colour
B	Black
U	Blue
N	Brown
G	Green
S	Slate/Grey
O	Orange
K	Pink
R	Red
P	Purple
W	White
Y	Yellow
LG	Light Green
LU	Light Blue


ECM Connector Pin Numbering



The above illustration shows the pin numbering system used in the engine management circuit diagram.

The black connector's pins are prefixed A and the grey connector's pins B. As viewed from the mating face with the ECM (as per the illustration), pins are numbered from right to left with number one in the top right corner.

Engine Management Circuit Diagram - Daytona 675 - up to VIN 300525 - without the Fuel Pump Relay



Fuel Pump Circuit Diagram - Daytona 675 - from VIN 300526 to VIN 323544 - with the Fuel Pump Relay


Key To Wiring Circuit Diagram

Key	Item Description
1	Fuel Pump Relay
2	Secondary Air Injection (SAI) Solenoid
3	Secondary Air Injection (SAI) Connector (Sub harness)
4	Secondary Air Injection (SAI) Connector (Main harness)
5	Secondary Air Injection (SAI) In-line Connector (Sub harness)
6	Fuel Pump
7	Fuel Pump Connector (Main harness)
8	Fuel Pump In-line Connector (Sub harness)
9	Engine Earth
10	Engine Control Module
11	Engine Management System (EMS) Main Relay
12	Engine Stop Switch

Key To Wiring Colour Codes

Code	Wiring Colour
B	Black
U	Blue
N	Brown
G	Green
S	Slate/Grey
O	Orange
K	Pink
R	Red
P	Purple
W	White
Y	Yellow
LG	Light Green
LU	Light Blue


ECM Connector Pin Numbering



The above illustration shows the pin numbering system used in the engine management circuit diagram.

The black connector's pins are prefixed A and the grey connector's pins B. As viewed from the mating face with the ECM (as per the illustration), pins are numbered from right to left with number one in the top right corner.

Fuel Pump Circuit Diagram - Daytona 675 - from VIN 300526 to VIN 323544 - with the Fuel Pump Relay



Circuit Diagram - Engine Management System - Daytona 675 - from VIN 323545 to VIN 381274


Key To Wiring Circuit Diagram

Key	Item Description
1	Engine Control Module
2	Diagnostic Connector
3	Instrument Assembly
4	Vehicle Speed Sensor
5	Clutch Switch
6	Starter Relay
7	Sidestand Switch
8	Gear Position Sensor
9	Lambda Sensor
10	Barometric Pressure Sensor
11	Intake Air Temperature Sensor
12	MAP Sensor
13	Coolant Temperature Sensor
14	Fall Detection Switch
15	Throttle Position Sensor
16	Exhaust Butterfly Valve Actuator
17	Low Fuel Sensor
18	Idle Speed Control Stepper Motor
19	Cooling Fan
20	Cooling Fan Relay
21	Fuse Box (fuse 5)
22	Intake Air Flap Solenoid
23	Ignition Coils
24	Secondary Air Injection Solenoid
25	Fuel Pump
26	Heated Lambda Sensor
27	Purge Valve
28	Fuel Injectors
29	Crankshaft Position Sensor
30	Engine Management System (EMS) Main Relay
31	Fuel Pump Relay

Key To Wiring Colour Codes

Code	Wiring Colour
B	Black
U	Blue
N	Brown
G	Green
S	Slate/Grey
O	Orange
K	Pink
R	Red
P	Purple
W	White
Y	Yellow
LG	Light Green
LU	Light Blue


ECM Connector Pin Numbering



The above illustration shows the pin numbering system used in the engine management circuit diagram.

The black connector's pins are prefixed A and the grey connector's pins B. As viewed from the mating face with the ECM (as per the illustration), pins are numbered from right to left with number one in the top right corner.

Circuit Diagram - Engine Management System - Daytona 675 - from VIN 323545 to VIN 381274



Circuit Diagram - Engine Management System - Daytona 675 - from VIN 381275


Key To Wiring Circuit Diagram

Key	Item Description
1	Engine Control Module
2	Diagnostic Connector
3	Instrument Assembly
4	Vehicle Speed Sensor
5	Clutch Switch
6	Starter Relay
7	Sidestand Switch
8	Gear Position Sensor
9	Lambda Sensor
10	Barometric Pressure Sensor
11	Intake Air Temperature Sensor
12	MAP Sensor
13	Coolant Temperature Sensor
14	Fall Detection Switch
15	Throttle Position Sensor
16	Accessory quickshifter
17	Exhaust Butterfly Valve Actuator
18	Low Fuel Sensor
19	Idle Speed Control Stepper Motor
20	Cooling Fan
21	Cooling Fan Relay
22	Fuse Box (fuse 5)
23	Intake Air Flap Solenoid
24	Ignition Coils
25	Secondary Air Injection Solenoid
26	Fuel Pump
27	Heated Lambda Sensor
28	Purge Valve
29	Fuel Injectors
30	Crankshaft Position Sensor
31	Engine Management System (EMS) Main Relay
32	Fuel Pump Relay

Key To Wiring Colour Codes

Code	Wiring Colour
B	Black
U	Blue
N	Brown
G	Green
S	Slate/Grey
O	Orange
K	Pink
R	Red
P	Purple
W	White
Y	Yellow
LG	Light Green
LU	Light Blue

ECM Connector Pin Numbering



The above illustration shows the pin numbering system used in the engine management circuit diagram.

The black connector's pins are prefixed A and the grey connector's pins B. As viewed from the mating face with the ECM (as per the illustration), pins are numbered from right to left with number one in the top right corner.

Engine Management Circuit Diagram - Street Triple and Street Triple R


Key To Wiring Circuit Diagram

Key	Item Description
1	Engine Management System (EMS) Main Relay
2	Crankshaft Position Sensor
3	Fuel Injector - cylinder 1
4	Fuel Injector - cylinder 2
5	Fuel Injector - cylinder 3
6	Purge Valve
7	Fuse Box (fuse 5)
8	Cooling Fan Relay
9	Idle Speed Control Stepper Motor
10	Cooling Fan
11	Heated Lambda Sensor
12	Secondary Air Injection Solenoid
13	Ignition Coil - cylinder 1
14	Ignition Coil - cylinder 2
15	Ignition Coil - cylinder 3
16	Low Fuel Sensor
17	Fuel Pump Relay
18	Fuel Pump
19	Lambda Sensor
20	Coolant Temperature Sensor
21	Engine Subharness Connector
22	MAP Sensor
23	Gear Position Sensor
24	Quickshifter (Street Triple R only)
25	Intake Air Temperature Sensor
26	Barometric Pressure Sensor
27	Throttle Position Sensor
28	Fall Detection Switch
29	Sidestand Switch
30	Starter Relay
31	Clutch Switch
32	Vehicle Speed Sensor
33	Instrument Assembly
34	Alarm
35	Diagnostic Connector
36	Engine Control Module

Key To Wiring Colour Codes

Code	Wiring Colour
B	Black
U	Blue
N	Brown
G	Green
S	Slate/Grey
O	Orange
K	Pink
R	Red
P	Purple
W	White
Y	Yellow
LG	Light Green
LU	Light Blue

ECM Connector Pin Numbering



The above illustration shows the pin numbering system used in the engine management circuit diagram.

The black connector's pins are prefixed A and the grey connector's pins B. As viewed from the mating face with the ECM (as per the illustration), pins are numbered from right to left with number one in the top right corner.

System Diagnostics

The engine management system has an on-board diagnostics feature which allows service technicians to retrieve stored data from the ECM using the Triumph diagnostic software. **Full details of the Triumph diagnostic software operation and how to interpret the results are given in the Triumph Diagnostic Tool User Guide.**

The software is connected, via an interface cable, to the motorcycle using a dedicated diagnostic plug situated beneath the seats. By using a dedicated plug, no electrical connectors associated with the system are disturbed, reducing potential connector damage.

The software allows the user to retrieve data associated with the system sensors and actuators, test various component functions, read build data and make minor adjustments to the set-up of the system. The data and tests available are described on the following pages.

On-board Fault Detection System

The on-board diagnostic system has two stages to fault detection. When a fault is detected, the DSM (Diagnostic Status Manager) raises a flag to indicate that a fault is present and increments a counter. The counter checks the number of instances that the fault is noted. For example, if there is a fault in the crankshaft position sensor, the counter will increment its count each time the crankshaft turns through 360°, provided the fault is still present.

When the count begins, the fault is detected but not confirmed. If the fault continues to be detected and the count reaches a pre-determined threshold, the fault becomes confirmed. If the fault is an emissions related fault or a serious malfunction affecting engine performance, a DTC (Diagnostic Trouble Code) and freeze-frame data will be logged in the ECM's memory and the MIL (Malfunction Indicator Lamp) on the motorcycle instrument panel is illuminated. Once a fault is confirmed, the number of warm-up cycles made by the engine is counted. If the fault clears, the warm-up cycle counter will extinguish the MIL (Malfunction Indicator Lamp) at a pre determined count, and erase the DTC and freeze frame data from the ECM memory at another (higher) count.

A single warm-up cycle is deemed to have taken place when the following criteria have been met:

- The coolant temperature must be raised to 72° C or more.
- The coolant temperature must have risen by 23° C or more from its start temperature, when 72° C is reached.
- A controlled power-down sequence must take place.

Note:


- When a fault has been rectified, the MIL will remain illuminated until sufficient non-fault warm-up cycles have taken place to turn it off. The MIL will be immediately extinguished if, after first rectifying the fault, the DTC (diagnostic trouble code) that caused the MIL illumination is erased from the ECM memory using the Triumph diagnostic software.

Note:

- In most cases, when a fault is detected, the engine management system will revert to a 'limp-home' mode. In this mode, the engine will still function though the performance and fuel economy may be marginally affected. In some cases, the rider may not notice any appreciable difference from normal operation.

Diagnostic Tool Connection

1. To connect the Triumph diagnostic interface to the motorcycle, Remove the rider's seat (see page 16-17) and release the diagnostic connector from its locating tang.
2. Plug the diagnostic interface directly in to the diagnostic connector.



1. Diagnostic connector (Daytona 675 shown)

2. Diagnostic interface

3. When the diagnostic session is completed, disconnect the Triumph diagnostic interface.
4. Refit the diagnostic connector to its locating tang and refit the rider's seat (see page 16-17).

Triumph Diagnostic Software

Described on the following pages is the range of information which can be retrieved from the ECM's memory and the adjustments which can be performed using the Triumph diagnostic software.

The tables indicate which tests are performed by the on-board system and what information can be retrieved by the Triumph diagnostic software.

Note:

- Full details of how to operate the software and how to interpret the data can be found in the **Triumph Diagnostic Tool User Guide**, which can be downloaded by authorised Triumph dealers from www.triumphonline.net.

Build Data

The **Build Data** screen will display the following information:

- Motorcycle model;
- Vehicle Identification Number (VIN);
- ECM type;
- ECM ID;
- ECM serial number;
- Tune number;
- Date of last tune download;
- Total tune downloads since manufacture;
- The lock status of the ECM (ECM Locked, Unlocked or Not Applicable).

Fuel System/Engine Management

Current Data

The data available under Current Data is:

Function Examined	Result Reported (Scale)
Fuel system status 1	open or closed loop operation
Calculated load value	%
Engine coolant temperature	°C
Short term fuel trim - Bank 1	%
Intake manifold absolute pressure	mm/hg
Engine speed	RPM
Vehicle speed	km/h
Ignition timing advance - cylinder 1	degrees
Intake air temperature	°C
Absolute throttle position	%
Bank 1 - oxygen sensor 1	Volts
Bank 1 - oxygen sensor 1 - short term fuel trim	%

Sensor Data

When using this function it is possible to check the status of various sensors and actuators.

The data sets are divided into seven groups - Sensor Voltages; Sensor Readings; Injector Data; Ignition Data; Idle Speed, Throttle Data and Inputs and Adaption Status. Each of these screens is described on the following pages.

Sensor Voltages

The data available under sensor voltages is:

Item Checked	Result Unit
Battery voltage	Volts
Voltage from ignition switch to ECU	Volts
Air temperature sensor voltage	Volts
Coolant temperature sensor voltage	Volts
Atmospheric pressure sensor voltage	Volts
Manifold absolute pressure sensor 1 voltage	Volts
Manifold absolute pressure sensor 2 voltage	Volts
Throttle position sensor voltage	Volts
Fuel level sensor voltage	Volts
Oxygen sensor output 1 voltage	Volts
Exhaust butterfly valve sensor voltage†	Volts

† Applies to models fitted with an exhaust butterfly valve only. All other models will show **Not Applicable** in this field.

Sensor Readings

The data available under sensor readings is:

Item Checked	Result Unit
Air temperature	°C
Coolant temperature	°C
Atmospheric (barometric) pressure	mmHg
Short term fuel trim†	%
Manifold absolute pressure (one reading per cylinder)	mmHg
Low fuel light	on/off
Oxygen sensor 1 short term fuel trim	%
Oxygen sensor 1 heater status	on/off
Exhaust butterfly valve sensor voltage†	%

† Applies to models fitted with an exhaust butterfly valve only. All other models will show **Not Applicable** in this field.

Fuel System/Engine Management

Injector Data

The data available under injector data is:

Item Checked	Result Unit
Injector 1 pulse time	milliseconds
Injector 2 pulse time	milliseconds
Injector 3 pulse time	milliseconds

Ignition Data

The data available under ignition data is:

Item Checked	Result Unit
Ignition timing cyl 1	degrees BTDC
Ignition timing cyl 2	degrees BTDC
Ignition timing cyl 3	degrees BTDC
Coil dwell time	milliseconds

Idle Speed and Throttle Data

The data available under idle speed and throttle data is:

Item Checked	Result Unit
Engine speed	RPM
Idle reference speed	RPM
Idle speed control current steps	numeric
Idle speed control target steps	numeric
Throttle position	% open
Secondary air injection status†	SAI on/off

† Applies to models fitted with a Secondary air injection only. All other models will show **Not Applicable** in this field.

Sensor Data

When using this function it is possible to check the status of various sensors and actuators.

The data sets are divided into seven groups - Sensor Voltages; Sensor Readings; Injector Data; Ignition Data; Idle Speed, Throttle Data and Inputs and Adaption Status. Each of these screens is described on the following pages.

Sensor Voltages

The data available under sensor voltages is:

Item Checked	Result Unit
Battery voltage	Volts
Voltage from ignition switch to ECU	Volts
Air temperature sensor voltage	Volts
Coolant temperature sensor voltage	Volts
Atmospheric pressure sensor voltage	Volts
Manifold absolute pressure sensor 1 voltage	Volts
Manifold absolute pressure sensor 2 voltage	Volts
Throttle position sensor voltage	Volts
Fuel level sensor voltage	Volts
Oxygen sensor output 1 voltage	Volts
Exhaust butterfly valve sensor voltage†	Volts

† Applies to models fitted with an exhaust butterfly valve only. All other models will show **Not Applicable** in this field.

Sensor Readings

The data available under sensor readings is:

Item Checked	Result Unit
Air temperature	°C
Coolant temperature	°C
Atmospheric (barometric) pressure	mmHg
Short term fuel trim†	%
Manifold absolute pressure (one reading per cylinder)	mmHg
Low fuel light	on/off
Oxygen sensor 1 short term fuel trim	%
Oxygen sensor 1 heater status	on/off
Exhaust butterfly valve sensor voltage†	%

† Applies to models fitted with an exhaust butterfly valve only. All other models will show **Not Applicable** in this field.

Fuel System/Engine Management

Injector Data

The data available under injector data is:

Item Checked	Result Unit
Injector 1 pulse time	milliseconds
Injector 2 pulse time	milliseconds
Injector 3 pulse time	milliseconds

Ignition Data

The data available under ignition data is:

Item Checked	Result Unit
Ignition timing cyl 1	degrees BTDC
Ignition timing cyl 2	degrees BTDC
Ignition timing cyl 3	degrees BTDC
Coil dwell time	milliseconds

Idle Speed and Throttle Data

The data available under idle speed and throttle data is:

Item Checked	Result Unit
Engine speed	RPM
Idle reference speed	RPM
Idle speed control current steps	numeric
Idle speed control target steps	numeric
Throttle position	% open
Secondary air injection status†	SAI on/off

† Applies to models fitted with a Secondary air injection only. All other models will show **Not Applicable** in this field.

Fuel System/Engine Management

Inputs

The data available under inputs is:

Item Checked	Result Unit
EMS Main relay status	relay on/off
Fuel pump relay status	on/off
Starter relay status	starter on/off
Starter switch status	switch on/off
Side stand status	up/down
Fall detection switch status	normal/over
Clutch switch status	release/grip
Neutral switch status	gear/neutral
Gear position status	numeric value or neutral
Vehicle speed	km/h
Malfunction indicator light status	MIL on/off
Cooling fan status	fan on/off
Air flap solenoid status†	off/on
Calculated load	%
Purge valve duty cycle‡	%

† Applies to models fitted with an intake air flap only. All other models will show **Not Applicable** in this field.

‡ Applies to models fitted with a purge valve only. All other models will show **Not Applicable** in this field.

Adaption Status

Because the fuel system is adaptive, the engine management system is able to automatically adjust to new working conditions, such as changes in altitude, component wear, air leaks etc. This screen displays information on the adaption status of the vehicle which will show if it has adapted or not.

Function Examined	Report Method
Closed Throttle Position Adapted	adapted/not adapted
Idle speed control adaption status	%
Oxygen sensor 1 adaption range (off idle)	%
Oxygen sensor 1 adaption range (idle)	%
Oxygen sensor 1 adaption status (off idle)	%
Oxygen sensor 1 adaption status (idle)	%

Function Tests

The system allows the diagnostic software to perform a series of function tests on various actuators in the engine management system. In some cases it is necessary to make a visual observation of a component and in others, if faults are present, DTCs will be logged.

The function tests available are:

Function Examined	Report Method
Instrument Panel	Observe instrument panel, refer to service manual
Idle Air Control Stepper Motor†	Observe throttle position/Stored fault code*
Purge Valve†	Listen for valve operation/Stored fault code*
Fuel Pump - Priming	Listen for fuel pump operation/Stored fault code*
Fuel Pump - Continuous Operation	Fuel pressure test/Listen for fuel pump operation/Stored fault code*
Cooling Fan Control†	Observe the cooling fan/Stored fault code*
Second Throttle Stepper Motor†	Observe second throttle position/Stored fault code*
Secondary Air Injection†	Listen for valve operation/Stored fault code*
Intake Air Flap Solenoid†	Listen for intake air flap solenoid operation
Exhaust Butterfly Valve Actuator†	Listen or observe for exhaust butterfly valve actuator operation/Stored fault code*

* If a fault is detected.

† Test will only be displayed if the component is fitted.

Instrument Panel Function Test

On the diagnostic software navigate to and select the 'FUNCTION TESTS' option.

Click the start button and observe the instruments for the following:

- tachometer needle move to 7,500 rpm;
- the neutral indicator and fuel warning with the malfunction indicator light (MIL) lights alternate on and off;
- coolant temperature increments up to maximum temperature;
- coolant warning light illuminates when coolant temperature gauge is at maximum;
- end of test. Instruments return to normal operation.

Adjust Tune

Using the Triumph diagnostic software, it is possible to:

- reset the adaptations;
- balance the throttle bodies.

Further functions are provided to allow correct replacement and adjustment of the:

- throttle position sensor;
- idle speed control stepper motor.

These functions are needed as, after replacement of the parts concerned, adjustments have to be made to specific Voltage settings, with the throttles set in a specific position.

To reset adaptations, see page 10-115.

To replace and adjust the throttle position sensor, see page 10-110.

To replace and adjust the ISC stepper motor, see page 10-112.

To balance the throttles, see page 10-109.

Freeze-frame Data

Freeze frame data is stored at the time a DTC is recorded (confirmed) by the ECM. If multiple DTCs are recorded, the freeze-frame data which is stored will relate to the first recorded DTC only.

By calling up freeze frame data associated with the first recorded DTC, the technician can check the engine condition at the time the fault occurred. The data available is:

Function Examined	Result Reported (Scale)
DTC	Diagnostic Trouble Code (DTC) number
Fuel system status 1	open or closed loop operation
Calculated load	%
Coolant temperature	°C
Short term fuel trim - bank 1	%
Intake manifold absolute pressure	mm/hg
Engine speed	RPM
Vehicle speed	km/h
Ignition advance	degrees
Intake air temperature	°C
Throttle position	%
Oxygen sensor 1 output Voltage	Volts
Oxygen sensor 1 short term fuel trim	%

Fuel System/Engine Management

Diagnostic Trouble Codes

Diagnostic trouble codes (DTCs) are logged in the ECM memory when there is a confirmed fault in the system.

The codes are reported to the Triumph diagnostic software as a four digit code.

As mentioned earlier, when the system detects a fault, it begins to count the number of times the fault occurs before illuminating the MIL and storing a fault code.

Similarly, if a fault clears, the ECM also records this fact and will turn off the MIL when sufficient no-fault warm-up cycles have taken place. Any fault codes will remain in the ECM memory until the required number of no-fault warm-up cycles have taken place. The number of warm-up cycles required to extinguish the MIL will always be less than the number required to remove a DTC from the ECM memory. DTCs can be removed at any time using the Triumph diagnostic software.

The system will log the diagnostic trouble codes listed below/over:

Diagnostic Trouble Code (DTC)	Fault Description	Number of no-fault cycles before turning off MIL	Number of no-fault cycles before DTC is erased	MIL illuminated when fault is logged
P0201	Injector 1 circuit malfunction	3	40	Yes
P0202	Injector 2 circuit malfunction	3	40	Yes
P0203	Injector 3 circuit malfunction	3	40	Yes
P1201	Injector 1 open circuit/short to ground	3	40	Yes
P1202	Injector 2 open circuit/short to ground	3	40	Yes
P1203	Injector 3 open circuit/short to ground	3	40	Yes
P0351	Ignition coil 1 circuit malfunction	3	40	Yes
P0352	Ignition coil 2 circuit malfunction	3	40	Yes
P0353	Ignition coil 3 circuit malfunction	3	40	Yes
P0335	Crankshaft sensor circuit malfunction	3	40	Yes
P0032	Oxygen sensor heater short circuit to battery	3	40	Yes
P0031	Oxygen sensor heater open circuit/short to ground	3	40	Yes
P0030	Oxygen sensor heater circuit malfunction	3	40	Yes
P0136	Oxygen sensor circuit malfunction	3	40	Yes
P0122	Throttle position sensor low input	3	40	Yes
P0123	Throttle position sensor high input	3	40	Yes
P0107	Manifold absolute pressure sensor low voltage	3	40	Yes
P0108	Manifold absolute pressure sensor high voltage	3	40	Yes
P1105	Manifold absolute pressure sensor pipe malfunction	3	40	Yes
P1107	Ambient air pressure sensor circuit low voltage	3	40	Yes
P1108	Ambient air pressure sensor circuit high voltage	3	40	Yes
P0112	Intake air temperature too high	3	40	Yes
P0113	Intake air temperature too low	3	40	Yes
P0117	Engine coolant temperature too high	3	40	Yes
P0118	Engine coolant temperature too low	3	40	Yes

Fuel System/Engine Management

Diagnostic Trouble Code (DTC)	Fault Description	Number of no-fault cycles before turning off MIL	Number of no-fault cycles before DTC is erased	MIL illuminated when fault is logged
P0500	Vehicle speed sensor malfunction	3	40	Yes
P1552	Cooling fan short circuit/open circuit	3	40	Yes
P1553	Cooling fan short to battery voltage/over temperature	3	40	Yes
P1628	Fuel pump short circuit to ground or open circuit	3	40	Yes
P1231	Fuel pump relay short circuit to ground or open circuit	3	40	Yes
P1232	fuel pump relay short circuit to battery	3	40	Yes
P1629	Fuel pump short circuit to battery	3	40	Yes
P0444	Purge valve system short circuit to ground or open circuit	3	40	Yes
P0445	Purge valve system short circuit to battery	3	40	Yes
P0617	Starter relay short circuit to battery	3	40	Yes
P0616	Starter relay short circuit to ground or open circuit	3	40	Yes
P0414	Secondary air injection system short circuit to battery	3	40	Yes
P0413	Secondary air injection system short circuit to ground or open circuit	3	40	Yes
P0505	Idle speed control system malfunction	3	40	Yes
P1631	Fall detection sensor circuit low voltage	3	40	Yes
P1632	Fall detection sensor circuit high voltage	3	40	Yes
P0560	System voltage - battery circuit malfunction	3	40	Yes
P1500	Vehicle speed output circuit malfunction*	0	40	No
P0654	Tachometer circuit malfunction*	0	40	No
P1115	Coolant temperature gauge circuit malfunction*	0	40	No
P0460	Fuel level sensor circuit malfunction*	0	40	No
P0705	Gear position sensor circuit malfunction*	0	40	No
P1610	Low fuel output circuit malfunction*	0	40	No
P0630	EEPROM fault*	0	40	No
P1690	CAN communication fault	N/A	40	No
P1078	Exhaust control valve actuator position sensor circuit low voltage (short to ground) (Daytona 675 only)	3	40	Yes
P1079	Exhaust control valve actuator position sensor circuit high voltage (short to Vcc) (Daytona 675 only)	3	40	Yes
P0078	Exhaust control valve actuator circuit malfunction (Daytona 675 only)	3	40	Yes
P1080	Exhaust control valve actuator mechanism malfunction (Daytona 675 only)	3	40	Yes

Fuel System/Engine Management

Diagnostic Trouble Code (DTC)	Fault Description	Number of no-fault cycles before turning off MIL	Number of no-fault cycles before DTC is erased	MIL illuminated when fault is logged
P1670	Intake flap solenoid circuit short to ground or open circuit (Daytona 675 only)	3	40	Yes
P1671	Intake flap solenoid circuit short to Vbatt (Daytona 675 only)	3	40	Yes
P1685	EMS main relay circuit malfunction	3	40	Yes
*-Supported by DTC P1690				
P1659	EMS ignition voltage input malfunction	3	40	Yes
P1698	Sensor supply (Vcc) circuit malfunction	3	40	Yes
P1602	Tunelock	Only if Tunelock is unlocked		Flashing
P1614	ECM or tune ID Incorrect	Only if Instrument ID Matching		Flashing

Electrical Connectors

Before beginning any diagnosis, the following connector related information should be noted:

Note:

- A major cause of hidden electrical faults can be traced to faulty electrical connectors. For example:
- Dirty/corroded terminals.
- Damp terminals.
- Broken or bent cable pins within multi-plugs.

For example, the electronic control module (ECM) relies on the supply of accurate information to enable it to plan the correct fueling and ignition timing. One dirty terminal will cause an excessive voltage drop resulting in an incorrect signal to the ECM.

If, when carrying out fault diagnosis, a fault appears to clear by simply disconnecting and reconnecting an electrical plug, examine each disconnected plug for the following.

Before Disconnection:

- If testing with a voltmeter, the voltage across a connector should be virtually battery volts (unless a resistor is fitted in the circuit). If there is a noticeable change, suspect faulty/dirty connections.

When Disconnecting a Connector:

- Check for a security device that must be released before the connector can be separated. E.G. barb, hook and eye etc.

When Inspecting a Connector:

- Check that the individual pins have not been bent.
- Check for dampness/dirt/corrosion.
- Check cables for security.
- Check cable pin joints for damage.

When Connecting a Connector:

- Ensure there is no dirt around the connector/seal.
- Push together squarely to ensure terminals are not bent or incorrectly located.
- Push the two halves together positively.

Disconnection of ECM connectors

Note:

- Two different coloured and shaped connectors are used in the ECM, which ensures correct connection is always made. The connectors on the ECM are coloured black and grey, and correspond with identical coloured connectors on the main harness.

! Caution


When disconnecting a connector, never pull directly on the wires as this may result in cable and connector damage.

! Caution

Never disconnect the ECM when the ignition switch is in the 'ON' position as this may cause multiple fault codes to be logged in the ECM memory.

Always disconnect an ECM after disconnecting the battery negative (black) lead first.

1. Turn the ignition to the 'OFF' position and wait at least 1 minute for the ECM to complete its power down sequence.
2. Press down on the locking device and gently pull back on the connector to release it from the ECM.



1. Locking device

Note:

- The ECM is located beneath the fuel tank, on the upper section of the airbox.

Reconnection of ECM connectors


Note:

- Two different coloured and shaped connectors are used in the ECM, which ensures correct connection is always made. The connectors on the ECM are coloured black and grey, and correspond with identical coloured connectors on the main harness.



Caution

Damage to the connector pins may result if an attempt to fit the connectors incorrectly is made.



1. ECM (Daytona 675 shown, Street Triple and Street Triple R similar)

- Fit the first connector into its socket and, whilst holding the connector in place, insert it fully into the ECM until the locking device retains it.
- Repeat the above for the second connector.

Further Diagnosis

The tables that follow will, if used correctly, help to pinpoint a fault in the system once a diagnostic trouble code has been stored.


Crankshaft Sensor

Fault Code	Possible cause	Action
P0335	Crankshaft sensor system fault	View & note diagnostic software 'freeze frame' data if available. Ensure sensor is fitted correctly and connector is secure. Disconnect ECM and proceed to pinpoint test 1:

Pinpoint Tests

Test	Result	Action
1 Check terminal and cable integrity: - ECM pin A01 - ECM pin A09	OK	Disconnect sensor and proceed to test 2
	Faulty	Rectify fault, proceed to test 6
2 Check cable for short circuit: - ECM pin A01 to earth - ECM pin A09 to earth	OK	Proceed to test 3
	Short circuit	Locate and rectify wiring fault, proceed to test 6
3 Check cable continuity: - ECM pin A09 to sensor pin 1 - ECM pin A01 to sensor pin 2	OK	Proceed to test 4
	Open circuit	Locate and rectify wiring fault, proceed to test 6
4 Check cable for short circuit: - ECM pin A01 to ECM pin A09	OK	Renew crankshaft sensor, proceed to test 6
	Short circuit	Locate and rectify wiring fault, proceed to test 6
5 Check crank toothed wheel: - Damage to teeth - magnetic debris contamination	OK	Proceed to test 6
	Faulty	Clean / renew toothed wheel, proceed to test 6
6 Reconnect harness, clear fault code and run engine to verify fault cleared	OK	Action complete - quit test
	Fault still present	Contact Triumph service

Circuit Diagram




Idle Speed Control

Fault Code	Possible cause	Action
P0505	ISC stepper motor / wiring fault	View & note diagnostic software 'freeze frame' data if available. View & note diagnostic software 'sensor' data. Ensure sensor connector is secure. Disconnect ECM and proceed to pinpoint test 1:

Pinpoint Tests

Test	Result	Action
1 Check cable and terminal integrity: - ECM pin A20 - ECM pin A21 - ECM pin A22 - ECM pin A23	OK	Proceed to test 2
	Faulty	Rectify fault, proceed to test 7
2 Check resistance value: - ECM pin A20 to ECM pin A21 - ECM pin A22 to ECM pin A23	4Ω to 12Ω	Disconnect stepper motor and proceed to test 3
	Open circuit	Disconnect stepper motor and proceed to test 4
	Short circuit	Disconnect stepper motor and proceed to test 5
3 Check cable for short circuit: - ECM pin A20 to earth - ECM pin A21 to earth - ECM pin A22 to earth - ECM pin A23 to earth	OK	Proceed to test 7
	Short circuit	Locate and rectify wiring fault, proceed to test 7
4 Check cable continuity: - ECM pin A22 to stepper motor pin A - ECM pin A23 to stepper motor pin A1 - ECM pin A20 to stepper motor pin B - ECM pin A21 to stepper motor pin B1	OK	Proceed to test 6
	Open circuit	Locate and rectify wiring fault, proceed to test 7
5 Check cable for short circuit: - ECM pin A22 to ECM pin A23 - ECM pin A20 to ECM pin A21	OK	Proceed to test 6
	Short circuit	Locate and rectify wiring fault, proceed to test 7
6 Check stepper motor resistance: - Motor pin A to motor pin A1 - Motor pin B to motor pin B1	4Ω to 12Ω	Proceed to test 7
	Faulty	Renew stepper motor, proceed to test 7
7 Reconnect harness, clear fault code and run diagnostic software function test to visually verify operation of stepper motor	OK	Action complete - quit test
	Fault still present	Contact Triumph service

Circuit Diagram




Fuel Injectors

Fault Code	Possible cause	Action
P0201/02/03	Injection system fault - injector 1/2/3 - Misfire indicates open circuit - Flooding indicates short circuit	View & note diagnostic software 'freeze frame' data if available. Ensure relevant injector connector is secure. Disconnect ECM and proceed to pinpoint test 1:

Pinpoint Tests

Test	Result	Action
1 Check cable and terminal integrity: - ECM pin A15 - ECM pin A14 - ECM pin A13	OK	Proceed to test 2
	Faulty	Rectify fault, proceed to test 7
2 Check resistance value: - ECM pin A06 to ECM pin A15 (injector 1) - ECM pin A06 to ECM pin A14 (injector 2) - ECM pin A06 to ECM pin A13 (injector 3)	11.0Ω to 12.5Ω	Proceed to test 3
	Open circuit	Disconnect relevant injector and proceed to test 4
	Short circuit	Disconnect relevant injector and proceed to test 5
3 Check cable for short circuit to ground: - ECM pin A15 to earth - ECM pin A14 to earth - ECM pin A13 to earth	OK	Proceed to test 7
	Short circuit	Locate and rectify wiring fault, proceed to test 7
4 Check cable continuity: - ECM pin A06 to relevant injector pin 2 - ECM pin A15 to injector 1 pin 1 - ECM pin A14 to injector 2 pin 1 - ECM pin A13 to injector 3 pin 1	OK	Proceed to test 6
	Open circuit	Locate and rectify wiring fault, proceed to test 7
5 Check cable for short circuit to supply box: - ECM pin A06 to ECM pin A15 (inj 1) - ECM pin A06 to ECM pin A14 (inj 2) - ECM pin A06 to ECM pin A13 (inj 3)	OK	Proceed to test 6
	Short circuit	Locate and rectify wiring fault, proceed to test 7
6 Check relevant injector resistance: - Injector pin 1 to injector pin 2	11.0Ω to 12.5Ω	Proceed to test 7
	Faulty	Renew relevant injector, proceed to test 7
7 Reconnect harness, clear fault code and run engine to verify fault cleared	OK	Action complete - quit test
	Fault still present	Contact Triumph service

Circuit Diagram




Throttle Position Sensor

Fault Code	Possible cause	Action
P0122 P0123	Throttle position sensor low input voltage (short to ground or open circuit) Throttle position sensor high input voltage (short circuit to sensor supply)	View & note diagnostic software 'freeze frame' data if available. View & note diagnostic software 'sensor' data. Ensure sensor connector is secure. Disconnect ECM and proceed to pinpoint test 1:

Pinpoint Tests

Test	Result	Action
1 Check cable and terminal integrity: - ECM pin B01 - ECM pin B20 - ECM pin A10	OK	Disconnect sensor and proceed to test 2
	Faulty	Rectify fault, proceed to test 5
2 Check cable for short circuit: - ECM pin A10 to ground	OK	Proceed to test 3
	Short circuit	Locate and rectify wiring fault, proceed to test 5
3 Check cable continuity: - ECM pin A10 to sensor pin 1 - ECM pin B20 to sensor pin 2 - ECM pin B01 to sensor pin 3	OK	Proceed to test 4
	Open circuit	Locate and rectify wiring fault, proceed to test 5
4 Check cable for short circuit: - ECM pin A10 to ECM pin B01 - ECM pin A10 to ECM pin B20	OK	Renew throttle position sensor, proceed to test 5
	Short circuit	Locate and rectify wiring fault, proceed to test 5
5 Reconnect harness, clear fault code and run engine to verify fault cleared	OK	Action complete - quit test
	Fault still present	Contact Triumph service

Circuit Diagram




Purge Valve

Fault Code	Possible cause	Action
P0444	Open circuit or short circuit to earth	View & note diagnostic software 'sensor' data. Ensure purge valve connector is secure. Disconnect ECM and proceed to pinpoint test 1:
P0445	Short circuit to battery+	Disconnect purge valve and proceed to pinpoint test 5:

Pinpoint Tests

Test	Result	Action
1 Check cable and terminal integrity: - ECM pin B09	OK	Proceed to test 2
	Faulty	Rectify fault, proceed to test 7
2 Check resistance value: - ECM pin A06 to ECM pin B09	24Ω to 28Ω	Disconnect purge valve and proceed to test 3
	Open circuit	Proceed to test 4
	Short circuit	Disconnect purge valve and proceed to test 5
3 Check cable for short circuit: - ECM pin B09 to earth	OK	Disconnect purge valve and proceed to test 7
	Short circuit	Locate and rectify wiring fault, proceed to test 7
4 Check cable continuity: - ECM pin B09 to valve pin 2 - ECM pin A06 to valve pin 1	OK	Proceed to test 6
	Open circuit	Locate and rectify wiring fault, proceed to test 7
5 Check cable for short circuit: - ECM pin A06 to ECM pin B09	OK	Proceed to test 6
	Short circuit	Locate and rectify wiring fault, proceed to test 7
6 Check purge valve resistance: - Valve pin 1 to valve pin 2	24Ω to 28Ω	Proceed to test 7
	Faulty	Renew purge valve, proceed to test 7
7 Reconnect harness, clear fault code and run diagnostic software function test to visually verify operation of purge valve	OK	Action complete - quit test
	Fault still present	Contact Triumph service

Circuit Diagram




Ignition Coils

Fault Code	Possible cause	Action
P0351/52/53	Ignition system fault - ignition coil 1/2/3	View & note diagnostic software 'freeze frame' data if available. Ensure relevant ignition coil connector is secure. Disconnect ECM and proceed to pinpoint test 1:

Pinpoint Tests

Test	Result	Action
1 Check cable and terminal integrity: - ECM pin B17 - ECM pin A18 - ECM pin B18	OK	Proceed to test 2
	Faulty	Rectify fault, proceed to test 7
2 Check resistance value: ECM pin A06 to - ECM pin (ignition coil 1) B17 - ECM pin (ignition coil 2) A18 - ECM pin (ignition coil 3) B18	0.8Ω to 1.2Ω	Proceed to test 3
	Open circuit	Disconnect relevant ignition coil and proceed to test 4
	Short circuit	Disconnect relevant ignition coil and proceed to test 5
3 Check cable for short circuit: - ECM pin B17 to earth - ECM pin A18 to earth - ECM pin B18 to earth	OK	Proceed to test 7
	Short circuit	Locate and rectify wiring fault, proceed to test 7
4 Check cable continuity: EMS main relay pin 5 to any ignition coil pin 2 - ECM pin B17 to ignition coil 1 pin 1 - ECM pin A18 to ignition coil 2 pin 1 - ECM pin B18 to ignition coil 3 pin 1	OK	Proceed to test 6
	Open circuit	Locate and rectify wiring fault, proceed to test 7
5 Check cable for short circuit: ECM pin A06 to - ECM pin (ignition coil 1) B19 - ECM pin (ignition coil 2) A18 - ECM pin (ignition coil 3) B18	OK	Proceed to test 6
	Short circuit	Locate and rectify wiring fault, proceed to test 7
6 Check relevant ignition coil resistance: - Ignition coil pin 1 to ignition coil pin 2	0.8Ω to 1.2Ω	Proceed to test 7
	Faulty	Renew relevant ignition coil, proceed to test 7
7 Reconnect harness, clear fault code and run engine to verify fault cleared	OK	Action complete - quit test
	Fault still present	Contact Triumph service

Circuit Diagram



Coolant Temperature Sensor

Fault Code	Possible cause	Action
P0118	Open circuit, or short circuit to battery+	View & note diagnostic software 'freeze frame' data if available. View & note diagnostic software 'sensor' data. Ensure sensor connector is secure. Disconnect ECM and proceed to pinpoint test 1:
P0117	Short circuit to ground	Disconnect sensor and proceed to test 6:


Pinpoint Tests

Test	Result	Action
1 Check cable and terminal integrity: - ECM pin A29 - ECM pin B20	OK	Proceed to test 2
	Faulty	Rectify fault, proceed to test 7
2 Check resistance value: - ECM pin A29 to ECM pin B20 (Temperature dependent - see below)	OK	Disconnect temp sensor and proceed to test 6
	Open circuit	Disconnect sensor and proceed to test 3
	Short circuit	Disconnect temp sensor and proceed to test 4
3 Check cable continuity: - ECM pin A29 to sensor pin 1 - ECM pin B20 to sensor pin 2	OK	Proceed to test 5
	Open circuit	Locate and rectify wiring fault, proceed to test 7
4 Check cable for short circuit: - ECM pin A29 to ECM pin B20	OK	Proceed to test 5
	Short circuit	Locate and rectify wiring fault, proceed to test 7
5 Check sensor resistance: - Sensor pin 1 to sensor pin 2 (Temperature dependent - see below)	OK	Proceed to test 7
	Faulty	Renew temp sensor, proceed to test 7
6 Check cable for short circuit: - ECM pin A29 to ground	OK	Proceed to test 7
	Short circuit	Locate and rectify wiring fault, proceed to test 7
7 Reconnect harness, clear fault code and run engine to verify fault cleared	OK	Action complete - quit test
	Fault still present	Contact Triumph service

Circuit Diagram

Resistance data under typical conditions:

Warm engine:	200 to 400Ω
Cold engine:	
20°C ambient	2.35 to 2.65KΩ
-10°C ambient	8.50 to 10.25KΩ



Intake Air Temperature Sensor

Fault Code	Possible cause	Action
P0113	Open circuit, or short circuit to battery+	View & note diagnostic software 'freeze frame' data if available. View & note diagnostic software 'sensor' data. Ensure sensor connector is secure. Disconnect ECM and proceed to pinpoint test 1:
P0112	Short circuit to ground	Disconnect sensor and proceed to pinpoint test 6:

Pinpoint Tests


Test	Result	Action
1 Check cable and terminal integrity: - ECM pin A11 - ECM pin B20	OK	Proceed to test 2
	Faulty	Rectify fault, proceed to test 7
2 Check resistance value: - ECM pin A11 to ECM pin B20 (Temperature dependent - see below)	OK	Disconnect temp sensor and proceed to test 6
	Open circuit	Disconnect temp sensor and proceed to test 3
	Short circuit	Disconnect temp sensor and proceed to test 4
3 Check cable continuity: - ECM pin A11 to sensor pin 1 - ECM pin B20 to sensor pin 2	OK	Proceed to test 5
	Open circuit	Locate and rectify wiring fault, proceed to test 7
4 Check cable for short circuit: - ECM pin A11 to ECM pin B20	OK	Proceed to test 5
	Short circuit	Locate and rectify wiring fault, proceed to test 7
5 Check sensor resistance: - Sensor pin 1 to sensor pin 2 (Temperature dependent - see below)	OK	Proceed to test 7
	Faulty	Renew temp sensor, proceed to test 7
6 Check cable for short circuit: - ECM pin A11 to ground	OK	Proceed to test 7
	Short circuit	Locate and rectify wiring fault, proceed to test 7
7 Reconnect harness, clear fault code and run engine to verify fault cleared	OK	Action complete - quit test
	Fault still present	Contact Triumph service

Circuit Diagram

If engine is warm, remove sensor and allow time to cool to ambient prior to test.

Resistance data:

Ambient temp	Resistance value
80°C	200 to 400Ω
20°C	2.35 to 2.65KΩ
-10°C	8.50 to 10.25KΩ



Fuel System/Engine Management


System Voltage

Fault Code	Possible cause	Action
P0560	Bike voltage system fault	View & note diagnostic software 'sensor' data. Ensure voltage across battery is acceptable, note voltage. Disconnect ECM and proceed to pinpoint test 1:

Pinpoint Tests

Test	Result	Action
1 Check cable and terminal integrity: - ECM pin A06	OK	Proceed to test 2
	Faulty	Rectify fault, proceed to test 3
2 With Ignition 'ON', check voltage at: - ECM pin A06	Same as 'across battery' voltage	Proceed to test 3
	Less than 'across battery' voltage	Locate and rectify wiring fault, proceed to test 3
3 Reconnect harness, clear fault code and run engine to verify fault cleared	OK	Action complete - quit test
	Fault still present	Contact Triumph service

Circuit Diagram




Cooling Fan Relay

Fault Code	Possible cause	Action
P1552	Fan relay open circuit, or short circuit to ground	View & note diagnostic software 'sensor' data. Ensure fan relay connector is secure. Disconnect ECM and proceed to pinpoint test 1:
P1553	Short circuit to battery+	Disconnect fan relay and proceed to pinpoint test 4:

Pinpoint Tests

Test	Result	Action
1 Check cable and terminal integrity: - ECM pin B30	OK	Disconnect fan relay and proceed to test 2
	Faulty	Rectify fault, proceed to test 5
2 Check cable for short circuit: - ECM pin B30 to ground	OK	Proceed to test 3
	Short circuit	Locate and rectify wiring fault, proceed to test 5
3 Check cable continuity: - Fan relay pin 2 to ECM pin B30 - Fan relay pin 1 to EMS main relay pin 5	OK	Proceed to test 4
	Open circuit	Locate and rectify wiring fault, proceed to test 5
4 Check cable for short circuit: - ECM pin B30 to ECM pin A06	OK	Proceed to test 5
	Short circuit	Locate and rectify wiring fault, proceed to test 5
5 Reconnect harness, clear fault code and run diagnostic software function test to visually verify operation of cooling fan	OK	Action complete - quit test
	Fault still present	Contact Triumph service

Circuit Diagram




Lambda Sensor

Fault Code	Possible cause	Action
P0130	Lambda sensor circuit fault	View & note 'freeze frame' data if available. View & note 'sensor' data. Ensure sensor connector is secure. Disconnect ECM and proceed to pinpoint test 1:

Pinpoint Tests

Test	Result	Action
1 Check cable and terminal integrity: - ECM pin A26 - ECM pin B20	OK	Disconnect Lambda sensor and proceed to test 2
	Faulty	Rectify fault, proceed to test 4
2 Check cable for short circuit: - ECM pin A26 to ECM pin B20 - ECM pin A26 to ECM pin A06	OK	Proceed to test 3
	Short circuit	Locate and rectify wiring fault, proceed to test 4
3 Check cable continuity: - ECM pin A26 to sensor pin 2 - ECM pin B20 to sensor pin 1	OK	Proceed to test 4
	Open circuit	Locate and rectify wiring fault, proceed to test 4
4 Reconnect harness, clear fault code and run engine. Check adaptation status	OK	Action complete - quit test
	Fault still present	Contact Triumph service

Circuit Diagram




Lambda Sensor Heater

Fault Code	Possible cause	Action
P0031	Lambda sensor heater circuit short circuit to ground or open circuit	View & note 'freeze frame' data if available. View & note 'sensor' data. Ensure sensor connector is secure. Disconnect ECM and proceed to pinpoint test 1:
P0032	Lambda sensor heater circuit, short circuit to battery	Disconnect lambda sensor and proceed to pinpoint test 4:

Pinpoint Tests

Test	Result	Action
1 Check cable and terminal integrity: - ECM pin B14	OK	Disconnect Lambda sensor and proceed to test 2
	Faulty	Rectify fault, proceed to test 5
2 Check cable for short circuit: - ECM pin B14 to ground	OK	Proceed to test 3
	Short circuit	Locate and rectify wiring fault, proceed to test 5
3 Check cable continuity: - ECM pin B14 to sensor pin 4 - ECM pin A06 to sensor pin 3	OK	Proceed to test 5
	Open circuit	Locate and rectify wiring fault, proceed to test 5
4 Check cable for short circuit: - ECM pin B14 to ECM pin A06	OK	Renew Lambda sensor and proceed to test 5
	Short circuit	Locate and rectify wiring fault, proceed to test 5
5 Reconnect harness, clear fault code and run engine. Check adaption status	OK	Action complete, quit test
	Fault still present	Contact Triumph service

Circuit Diagram



EEPROM Error

Fault Code	Possible cause	Action
P0603	EEPROM error	View & note 'freeze frame' data if available. No tests available - contact Triumph service.


Fall Detection Switch

Fault Code	Possible cause	Action
P1631	Fall detection switch low input voltage	View & note 'freeze frame' data if available.
P1632	Fall detection switch high input voltage or open circuit	View & note 'sensor' data Ensure switch connector is secure. Disconnect ECM and proceed to pinpoint test 1:

Pinpoint Tests

Test	Result	Action
1 Check cable and terminal integrity: - ECM pin B21	OK	Disconnect sensor and proceed to test 2
	Faulty	Rectify fault, proceed to test 6
2 Check cable for short circuit: - ECM pin B21 to ground	OK	Proceed to test 3
	Short circuit	Locate and rectify wiring fault, proceed to test 6
3 Check cable continuity: - ECM pin B01 to sensor pin 4 - ECM pin B21 to sensor pin 5 - ECM pin B20 to sensor pin 6	OK	Proceed to test 4
	Open circuit	Locate and rectify wiring fault, proceed to test 6
4 Check cable for short circuit: - ECM pin B21 to ECM pin B1 - ECM pin B21 to ECM pin B20	OK	Connect ECM and proceed to test 5
	Short circuit	Locate and rectify wiring fault, proceed to test 6
5 Check voltage (with ignition 'ON') between: - Sensor pin 4 and sensor pin 6	5V	Renew fall detection switch and proceed to test 6
	Less than 4.8V	Locate and rectify wiring fault, proceed to test 6
6 Reconnect harness, clear fault code	OK	Action complete, quit test
	Fault still present	Contact Triumph service

Circuit Diagram




Vehicle Speed Sensor

Fault Code	Possible cause	Action
P0500	Vehicle speed sensor circuit fault	View & note 'freeze frame' data if available. View & note 'sensor' data. Ensure sensor connector is secure. Disconnect ECM and proceed to pinpoint test 1:

Pinpoint Tests

Test	Result	Action
1 Check cable and terminal integrity: - ECM pin A34 - Instrument pin 9	OK	Disconnect sensor and proceed to test 2
	Faulty	Rectify fault, proceed to test 4
2 Check cable for short circuit: - ECM pin A34 to ground - ECM pin A34 to Instruments pin 9	OK	Proceed to test 3
	Faulty	Locate and rectify wiring fault, proceed to test 4
3 Check cable for continuity: - ECM pin A34 to sensor pin 3 - Sensor pin 2 to ground - Instruments pin 9 to sensor pin 1	OK	Renew vehicle speed sensor and proceed to test 4
	Open circuit	Locate and rectify wiring fault, proceed to test 4
4 Reconnect harness, clear fault code and run engine	OK	Action complete, quit test
	Fault still present	Contact Triumph service

Circuit Diagram




Instrument Communication (CAN)

Fault Code	Possible cause	Action
P1690	Fault in CAN communication between ECM and instrument pack.	View & note 'freeze frame' data if available. View & note 'sensor' data. Ensure instrument connector is secure. Disconnect ECM and proceed to pinpoint test 1:

Pinpoint Tests

Test	Result	Action
1 Check cable and terminal integrity: - ECM pin B27 - ECM pin B28 - Instrument pin 4 - Instrument pin 5	OK	Disconnect instruments and proceed to test 2
	Faulty	Rectify fault, proceed to test 4
2 Check cable for short circuit: - ECM pin B27 to B28 - ECM pin B27 to ground - ECM pin B28 to ground	OK	Proceed to test 3
	Faulty	Locate and rectify wiring fault, proceed to test 4
3 Check cable continuity: - ECM pin B28 to Instrument pin 4 - ECM pin B27 to Instrument pin 5	OK	Contact Triumph service
	Open circuit	Locate and rectify wiring fault, proceed to test 4
4 Reconnect harness, clear fault code and run engine	OK	Action complete, quit test
	Fault still present	Contact Triumph service

Circuit Diagram




Fuel Level Sensor

Fault Code	Possible cause	Action
P0460	Fuel level sensor circuit fault	View & note 'freeze frame' data if available. View & note 'sensor' data. Ensure sensor connector is secure. Disconnect ECM and proceed to pinpoint test 1:

Pinpoint Tests

Test	Result	Action
1 Check cable and terminal integrity: - ECM pin B04	OK	Disconnect sensor and proceed to test 2
	Faulty	Rectify fault, proceed to test 5
2 Check cable for short circuit: - ECM pin B04 to ground	OK	Proceed to test 3
	Short circuit	Locate and rectify wiring fault, proceed to test 5
3 Check cable continuity: - ECM pin B04 to sensor pin 1 - Sensor pin 2 to ground	OK	Proceed to test 4
	Open circuit	Locate and rectify wiring fault, proceed to test 5
4 Check cable for short circuit: - Sensor pin 1 to sensor pin 2	OK	Renew fuel level sensor and proceed to test 5
	Short circuit	Locate and rectify wiring fault, proceed to test 5
5 Reconnect harness, clear fault code	OK	Action complete, quit test
	Fault still present	Contact Triumph service

Circuit Diagram




Ambient (Barometric) Pressure Sensor

Fault Code	Possible cause	Action
P1107	Ambient pressure sensor circuit short circuit to ground	View & note 'freeze frame' data if available. View & note 'sensor' data. Ensure sensor connector is secure. Disconnect ECM and proceed to pinpoint test 1:
P1108	Ambient pressure sensor circuit, short circuit to supply or open circuit	Disconnect ambient pressure sensor and proceed to pinpoint test 4:

Pinpoint Tests

Test	Result	Action
1 Check cable and terminal integrity: - ECM pin A27 - ECM pin B20 - ECM pin B01	OK	Disconnect ambient pressure sensor and proceed to test 2
	Faulty	Rectify fault, proceed to test 5
2 Check cable for short circuit: - ECM pin A27 to ECM B20 - ECM pin A27 to ground	OK	Proceed to test 3
	Short circuit	Locate and rectify wiring fault, proceed to test 5
3 Check cable for continuity: - ECM pin A27 to sensor pin 1 - ECM pin B20 to sensor pin 2 - ECM pin B01 to sensor pin 3	OK	Renew ambient pressure sensor and proceed to test 5
	Open circuit	Locate and rectify wiring fault, proceed to test 5
4 Check cable for short circuit: - ECM pin A27 to ECM pin B01	OK	Renew ambient pressure sensor and proceed to test 5
	Short circuit	Locate and rectify wiring fault, proceed to test 5
5 Reconnect harness, clear fault code and run engine	OK	Action complete, quit test
	Fault still present	Contact Triumph service

Circuit Diagram




Manifold Absolute Pressure (Map) Sensor

Fault Code	Possible cause	Action
P0107	MAP sensor circuit short circuit to ground	View & note 'freeze frame' data if available. View & note 'sensor' data. Ensure sensor connector is secure. Disconnect ECM and proceed to pinpoint test 1:
P0108	MAP sensor circuit, short circuit to supply or open circuit	Disconnect MAP sensor and proceed to test 4:
P1105	MAP sensor pipe fault	Check connection/condition of pipe from MAP sensor to throttle body.

Pinpoint Tests

Test	Result	Action
1 Check cable and terminal integrity: - ECM pin A28 - ECM pin B20 - ECM pin B01	OK	Disconnect MAP sensor and proceed to test 2
	Faulty	Rectify fault, proceed to test 5
2 Check cable for short circuit: - ECM pin A28 to ECM B20 - ECM pin A28 to ground	OK	Proceed to test 3
	Short circuit	Locate and rectify wiring fault, proceed to test 5
3 Check cable for continuity: - ECM pin A28 to sensor pin 1 - ECM pin B20 to sensor pin 2 - ECM pin B01 to sensor pin 3	OK	Renew MAP sensor and proceed to test 5
	Open circuit	Locate and rectify wiring fault, proceed to test 5
4 Check cable for short circuit: - ECM pin A28 to ECM pin B01	OK	Renew MAP sensor and proceed to test 5
	Short circuit	Locate and rectify wiring fault, proceed to test 5
5 Reconnect harness, clear fault code and run engine	OK	Action complete, quit test
	Fault still present	Contact Triumph service

Circuit Diagram




Gear Position Sensor

Fault Code	Possible cause	Action
P0705	Gear position sensor circuit fault	View & note 'freeze frame' data if available. View & note 'sensor' data. Ensure sensor connector is secure. Disconnect ECM and proceed to pinpoint test 1:

Pinpoint Tests

Test	Result	Action
1 Check cable and terminal integrity: - ECM pin B24	OK	Disconnect sensor and proceed to test 2
	Faulty	Rectify fault, proceed to test 5
2 Check cable for short circuit: - ECM pin B24 to ground	OK	Proceed to test 3
	Short circuit	Locate and rectify wiring fault, proceed to test 5
3 Check cable for continuity: - ECM pin B24 to sensor pin 1 - ECM pin B20 to sensor pin 2 - ECM pin A31 to sensor pin 3	OK	Proceed to test 4
	Open circuit	Locate and rectify wiring fault, proceed to test 5
4 Check cable for short circuit: - Sensor pin 1 to sensor pin 2 - Sensor pin 1 to sensor pin 3	OK	Renew gear position sensor and contact pin and proceed to test 5
	Short circuit	Locate and rectify wiring fault, proceed to test 5
5 Reconnect harness, clear fault code	OK	Action complete, quit test
	Fault still present	Contact Triumph service

Circuit Diagram




Secondary Air Injection Valve

Fault Code	Possible cause	Action
P0413	Open circuit or short circuit to earth	View & note diagnostic software 'sensor' data. Ensure SAI valve connector is secure. Disconnect ECM and proceed to pinpoint test 1:
P0414	Short circuit to battery positive	Disconnect SAI valve and proceed to pinpoint test 5:

Pinpoint Tests

Test	Result	Action
1 Check cable and terminal integrity: - ECM pin B08	OK	Proceed to test 2
	Faulty	Rectify fault, proceed to test 7
2 Check resistance value: - ECM pin B08 to ECM pin A06	20Ω to 25Ω	Disconnect SAI valve and proceed to test 3
	Open circuit	Proceed to test 4
	Short circuit	Disconnect SAI valve and proceed to test 5
3 Check cable for short circuit: - ECM pin B08 to ground	OK	Proceed to test 6
	Short circuit	Locate and rectify wiring fault, proceed to test 7
4 Check cable continuity: - ECM pin B08 to valve pin 1 - ECM pin A06 to valve pin 2	OK	Proceed to test 6
	Open circuit	Locate and rectify wiring fault, proceed to test 7
5 Check cable for short circuit: - ECM pin B08 to ECM pin A06	OK	Proceed to test 6
	Short circuit	Locate and rectify wiring fault, proceed to test 7
6 Check SAI valve resistance: - Valve pin 1 to Valve pin 2	20Ω to 25Ω	Proceed to test 7
	Faulty	Renew SAI valve, proceed to test 7
7 Reconnect harness, clear fault code and run diagnostic software function test to visually verify operation of SAI valve	OK	Action complete - quit test
	Fault still present	Contact Triumph service

Circuit Diagram



Fuel Pump - up to VIN 300525 - without Fuel Pump Relay


Fault Code	Possible cause	Action
P1628	Open circuit or short circuit to earth	View & note diagnostic software 'sensor' data. Ensure fuel pump connector is secure. Disconnect ECM and proceed to pinpoint test 1:
P1629	Short circuit to battery positive	Disconnect fuel pump and proceed to pinpoint test 5:

Pinpoint Tests

Test	Result	Action
1 Check cable and terminal integrity: - ECM pin B36	OK	Proceed to test 2
	Faulty	Rectify fault, proceed to test 7
2 Check resistance value: - ECM pin B36 to fuse box Fuse 2, note that the engine stop switch must be in the 'RUN' position and any alarm fitted must be disarmed	2Ω to 6Ω	Disconnect fuel pump and proceed to test 3
	Open circuit	Proceed to test 4
	Short circuit	Disconnect fuel pump and proceed to test 5
3 Check cable for short circuit: - ECM pin B36 to earth	OK	Proceed to test 6
	Short circuit	Locate and rectify wiring fault, proceed to test 7
4 Check cable continuity: - ECM pin B36 to Pump pin 2 - Fuse box fuse 2 to fuel pump pin 1, note that the engine stop switch must be in the 'RUN' position and any alarm fitted must be disarmed	OK	Proceed to test 6
	Open circuit	Locate and rectify wiring fault, proceed to test 7
5 Check cable for short circuit: - ECM pin B36 to fuse box Fuse 2, note that the engine stop switch must be in the 'RUN' position and any alarm fitted must be disarmed	OK	Proceed to test 6
	Faulty	Locate and rectify wiring fault, proceed to test 7
6 Check fuel pump resistance: - Pump pin 1 to pump pin 2	2Ω to 6Ω	Proceed to test 7
	Faulty	Renew fuel pump module, proceed to test 7
7 Reconnect harness, clear fault code and run diagnostic software function test to verify operation of fuel pump	OK	Action complete - quit test
	Fault still present	Contact Triumph service

Fuel System/Engine Management

Circuit Diagram




Fuel Pump - from VIN 300526 - with Fuel Pump Relay

Fault Code	Possible cause	Action
P1231	Fuel pump relay short circuit to ground or open circuit	Check if pump runs briefly when ignition is switched on. Ensure fuel pump relay connector is secure. Disconnect ECM and proceed to pinpoint test 1:
P1232	Fuel pump relay short circuit to battery positive	Disconnect fuel pump relay and proceed to pinpoint test 4:

Pinpoint Tests

Test	Result	Action
1 Check cable and terminal integrity: - ECM pin B29	OK	Disconnect fuel pump relay and proceed to test 2
	Faulty	Rectify fault, proceed to test 5
2 Check cable for short circuit to ground: - ECM pin B29 to earth	OK	Proceed to test 3
	Short circuit	Locate and rectify wiring fault, proceed to test 5
3 Check cable continuity: - ECM pin B29 to fuel pump relay pin 2 - Fuel pump relay pin 1 to ECM pin A19	OK	Proceed to test 4
	Open circuit	Locate and rectify wiring fault, proceed to test 5
4 Check cable for short circuit: - ECM pin B29 to Alarm pin 1 or 3	OK	Proceed to test 5
	Short circuit	Locate and rectify wiring fault, proceed to test 5
5 Reconnect harness, clear fault code and run diagnostic software function test to verify operation of fuel pump	OK	Action complete - quit test
	Fault still present	Contact Triumph service

Circuit Diagram



Intake Air Flap Solenoid - Daytona 675 only

Fault Code	Possible cause	Action
P1670	Open circuit or short circuit to earth	View & note diagnostic software 'sensor' data. Ensure intake air flap solenoid connector is secure. Disconnect ECM and proceed to pinpoint test 1:
P1671	Short circuit to battery positive	Disconnect intake air flap actuator and proceed to pinpoint test 5:


Pinpoint Tests

Test	Result	Action
1 Check cable and terminal integrity: - ECM pin B10	OK	Proceed to test 2
	Faulty	Rectify fault, proceed to test 7
2 Check resistance value: - ECM pin B10 to ECM pin A06	40Ω to 50Ω	Disconnect intake flap solenoid and proceed to test 3
	Open circuit	Proceed to test 4
	Short circuit	Disconnect intake flap solenoid and proceed to test 5
3 Check cable for short circuit: - ECM pin B10 to earth	OK	Proceed to test 6
	Short circuit	Locate and rectify wiring fault, proceed to test 7
4 Check cable continuity: - ECM pin B10 to Actuator pin 2 - ECM pin A06 to Actuator pin 1	OK	Proceed to test 6
	Open circuit	Locate and rectify wiring fault, proceed to test 7
5 Check cable for short circuit: - ECM pin B10 to ECM pin A06	OK	Proceed to test 6
	Faulty	Locate and rectify wiring fault, proceed to test 7
6 Check Intake Air Flap Solenoid resistance: - Solenoid pin 1 to Actuator pin 2	40Ω to 50Ω	Proceed to test 7
	Faulty	Renew intake flap solenoid, proceed to test 7
7 Reconnect harness, clear fault code and run engine to visually verify operation of Intake Flap Actuator (see below)	OK	Action complete - quit test
	Fault still present	Contact Triumph service

Note:

- To verify the correct operation of the air intake flap, start the engine and briefly raise the engine speed above 4500 rpm. The flap should be seen to open as the engine speed rises and close again as the engine speed falls.

Circuit Diagram




Exhaust Butterfly Valve (EXBV) Position Sensor - Daytona 675 only

Fault Code	Possible cause	Action
P1078	Exhaust butterfly valve position sensor low input voltage (short to ground or open circuit)	View & note diagnostic software 'freeze frame' data if available. View & note diagnostic software 'sensor' data.
P1079	Exhaust butterfly valve position sensor high input voltage (short circuit to sensor supply)	Ensure actuator connector is secure. Disconnect ECM and proceed to pinpoint test 1:

Pinpoint Tests

Test	Result	Action
1 Check cable and terminal integrity: - ECM pin B02 - ECM pin B01 - ECM pin B20	OK	Disconnect Actuator and proceed to test 2
	Faulty	Rectify fault, proceed to test 5
2 Check cable for short circuit: - ECM pin B02 to ground	OK	Proceed to test 3
	Short circuit	Locate and rectify wiring fault, proceed to test 5
3 Check cable continuity: - ECM pin B02 to Actuator pin 2 - ECM pin B01 to Actuator pin 3 - ECM pin B20 to Actuator pin 1	OK	Proceed to test 4
	Open circuit	Locate and rectify wiring fault, proceed to test 5
4 Check cable for short circuit: - ECM pin B02 to ECM pin B01 - ECM pin B02 to ECM pin B20	OK	Renew exhaust control valve actuator, proceed to test 5
	Short circuit	Locate and rectify wiring fault, proceed to test 5
5 Reconnect harness, clear fault code and run diagnostic software function test to visually verify operation of the exhaust control valve actuator	OK	Action complete - quit test
	Fault still present	Contact Triumph service

Circuit Diagram




Exhaust Butterfly Valve (EXBV) Motor - Daytona 675 only

Fault Code	Possible cause	Action
P0078	Exhaust butterfly valve motor circuit fault	View & note diagnostic software 'freeze frame' data if available. View & note diagnostic software 'sensor' data. Ensure actuator connector is secure. Disconnect ECM and proceed to pinpoint test 1:
P1080	Cable or Mechanism fault	Proceed to pinpoint test 5:

Pinpoint Tests

Test	Result	Action
1 Check cable and terminal integrity: - ECM pin A07 - ECM pin A08	OK	Disconnect actuator and proceed to test 2
	Faulty	Rectify fault, proceed to test 6
2 Check cable for short circuit: - ECM pin A07 to ground - ECM pin A08 to ground	OK	Proceed to test 3
	Short circuit	Locate and rectify wiring fault, proceed to test 6
3 Check cable continuity: - ECM pin A07 to Actuator pin 6 - ECM pin A08 to Actuator pin 5	OK	Proceed to test 4
	Open circuit	Locate and rectify wiring fault, proceed to test 6
4 Check cable for short circuit: - ECM pin A07 to ECM pin A08	OK	Renew exhaust control valve actuator, proceed to test 6
	Short circuit	Locate and rectify wiring fault, proceed to test 6
5 Check adjustment of cables is within specification. Disconnect cables and check that the cables are free to slide through the cable outers (see page 10-131) Using a suitable tool check that the exhaust control valve can be rotated manually	OK	Renew Exhaust control valve actuator, proceed to test 6
	Faulty	Renew relevant part and proceed to test 6
6 Reconnect harness, clear fault code and run diagnostic software function test to visually verify operation of the exhaust control valve actuator	OK	Action complete - quit test
	Fault still present	Contact Triumph service

Circuit Diagram




EMS Main Relay Circuit

Fault Code	Possible cause	Action
P1685	EMS main relay circuit fault	Note that the starter motor cannot be powered if a main relay fault exists. Ensure the EMS main relay connector is secure. Proceed to pinpoint test 1:

Pinpoint Tests

Test	Result	Action
1 Ensure ignition has been switched off for greater than one minute. Identify EMS Main Relay on the harness. Check that relay operates when the ignition is switched ON.	OK	Proceed to test 2
	Faulty	Disconnect ECM and proceed to test 4
2 Check fuse box Fuse 6 integrity	OK	Disconnect ECM and proceed to test 4
	Faulty	Disconnect ECM and proceed to test 3
3 Check cable for short circuit: - ECM pin A06 to ground - EMS Main relay pin 3 to ground	OK	Replace Fuse 6 and proceed to test 4
	Short circuit	Locate and rectify wiring fault, replace Fuse 6 and proceed to test 7
4 Check cable and terminal integrity: - ECM pin A06 - ECM pin B15 - EMS Main Relay pin 1 - EMS Main Relay pin 2 - EMS Main Relay pin 3 - EMS Main Relay pin 5	OK	Disconnect Main Relay and proceed to test 5
	Faulty	Rectify fault, proceed to test 7
5 Check cable for short circuit: - ECM pin B15 to ground	OK	Proceed to test 6
	Short circuit	Locate and rectify wiring fault, proceed to test 7
6 Check cable continuity: - ECM pin A06 to EMS Relay pin 5 - ECM pin B15 to Relay pin 1 - EMS Main Relay pin 2 to ground - EMS Main Relay pin 3 to Fuse box Fuse 6	OK	Replace EMS Main Relay and proceed to test 7
	Open circuit	Locate and rectify wiring fault, proceed to test 7
7 Reconnect harness, clear fault code. Switch ignition off for longer than one minute. Switch ignition on and check that the EMS main relay operates. Start engine as final check	OK	Action complete - quit test
	Fault still present	Contact Triumph service

Circuit Diagram




EMS Ignition Voltage Input Circuit

Fault Code	Possible cause	Action
P1659	EMS ignition voltage input circuit fault	Disconnect ECM and proceed to pinpoint test 1:

Pinpoint Tests

Test	Result	Action
1 Check Fuse box Fuse 2 integrity	OK	Proceed to test 3
	Faulty	Proceed to test 2
2 Check cable for short circuit: - ECM pin A19 to ground	OK	Replace Fuse 2 and proceed to test 3
	Short circuit	Locate and rectify wiring fault, replace Fuse 2 and proceed to test 5
3 Check cable and terminal integrity: - ECM pin A19 - Alarm Connector pin 1 - Alarm Connector pin 2 - Right hand switchcube pin 2 - Right hand switchcube pin 5	OK	Proceed to test 4
	Faulty	Rectify fault, proceed to test 5
4 Check cable continuity: - ECM pin A19 to fuse box Fuse 2, note that the engine stop switch must be in the 'RUN' position and any Alarm fitted must be disarmed	OK	Proceed to test 5
	Open circuit	Locate and rectify wiring, immobiliser or engine stop switch fault, proceed to test 5
5 Reconnect harness, clear fault code and run engine to verify fault cleared	OK	Action complete - quit test
	Fault still present	Contact Triumph service

Circuit Diagram




5 Volt Sensor Supply Circuit

Fault Code	Possible cause	Action
P1698	Sensor supply circuit shorted Sensor supply circuit shorted to ground Sensor supply circuit shorted to battery positive	View & note 'sensor' data. Note ECM sensors requiring a power supply will not be active. Disconnect ECM and proceed to pinpoint test 1:

Pinpoint Tests

Test	Result	Action
1 Check cable and terminal integrity: - ECM pin B01 - ECM pin B20	OK	Proceed to test 2
	Faulty	Rectify fault, proceed to test 5
2 Check cable for short circuit - ECM pin B01 to ECM pin B20	OK	Proceed to test 4
	Faulty	Proceed to test 3
3 Disconnect the following sensors in turn: - MAP sensor - Ambient pressure sensor - Throttle position switch - Exhaust control valve actuator - Fall detection sensor and retest for short circuit - ECM pin B01 to ECM pin B20	OK	Replace sensor last removed and proceed to test 5
	Faulty	Proceed to test 4
4 Check cable for short circuit: - ECM pin B01 to ground - ECM pin B20 to ground - ECM pin B01 to A06 - ECM pin B20 to A06 - ECM pin B01 to battery positive - ECM pin B20 to battery positive	OK	Proceed to test 5
	Short circuit	Locate and rectify wiring fault, proceed to test 5
5 Reconnect harness, clear fault code and use service software to check for correct sensor outputs and 5V sensor supply voltage level	OK	Action complete - quit test
	Fault still present	Contact Triumph service

Circuit Diagram



Tune Lock

Fault Code	Possible cause	Action
P1602	ECM is locked to prevent the motorcycle from being operated	This is also identified by a fast flashing MIL indication, and a disabled engine management system. Unlock the ECM using the diagnostic software and supplied unlock code from Triumph service.

Test 1	Check voltage to ECM pin 85	OK	Placed in test 2
Test 2	Check voltage to ECM pin 85	OK	Placed in test 3
Test 3	Check voltage to ECM pin 85	OK	Placed in test 4
Test 4	Check voltage to ECM pin 85	OK	Placed in test 5
Test 5	Check voltage to ECM pin 85	OK	Placed in test 6
Test 6	Check voltage to ECM pin 85	OK	Placed in test 7
Test 7	Check voltage to ECM pin 85	OK	Placed in test 8
Test 8	Check voltage to ECM pin 85	OK	Placed in test 9
Test 9	Check voltage to ECM pin 85	OK	Placed in test 10
Test 10	Check voltage to ECM pin 85	OK	Placed in test 11
Test 11	Check voltage to ECM pin 85	OK	Placed in test 12
Test 12	Check voltage to ECM pin 85	OK	Placed in test 13
Test 13	Check voltage to ECM pin 85	OK	Placed in test 14
Test 14	Check voltage to ECM pin 85	OK	Placed in test 15
Test 15	Check voltage to ECM pin 85	OK	Placed in test 16
Test 16	Check voltage to ECM pin 85	OK	Placed in test 17
Test 17	Check voltage to ECM pin 85	OK	Placed in test 18
Test 18	Check voltage to ECM pin 85	OK	Placed in test 19
Test 19	Check voltage to ECM pin 85	OK	Placed in test 20
Test 20	Check voltage to ECM pin 85	OK	Placed in test 21
Test 21	Check voltage to ECM pin 85	OK	Placed in test 22
Test 22	Check voltage to ECM pin 85	OK	Placed in test 23
Test 23	Check voltage to ECM pin 85	OK	Placed in test 24
Test 24	Check voltage to ECM pin 85	OK	Placed in test 25
Test 25	Check voltage to ECM pin 85	OK	Placed in test 26
Test 26	Check voltage to ECM pin 85	OK	Placed in test 27
Test 27	Check voltage to ECM pin 85	OK	Placed in test 28
Test 28	Check voltage to ECM pin 85	OK	Placed in test 29
Test 29	Check voltage to ECM pin 85	OK	Placed in test 30
Test 30	Check voltage to ECM pin 85	OK	Placed in test 31
Test 31	Check voltage to ECM pin 85	OK	Placed in test 32
Test 32	Check voltage to ECM pin 85	OK	Placed in test 33
Test 33	Check voltage to ECM pin 85	OK	Placed in test 34
Test 34	Check voltage to ECM pin 85	OK	Placed in test 35
Test 35	Check voltage to ECM pin 85	OK	Placed in test 36
Test 36	Check voltage to ECM pin 85	OK	Placed in test 37
Test 37	Check voltage to ECM pin 85	OK	Placed in test 38
Test 38	Check voltage to ECM pin 85	OK	Placed in test 39
Test 39	Check voltage to ECM pin 85	OK	Placed in test 40
Test 40	Check voltage to ECM pin 85	OK	Placed in test 41
Test 41	Check voltage to ECM pin 85	OK	Placed in test 42
Test 42	Check voltage to ECM pin 85	OK	Placed in test 43
Test 43	Check voltage to ECM pin 85	OK	Placed in test 44
Test 44	Check voltage to ECM pin 85	OK	Placed in test 45
Test 45	Check voltage to ECM pin 85	OK	Placed in test 46
Test 46	Check voltage to ECM pin 85	OK	Placed in test 47
Test 47	Check voltage to ECM pin 85	OK	Placed in test 48
Test 48	Check voltage to ECM pin 85	OK	Placed in test 49
Test 49	Check voltage to ECM pin 85	OK	Placed in test 50
Test 50	Check voltage to ECM pin 85	OK	Placed in test 51
Test 51	Check voltage to ECM pin 85	OK	Placed in test 52
Test 52	Check voltage to ECM pin 85	OK	Placed in test 53
Test 53	Check voltage to ECM pin 85	OK	Placed in test 54
Test 54	Check voltage to ECM pin 85	OK	Placed in test 55
Test 55	Check voltage to ECM pin 85	OK	Placed in test 56
Test 56	Check voltage to ECM pin 85	OK	Placed in test 57
Test 57	Check voltage to ECM pin 85	OK	Placed in test 58
Test 58	Check voltage to ECM pin 85	OK	Placed in test 59
Test 59	Check voltage to ECM pin 85	OK	Placed in test 60
Test 60	Check voltage to ECM pin 85	OK	Placed in test 61
Test 61	Check voltage to ECM pin 85	OK	Placed in test 62
Test 62	Check voltage to ECM pin 85	OK	Placed in test 63
Test 63	Check voltage to ECM pin 85	OK	Placed in test 64
Test 64	Check voltage to ECM pin 85	OK	Placed in test 65
Test 65	Check voltage to ECM pin 85	OK	Placed in test 66
Test 66	Check voltage to ECM pin 85	OK	Placed in test 67
Test 67	Check voltage to ECM pin 85	OK	Placed in test 68
Test 68	Check voltage to ECM pin 85	OK	Placed in test 69
Test 69	Check voltage to ECM pin 85	OK	Placed in test 70
Test 70	Check voltage to ECM pin 85	OK	Placed in test 71
Test 71	Check voltage to ECM pin 85	OK	Placed in test 72
Test 72	Check voltage to ECM pin 85	OK	Placed in test 73
Test 73	Check voltage to ECM pin 85	OK	Placed in test 74
Test 74	Check voltage to ECM pin 85	OK	Placed in test 75
Test 75	Check voltage to ECM pin 85	OK	Placed in test 76
Test 76	Check voltage to ECM pin 85	OK	Placed in test 77
Test 77	Check voltage to ECM pin 85	OK	Placed in test 78
Test 78	Check voltage to ECM pin 85	OK	Placed in test 79
Test 79	Check voltage to ECM pin 85	OK	Placed in test 80
Test 80	Check voltage to ECM pin 85	OK	Placed in test 81
Test 81	Check voltage to ECM pin 85	OK	Placed in test 82
Test 82	Check voltage to ECM pin 85	OK	Placed in test 83
Test 83	Check voltage to ECM pin 85	OK	Placed in test 84
Test 84	Check voltage to ECM pin 85	OK	Placed in test 85
Test 85	Check voltage to ECM pin 85	OK	Placed in test 86
Test 86	Check voltage to ECM pin 85	OK	Placed in test 87
Test 87	Check voltage to ECM pin 85	OK	Placed in test 88
Test 88	Check voltage to ECM pin 85	OK	Placed in test 89
Test 89	Check voltage to ECM pin 85	OK	Placed in test 90
Test 90	Check voltage to ECM pin 85	OK	Placed in test 91
Test 91	Check voltage to ECM pin 85	OK	Placed in test 92
Test 92	Check voltage to ECM pin 85	OK	Placed in test 93
Test 93	Check voltage to ECM pin 85	OK	Placed in test 94
Test 94	Check voltage to ECM pin 85	OK	Placed in test 95
Test 95	Check voltage to ECM pin 85	OK	Placed in test 96
Test 96	Check voltage to ECM pin 85	OK	Placed in test 97
Test 97	Check voltage to ECM pin 85	OK	Placed in test 98
Test 98	Check voltage to ECM pin 85	OK	Placed in test 99
Test 99	Check voltage to ECM pin 85	OK	Placed in test 100



ECM or Tune ID Incorrect

Fault Code	Possible cause	Action
P1614	ECM or tune is incorrect, causing the ECM to be disabled to prevent the motorcycle from being operated	This is also identified by a fast flashing MIL indication, and a disabled engine management system.

Pinpoint Tests

Test	Result	Action
1 Check ECM part number is correct for the motorcycle	OK	Proceed to test 2
	Incorrect	Replace ECM with correct part and proceed to test 3
2 Check that the tune is correct for the motorcycle, using the diagnostic software	OK	Proceed to test 3
	Incorrect	Update tune using the diagnostic software, proceed to test 3
3 Clear fault code, check for normal operation	OK	Action complete - quit test
	Fault still present	Contact Triumph service

Fault Finding - Non Electrical

Symptom	Possible cause(s)
Poor throttle response at low RPM	Low fuel pressure caused by filter blockage/leaks
Cutting out at idle	Throttle bodies out of balance
	ISC (Idle Speed Control) actuator inoperative
	Low fuel pressure
	Weak mixture caused by air leak at the throttle body/transition piece to cylinder head face
Idle speed too low/high	ISC (Idle Speed Control) actuator sticking
	Incorrect closed throttle position setting
	Mechanical fault with the throttle linkage
Diagnostic software malfunctions during tune download procedure	Low battery voltage
Throttle hang-up	Incorrect closed throttle position setting
Bike will start but cuts out immediately	ISC motor stuck
	Low fuel pressure caused by filter blockage/leaks
Abnormally high fuel pressure	Fuel pressure regulator inoperative
Temperature gauge reads cooler than normal	Cooling system air-locked resulting in coolant temperature sensor operating in air instead of coolant
Intake air flap inoperative - (Daytona 675 only)	Vacuum leak to actuator, vacuum reservoir or hoses

Fuel Tank


Removal

Warning


Observe the warning advice given in the general information section on the safe handling of fuel and fuel containers.

A fire, causing personal injury and damage to property, could result from spilled fuel or fuel not handled or stored correctly.

1. Remove the rider's seat (see page 16-17).
2. Disconnect the battery, negative (black) lead first.
3. Release the bolts securing the fuel tank to the frame.




1. Rear fuel tank to frame bolt



1. Front fuel tank to frame bolts

4. Withdraw the spacer sleeve from the frame.



1. Spacer sleeve


5. Raise the fuel tank and disconnect the electrical connections to the fuel pump and the low fuel level sensor.

Warning

When disconnected, the fuel tank is self-sealing but a small amount of fuel may escape causing clothing and components to be coated with fuel.

This would represent a serious fire hazard which could lead to burn injuries and damage to property.

6. On models fitted with a double check clip (from early 2007), ease the latch away from the connector until the release buttons are exposed.



1. Locked Position


2. Unlocked Position

7. Disconnect the fuel hose by squeezing the sides of the connector and pulling the hose free from its spigot on the fuel pump plate.

Note:

- On Street Triple and Street Triple R models, access to the fuel hoses connector is restricted. An assistant may be required to support the fuel tank whilst disconnecting the fuel hose on these models.
- Before disconnection, note the position of the two breather hoses so that they can be returned to the same locations when refitting the tank.

8. Disconnect the two breather hoses.



cdve


1. Fuel hose
 2. Fuel pump electrical connection
 3. Low fuel level sensor connection
 4. Breather hoses
9. Remove the fuel tank from the frame.

Installation

1. Position the fuel tank to the frame.
2. Connect the two breather hoses as previously noted.

Note:

- The fuel hose has different coloured connectors on each end, to aid orientation. The orange end must be fitted to the fuel tank, the grey end must be fitted to the fuel rail.
3. Reconnect the fuel feed hose by gently pushing inwards until the hose engages with a click.
 4. Slide the double check latch down (i.e. towards the spigot) until the release buttons are covered. If the latch will not slide into position, then the fuel hose is not fully home on its spigot and must therefore be refitted correctly.
 5. Reconnect the fuel pump electrical connection.
 6. Reconnect the low fuel level sensor.



cdve


1. Fuel hose
 2. Fuel pump electrical connection
 3. Low fuel level sensor connection
 4. Breather hoses
7. Align the fuel tank to the mounting points. Refit the rear spacer sleeve. Fit and tighten the three bolts to **9 Nm**.
 8. Reconnect the battery, positive (red) lead first.
 9. Start the engine and check carefully for fuel leaks. Rectify as necessary.
 10. Refit the rider's seat (see page 16-17).

Fuel Tank - Raising and Supporting - Street Triple and Street Triple R only

Note:

- The fuel tank may be raised without being removed completely, for access to fuse box and relays.

1. Remove the rider's seat (see page 16-17).
2. Disconnect the battery, negative (black) lead first.
3. Remove the fuel tank support from its location under the seat base.




1. Fuel tank support
2. Seat base

4. Remove the front fuel tank fixings and pivot the fuel tank upwards at the front.

Note:


- It is permissible to use either the left hand or right hand fixing holes to support the fuel tank.
5. While supporting the fuel tank in the raised position, locate the fuel tank support into the fixing hole in the frame and into the fixing hole in the fuel tank bracket.



1. Fuel tank support
2. Fuel tank

Fuel Tank - Lowering and Securing - Street Triple and Street Triple R only

1. Support the fuel tank and remove the tank support.
2. Lower the fuel tank into position and secure with the two fixings. Tighten to **9 Nm**.
3. Refit the fuel tank support to its location under the seat base.



1. Fuel tank support
2. Seat base

4. Reconnect the battery, positive (red) lead first.
5. Refit the seat (see page 16-17).

Fuel Pump, Fuel Filter and Low Fuel Level Sensor

Removal

Note:


- The fuel pump, fuel filter and low fuel level sensor assembly is a sealed for life unit and must be replaced as a complete assembly.

1. Remove the rider's seat (see page 16-17).
2. Disconnect the battery, negative (black) lead first.
3. Remove the fuel tank (see page 10-89).
4. Drain the fuel tank into a suitable container.

Warning

Observe the warning advice given in the general information section on the safe handling of fuel and fuel containers. A fire, causing personal injury and damage to property, could result from spilled fuel or fuel not handled or stored correctly.

5. Invert the fuel tank and place on a protective surface to prevent paint damage.
6. Remove the fixings securing the fuel pump mounting plate to the fuel tank.




1. Mounting plate

2. Mounting plate fixings

7. Lift the fuel pump assembly and manoeuvre it from the fuel tank aperture.

8. Noting its orientation, remove and discard the sealing ring from the fuel pump assembly.




1. Fuel pump assembly

2. Sealing ring location

Installation

1. Install a new sealing ring in the fuel pump assembly, with the seal lip facing uppermost, and ensure that it is correctly seated.




cdva

1. Sealing ring

2. Seal lip


2. Taking care to ensure the sealing ring is not damaged or dislodged, manoeuvre the fuel pump assembly into the fuel tank aperture.

3. Ensure the locating peg on the fuel pump assembly is located in the cut out on the mounting plate and the offset hole is positioned as shown below.



1. Offset hole position
2. Locating peg

4. In the sequence shown below, tighten the mounting plate fixings to **9 Nm**.



Fuel pump mounting plate torque sequence

5. Refit the fuel tank (see page 10-90).
6. Reconnect the battery, positive (red) lead first.
7. Refit the rider's seat (see page 16-17).

Fuel Pressure Checking



Warning

Observe the fuel handling precautions given in the general information section.

Fuel pressure is checked using service tool T3880001.



cdgh

Tool T3880001

1. Remove the rider's seat (see page 16-17).
2. Remove the fuel tank (see page 10-89) and place on a suitable support, close to the motorcycle.
3. Using the extension cable T3880123, carefully connect the fuel pump connection on the main harness to the fuel tank. Connect the other end of the extension cable to the motorcycle main harness.
4. Select the fuel pressure gauge adapter marked 'B' from service tool T3880001.




Warning

Always use the correct fuel pressure gauge adapter (**adapter 'B' for Daytona 675, Street Triple and Street Triple R**). Use of an incorrect adapter will result in a fuel leak. A fuel leak can result in a fire causing damage to property and injury to persons.

Fuel System/Engine Management


5. Connect the adaptor hose to the fuel pump plate outlet as shown in the illustration below.



cdve

1. Adaptor hose 'B'
2. Fuel pump plate outlet
3. Extension cable T3880123


6. Connect the fuel hose to the adaptor hose as shown in the illustration below.



cdxt

1. Motorcycle fuel hose (Daytona 675 shown)
2. Adaptor hose 'B'
3. Fuel pump connection
4. Wiring extension T3880123
5. Fuel pump connection
6. Fuel pump plate outlet

7. Connect the fuel pressure gauge to the adaptor hose as shown below by pushing the gauge spigot in to adaptor until a click can be heard.



cdvr

1. Adaptor hose
2. Fuel pressure gauge

Note:

- To release the fuel pressure gauge from the adapter, slide the outer ferrule downwards. This will allow the gauge to spring upwards from the adapter.
8. Ensure the gauge is visible to the side of the motorcycle.
 9. Start the engine and observe the fuel pressure reading on the gauge.


Note:

- The fuel pressure should be 3.0 bar nominally.
10. When fuel pressure checking is complete, disconnect the fuel pressure gauge adapter and wiring extension.
 11. Refit the fuel tank (see page 10-90).
 12. Refit the rider's seat (see page 16-17).

Fuel Delivery System

Fuel is delivered to the injectors by a pump located inside the fuel tank. Fuel flows in the direction of the arrows shown in the diagram below.

Incorporated in the fuel pump assembly is a filter, a pressure regulator and a pick-up strainer. The fuel pump assembly also contains the low fuel level sensor.




Direction of Fuel Flow

Airbox

Removal


1. Remove the rider's seat (see page 16-17).
2. Disconnect the battery, negative (black) lead first.
3. Remove the fuel tank (see page 10-89).
4. Disconnect the ECM connectors (see page 10-43).
5. **Street Triple and Street Triple R only:** Remove the three fixings and detach the relay and fuse box bracket. Without disconnecting any connectors, position the bracket assembly aside.



1. Relay and fuse box bracket

2. Fixings

6. **All models:** Disconnect the intake air temperature sensor multi-plug.




1. Intake air temperature sensor

2. Multi-plug


Fuel System/Engine Management

7. Disconnect the map sensor multi-plug.



1. Map sensor
2. Multi-plug


8. Release the eight fixings and remove the airbox upper section.



1. Airbox upper section
2. Fixings


9. Release the six fixings and remove the airbox intake trumpets.

10. Release the fixing securing the airbox to the frame.




1. Airbox front fixing location
2. Airbox intake trumpet fixings

11. Release the spring hose clip and disconnect the secondary air injection hose at the airbox.



1. Secondary air injection hose
2. Spring hose clip

12. Release the spring hose clip and disconnect the engine breather hose at the airbox.



1. Engine breather hose
2. Spring hose clip

13. Remove the airbox from the motorcycle.


Inspection

1. Thoroughly clean the inside and outside of the airbox.
2. Check the airbox and intake trumpets for damage.
3. Check the air intake seal at the front of the airbox for damage.

Installation

1. Position the airbox to the frame.
2. Connect the engine breather hose and refit the spring hose clip.
3. Connect the secondary air injection hose and refit the spring hose clip.

4. Align the front of the air box to the frame and loosely install the fixing. Do not tighten the fixing at this stage.
5. Align the rear of the airbox to the throttle bodies and fit the airbox intake trumpets. Tighten the fixings to **6 Nm**.
6. Tighten the airbox front fixing to **3 Nm**.
7. Refit the airbox upper section and tighten the fixings to **1.5 Nm**.
8. Reconnect the air temperature and map sensor multi-plugs.
9. **Street Triple and Street Triple R only:** Reposition the relay and fusebox bracket to the airbox and install the three fixings. Tighten the fixings to **3 Nm**.



cerk

1. Relay and fuse box bracket

2. Fixings

10. **All models:** Reconnect the ECM connectors (see page 10-44).
11. Refit the fuel tank (see page 10-90).
12. Reconnect the battery, positive (red) lead first.
13. Refit the rider's seat (see page 16-17).


Air Filter Element

Removal

Note:

- The air filter element can be accessed after first removing the airbox upper section. It is not necessary to remove the lower section.

1. Remove the rider's seat (see page 16-17).
2. Disconnect the battery negative (black) lead first.
3. Remove the fuel tank (see page 10-89).
4. Remove the airbox upper section (see page 10-95).
5. Remove and discard the six fixings then remove the air filter element from the airbox lower section.



cdvh

1. Air filter element

2. Fixings


Installation

1. Thoroughly clean the inside and outside of the airbox.
2. Seat the air filter element in the lower section.
3. Secure the air filter element with new fixings. Tighten to **4 Nm**.
4. Refit the airbox upper section (see page 10-96).
5. Refit the fuel tank (see page 10-90).
6. Reconnect the battery, positive (red) lead first
7. Refit the rider's seat (see page 16-17).

Intake Air Temperature Sensor

Removal

1. Remove the rider's seat (see page 16-17).
2. Disconnect the battery, negative (black) lead first.
3. Remove the fuel tank (see page 10-89).
4. Disconnect the intake air temperature sensor multi-plug.



1. Intake air temperature sensor (Daytona 675 shown)
2. Multi-plug

Note:

- The intake air temperature sensor has a threaded base.

5. Unscrew the sensor to remove it from the airbox.


Installation

1. Fit the air temperature sensor to the airbox. Tighten the sensor to **4 Nm**.
2. Reconnect the intake air temperature sensor multi-plug.
3. Refit the fuel tank (see page 10-90).
4. Reconnect the battery, positive (red) lead first.
5. Refit the rider's seat (see page 16-17).

Map Sensor

Removal

1. Remove the rider's seat (see page 16-17).
2. Disconnect the battery, negative (black) lead first.
3. Remove the fuel tank (see page 10-89).
4. Disconnect the map sensor multi-plug.



1. Map sensor
2. Multi-plug
3. Fixing
4. Vacuum hose

5. Disconnect the vacuum hose from the sensor.
6. Release the fixing screw securing the sensor to the airbox and remove the sensor.

Installation

1. Fit the sensor to the airbox, tightening the fixing to **3 Nm**.
2. Refit the vacuum hose.
3. Reconnect the map sensor multi-plug.
4. Refit the fuel tank (see page 10-90).
5. Reconnect the battery, positive (red) lead first.
6. Refit the rider's seat (see page 16-17).


Barometric Pressure Sensor - Daytona 675 only

Removal

Note:

- The barometric pressure sensor is located on the intake air duct behind the fairing cockpit. It is not necessary to remove the cockpit to access the sensor.

- Remove the rider's seat (see page 16-17).
- Disconnect the battery, negative (black) lead first.
- Remove the windscreen (see page 16-22 for Daytona 675 up to VIN 381274, see page 16-23 for Daytona 675 from VIN 381275).
- Disconnect the multi-plug.
- Release the fixing securing the sensor to the intake air duct and remove the sensor.



- Barometric pressure sensor (cockpit shown removed for clarity)
- Multi-plug
- Fixing

Installation

- Fit the sensor to the intake air duct, tightening the fixing to **3 Nm**.
- Reconnect the multi-plug.
- Refit the windscreen (see page 16-22 for Daytona 675 up to VIN 381274, see page 16-25 for Daytona 675 from VIN 381275).
- Reconnect the battery, positive (red) lead first.
- Refit the rider's seat (see page 16-17).


Barometric Pressure Sensor - Street Triple and Street Triple R only

Removal

Note:

- The barometric pressure sensor is located on the rear subframe, forward of the rear light unit.

- Remove the rider's seat (see page 16-17).
- Disconnect the battery, negative (black) lead first.
- Remove the rear bodywork (see page 16-19).
- Remove the rear light unit (see page 17-26).
- Disconnect the multi-plug.
- Release the fixing securing the sensor to the rear subframe and remove the sensor.



- Barometric pressure sensor
- Fixing
- Multi-plug

Installation

- Fit the sensor to the rear subframe, tightening the fixing to **3 Nm**.
- Reconnect the multi-plug.
- Refit the rear light unit (see page 17-26).
- Refit the rear bodywork (see page 16-25).
- Reconnect the battery, positive (red) lead first.
- Refit the rider's seat (see page 16-17).


Fall Detection Switch - Daytona 675 only

Removal

Note:

- The fall detection switch is located on the instrument bracket behind the fairing cockpit. It is not necessary to remove the cockpit to access the switch.

- Remove the rider's seat (see page 16-17).
- Disconnect the battery, negative (black) lead first.
- Remove the windscreen (see page 16-22 for Daytona 675 up to VIN 381274, see page 16-23 for Daytona 675 from VIN 381275).
- Disconnect the multi-plug.
- Release the fixings securing the switch to the instrument bracket and remove the switch.



- cdvs
- Fall detection switch (cockpit shown removed for clarity)
 - Multi-plug
 - Fixings

Installation

- Fit the switch to the instrument bracket, tightening the two fixings to **3 Nm**.
- Reconnect the multi-plug.
- Refit the windscreen (see page 16-22 for Daytona 675 up to VIN 381274, see page 16-25 for Daytona 675 from VIN 381275).
- Reconnect the battery, positive (red) lead first.
- Refit the rider's seat (see page 16-17).


Fall Detection Switch - Street Triple and Street Triple R only

Removal

Note:

- The fall detection switch is located on the relay bracket fitted to the airbox.

- Remove the rider's seat (see page 16-17).
- Disconnect the battery, negative (black) lead first.
- Remove the fuel tank (see page 10-89).
- Disconnect the multi-plug.
- Release the fixings securing the switch to the relay bracket and remove the switch.



- cerk1
- Fall detection switch
 - Multi-plug
 - Fixings


Installation

- Fit the switch to the relay bracket, tightening the two fixings to **3 Nm**.
- Reconnect the multi-plug.
- Refit the fuel tank (see page 10-90).
- Reconnect the battery, positive (red) lead first.
- Refit the rider's seat (see page 16-17).

Intake Air Duct - Daytona 675 only

Removal

1. Remove the rider's seat (see page 16-17).
2. Disconnect the battery, negative (black) lead first.
3. Remove the cockpit (see page 16-23).
4. Remove the barometric pressure sensor (see page 10-99).
5. Detach the instrument pack bracket, together with the fall sensor and its bracket (see page 17-20) and tie aside.
6. Disconnect the vacuum hose from the intake air flap actuator.
7. Release the four fixings securing the intake air duct to the frame headstock and remove the duct.



1. Intake air duct
2. Fixings (left hand shown)

Installation

1. Position the duct to the frame headstock and refit the four fixings. Tighten the fixings to **7 Nm**.
2. Reconnect the intake air flap actuator vacuum hose.
3. Refit the instrument bracket and fall detection switch bracket (see page 17-21).
4. Refit the barometric pressure sensor (see page 10-99).
5. Refit the cockpit (see page 16-24).
6. Reconnect the battery, positive (red) lead first.
7. Refit the rider's seat (see page 16-17).


Intake Air Flap Actuator - Daytona 675 only

Operation

The intake air flap actuator is located on the intake air duct, forward of the instruments. It is vacuum operated, being controlled by a solenoid valve which is in turn operated by the ECM.


Removal

1. Remove the rider's seat (see page 16-17).
2. Disconnect the battery, negative (black) lead first.
3. Remove the cockpit (see page 16-23).
4. Remove the grille from the intake air duct.
5. Disconnect the vacuum hose from the intake air flap actuator.
6. Rotate the actuator one quarter turn clockwise to release it from the intake air duct.



1. Actuator
2. Actuator release direction


7. Disconnect the actuator rod from the intake air flap and remove the actuator.



1. Actuator
2. Actuator rod removal direction


Installation

1. Position the actuator to the intake air duct and connect the actuator rod to the intake air flap.



1. Actuator
2. Actuator rod installation direction

2. Rotate the actuator one quarter turn anti-clockwise to refit the actuator to the intake air duct.



1. Actuator
2. Actuator installation direction

3. Reconnect the intake air flap actuator vacuum hose.
4. Refit the intake air duct grille.
5. Refit the cockpit (see page 16-24).
6. Reconnect the battery, positive (red) lead first.
7. Refit the rider's seat (see page 16-17).

Crankshaft position sensor

Note:


- The alternator stator and crankshaft position sensor are supplied as an assembly and cannot be separated.
- For additional information, refer to alternator (see page 17-33 for removal and page 17-34 for installation).

Throttle Cable

Adjustment

Note:

- Minor adjustments to the opening cable can be made using the adjuster near the throttle grip end of the throttle. Where a correct setting cannot be achieved this way, the adjusters at the throttle end of both cables must be used. The opening cable must be set first followed by the closing cable.




1. Throttle grip

2. Correct setting, 2-3 mm

1. Remove the rider's seat (see page 16-17).
2. Disconnect the battery, negative (black) lead first.
3. Set the 'opening' cable adjuster at the throttle grip end such that it has an equal amount of adjustment in each direction. Tighten the locknut.
4. Remove the fuel tank (see page 10-89).
5. Remove the airbox (see page 10-95).

- Set the 'opening' cable adjuster at the throttle body end to give 2-3 mm of play at the throttle grip. Tighten the locknut.



1. 'Opening' Cable Adjuster (Throttle End)

2. 'Closing' Cable Adjuster (Throttle End)

3. Closing cable – free play measurement point

- With the throttle fully closed, ensure that there is 2-3 mm of free play in the 'closing' cable. Adjust if necessary ensuring that the locknut is secure afterwards.



Warning

Operation of the motorcycle with incorrectly adjusted, incorrectly routed or damaged throttle cables could interfere with the operation of the brakes, clutch or the throttle itself. Any of these conditions could result in loss of motorcycle control and an accident.



Warning

Move the handlebars to left and right full lock while checking that cables and harnesses do not bind. Cables or harness that bind will restrict the steering and may cause loss of motorcycle control and an accident.



Warning

Ensure that the adjuster locknuts are tightened. A loose throttle cable adjuster could cause the throttle to stick leading to loss of motorcycle control and an accident.


- Refit the airbox (see page 10-96).
- Refit the fuel tank (see page 10-90).
- Reconnect the battery, positive (red) lead first.
- Refit the rider's seat (see page 16-17).

Removal

Note:

- Before beginning to remove the throttle cables, note the exact routing and location of both cables to help ensure that they are returned to the same locations and routing on assembly.

- Remove the rider's seat (see page 16-17).
- Disconnect the battery, negative (black) lead first. (see page 17-14).
- Remove the fuel tank (see page 10-89).
- Remove the airbox (see page 10-95).
- Detach the throttle bodies (see page 10-106).
- Slacken the adjuster locknuts at the throttle body end of the cables such that they will allow the outer cables to be detached from the cable bracket.
- Detach the inner cable nipples from the throttle cam.



1. Throttle cam


2. Opening cable

3. Closing cable

4. Opening cable nipple

5. Closing cable nipple


8. At the throttle grip end, slide off the rubber boot and release the screws which secure the two halves of the throttle grip guide to each other.



cdut

1. Throttle grip guide
2. Screws
3. Rubber boot

9. Separate the two halves of the guide then release the inner cables from the throttle grip.



cduu

1. Opening cable
2. Closing cable

10. Detach the cables from the motorcycle.


Inspection

1. Check that both the throttle cables operate smoothly, without sticking or binding. Replace the cables if there is any doubt as to their correct operation.

Installation

1. Locate the cables to the frame following the routing noted during removal.


2. Engage the inner cable nipples to the throttle grip, ensuring the 'opening' cable is located in the upper slot in the throttle grip, and the 'closing' cable is located to the lower slot.



cduu

1. Opening cable
2. Closing cable

3. Assemble the two halves of the cable guide ensuring that the outer cables are correctly located in the guide and the guide is positioned on the handlebars as noted prior to removal. Fit and tighten the two screws to **4 Nm**.




cdut

1. Throttle grip guide
2. Screws
3. Rubber boot

4. Refit the boot.
5. Attach the other end of the inner cables to the throttle cam ensuring the 'opening' cable is fitted to the top of the cam and the 'closing' cable to the bottom.

6. Locate the outer cables to the bracket and adjust until the start of the thread is 14 mm away from the back of the throttle cable bracket. Secure the adjuster and locknuts.



1. Opening cable

2. Closing cable

7. Refit the throttle bodies (see page 10-108).
8. Set the throttle cable adjustment (see page 10-103).
9. Refit the airbox (see page 10-96).
10. Refit the fuel tank (see page 10-90).
11. Reconnect the battery, positive (red) lead first
12. Refit the rider's seat (see page 16-17).

Throttle Bodies/Injectors

Removal

Note:


- Because fuel stored in the fuel rail will be at 3 bar pressure, it is essential that the fuel pressure is reduced before any dismantling of the fuel rail takes place. To reduce pressure, briefly crank the engine with the fuel pump disconnected.

Warning

If the fuel rail is dismantled without first reducing pressure fuel may escape causing clothing and components to be coated with fuel.

This would represent a serious fire hazard which could lead to burn injuries and damage to property.

1. Remove the rider's seat (see page 16-17).
2. Disconnect the battery, negative (black) lead first.
3. Remove the fuel tank (see page 10-89).
4. Remove the airbox (see page 10-95).
5. Disconnect the throttle position sensor multi-plug.
6. Disconnect the fuel injector multi-plugs.
7. Disconnect the idle speed control stepper motor multi-plug.
8. Release the clips securing the throttle bodies to the transition pieces.




1. Transition piece (one per cylinder)

2. Clip location (throttle bodies removed for clarity)


9. Ease the throttle bodies from the transition pieces and lay the assembly carefully on the cam cover.
10. Release both throttle cables from the throttle cam (see page 10-104).

11. Remove the throttle bodies.
12. If required, release the screws securing the fuel rail to the throttle bodies.




1. Fuel rail
2. Fuel rail screws

13. Ease the fuel rail and injectors from the throttle bodies.
14. To detach the injectors from the fuel rail, gently ease the injector from the rail.



1. Injector
2. Fuel rail

15. To detach the transition pieces from the head, release the screws, raise the transition pieces and collect the O-rings.




1. Transition piece
2. O-ring
3. Fixings

Inspection

1. Check all joints and seals for splits, cuts and damage.
2. Check the throttles for sticking, loose or damaged throttle plates.
3. Check the transition piece O-rings for damage.

Installation

1. Thoroughly clean the transition piece to cylinder head mating faces.
2. Refit the transition pieces to the head incorporating new O-rings to the joint face. Tighten the transition piece fixings to **12 Nm**.




1. Transition piece

2. O-ring

3. Fixings

3. If the injectors have been removed from the fuel rail, refit them to the rail, ensuring the injector locating peg is fully engaged in the slot in the rail.



cdvp1


1. Injector

2. Fuel rail

3. Locating peg

4. Check the injector O-rings for splits and other damage. Replace as necessary.

5. Refit the injectors and fuel rail to the throttle bodies. Tighten the fuel rail screws to **3.5 Nm**.



cdus

1. Fuel rail


2. Fuel rail screws

6. Re-attach the throttle cables (see page 10-105).

Warning

The throttle body clips must be positioned as shown below. If the clips are not positioned as shown this could cause the throttle to stick, leading to loss of motorcycle control and an accident.

7. Refit the throttle bodies to the transition pieces and secure with the clips.



cdux

1. Transition piece (one per cylinder)

2. Clip location (throttle bodies removed for clarity)

8. Adjust the throttle cables (see page 10-103).
9. Reconnect the idle speed control stepper motor multi-plug.
10. Reconnect the fuel injector multi-plugs.
11. Reconnect the throttle position sensor multi-plug.
12. Refit the airbox (see page 10-96).
13. Refit the fuel tank (see page 10-90).
14. Reconnect the battery, positive (red) lead first.
15. Refit the rider's seat (see page 16-17).

Throttle Body Balancing

Note:

- The throttles cannot be balanced using equipment to measure vacuum in each throttle. Instead, the Triumph diagnostic software must be used.

- Remove the rider's seat (see page 16-17).
- Remove the fuel tank (see page 10-89) and place on a suitable support, close to the motorcycle.
- Remove the airbox (see page 10-95).



Warning

If the engine has recently been running, the components beneath the fuel tank may be hot to the touch.


- Turn the ignition to the 'OFF' position.
- Using the extension cable T3880123, carefully connect the fuel pump connection on the main harness to the fuel tank. Connect the other end of the harness extension to the motorcycle main harness.
- Select the fuel pressure gauge adapter marked 'B' from service tool T3880001.



Warning

Always use the correct fuel pressure gauge adapter (adapter 'B' for Daytona 675, Street Triple and Street Triple R). Use of an incorrect adapter will result in a fuel leak. A fuel leak can result in a fire causing damage to property and injury to persons.


- Connect the adapter hose to the fuel pump plate outlet as shown in the illustration below.



cdve

- Adapter hose 'B'
- Fuel pump plate outlet
- Tool T3880123

- Connect the fuel hose to the adaptor hose as shown in the illustration below.




- Motorcycle fuel hose
- Adaptor hose 'B'
- Fuel pump connection
- Wiring extension T3880123
- Fuel pump connection
- Fuel pump plate outlet

- Attach exhaust extraction hoses to the silencer.
- Attach the Triumph diagnostic tool to the dedicated plug, refer to the Triumph Diagnostic Tool User Guide. Start the engine, and allow to idle.
- On the diagnostic software navigate to 'ADJUST TUNE'.
- Select 'BALANCE THROTTLES'.
- Click the Adjust button.

Note:

- The balance throttle screen will show the vacuum value of each throttle in mm/hg. In addition, when the throttles are balanced to an acceptable range of each other the word **'THROTTLES BALANCED'** in green text will appear on the right of the screen. At this point, no further adjustment is necessary or productive.
 - If the throttles are not balanced to each other the word **'THROTTLES UN-BALANCED'** in red text will appear on the right of the screen. At this point adjustment will be necessary.
 - The adjusters operate on the outer cylinders only (cylinders 1 and 3). The centre throttle (cylinder 2) adjustment is fixed, this being controlled by the idle speed control stepper motor. Note that the centre reading will alter slightly as the two outer cylinders are adjusted.
 - **DO NOT** attempt to adjust the centre throttle stop screw, located below the idle stepper motor. The stop screw is set at the factory during manufacture, and must not be adjusted.
14. Using the throttle adjusters, make adjustments to the two outer cylinders until the word **'THROTTLES BALANCED'** in green text appears.




1. Adjusters

15. When balanced, stop the engine and disconnect the diagnostic tool.
16. Disconnect the fuel pressure gauge adapter and wiring extension.
17. Refit the airbox (see page 10-96).
18. Refit the fuel tank (see page 10-90).
19. Remove the exhaust extraction hoses from the silencer.
20. Refit the rider's seat (see page 16-17).

Throttle Position Sensor

Removal

1. Remove the rider's seat (see page 16-17).
2. Disconnect the battery, negative (black) lead first.
3. Remove the fuel tank (see page 10-89).
4. Remove the airbox (see page 10-95).
5. Remove the throttle body assembly (see page 10-106).
6. Release the two screws and rotate the throttle position sensor clockwise through 45° to remove it from the left hand end of the throttle body. Collect the O-ring on disassembly.



1. Throttle position sensor
2. Screws
3. O-ring

Installation

1. Fit the replacement throttle position sensor ensuring the O-ring is positioned correctly between the sensor and throttle body. Rotate the sensor through 45° anti-clockwise until the screw holes align.
2. Engage the new screws and washers supplied and part tighten such that the sensor can still be rotated.
3. Position the throttle body assembly near to its fitted position and reconnect the sensor and all other throttle body electrical connectors.
4. Reconnect the battery, positive (red) lead first.
5. Attach the Triumph diagnostic tool to the dedicated plug, refer to the Triumph Diagnostic Tool User Guide.
6. Turn the ignition to the 'ON' position.
7. On the diagnostic software navigate to and select the 'ADJUST TUNE' option.

8. At the next screen, select Throttle Position Sensor Adjust then click the 'Adjust' button.
9. On pressing the adjust button, the diagnostic tool will send a command, which drives the primary throttle to the fully closed position. The tool will also display the voltage reading coming from the throttle position sensor.

Gently rotate the new throttle position sensor until the voltage reading on the software shows 0.6 Volts +/- 0.02 Volts. The reading on the screen will turn green, indicating that the reading is correct.

Note:

- **This is a setting voltage only. Because of the adaptive nature of the engine management system, the in-service voltage may vary from this setting figure.**
10. Tighten the sensor retaining screws to **2 Nm** and recheck the voltage reading shown on the tool. Repeat the adjustment if the reading is outside the specified range.
 11. Click on the OK button to return the throttle to normal control and return the diagnostic tool to the 'ADJUST TUNE' menu.
 12. Disconnect the diagnostic tool.
 13. Check that the throttle opens and closes without obstruction/sticking and has a smooth action throughout the full range of its movement. Rectify as necessary.

Warning

Operation of the motorcycle with an incorrectly adjusted throttle position sensor, or a throttle position sensor that causes the throttle to stick could result in loss of throttle control. Loss of throttle control could result in loss of control of the motorcycle and an accident.

Warning


Operation of the motorcycle with an incorrectly adjusted, incorrectly routed or damaged throttle cable could interfere with the operation of the brakes, clutch or the throttle itself. Any of these conditions could result in loss of control of the motorcycle and an accident.

14. Disconnect the battery, negative (black) lead first.
15. Refit the throttle body assembly (see page 10-108).
16. Refit the airbox (see page 10-96).
17. Refit the fuel tank (see page 10-90).
18. Reconnect the battery, positive (red) lead first.
19. Check and clear any stored faults using the diagnostic tool, refer to the Triumph Diagnostic Tool User Guide.
20. Refit the rider's seat (see page 16-17).

Idle Speed Control Stepper Motor


Removal

1. Remove the rider's seat (see page 16-17).
2. Disconnect the battery, negative (black) lead first.
3. Remove the fuel tank (see page 10-89).
4. Remove the airbox (see page 10-95).
5. Remove the throttle bodies (see page 10-106).
6. Remove the nut, metal washer and plastic washer attaching the idle control stepper arm to the idle speed control lever.




- 1. Idle speed control lever**
2. Nut etc.

7. Remove the two screws securing the idle speed control stepper motor to its bracket, then remove the stepper motor in the direction shown.



- 1. Idle speed control stepper motor**
2. Bracket
3. Fixings
4. Direction of removal



8. Leave the plastic collar and spring on the stepper motor arm.




- 1. Collar**
2. Spring

Installation

1. Ensure the Idle speed control lever is correctly positioned in relation to the throttle cam as shown below.




2. If removed, loosely fit the spring and collar on the stepper motor arm.




1. Collar
2. Spring

3. Locate the stepper motor to its bracket and tighten the fixings to **3.5 Nm**.




1. Idle speed control stepper motor
2. Bracket
3. Fixings
4. Direction of fitting

4. Fit the plastic washer to the lever then fit the metal washer and nut.



1. Idle speed control lever
2. Nut etc.

5. Mount the throttle body onto the engine.
6. Temporarily reconnect the battery, positive (red) lead first.
7. Attach the Triumph diagnostic tool to the dedicated plug, refer to the Triumph Diagnostic Tool User Guide.
8. Turn the ignition to the 'ON' position.
9. On the diagnostic software navigate to and select the 'ADJUST TUNE' option.
10. Select Idle Speed Control Stepper Motor Adjust then click the Adjust button.
11. On pressing the adjust key, the diagnostic tool will send a command that drives the throttle to the fully closed position. The tool will also display the voltage reading coming from the throttle position sensor which should be between the target voltage range of 0.58V and 0.62V.
12. Tighten the stepper arm nut on the idle speed stepper motor until a clearance of 0.5 mm can be measured between the idle speed control cam and the throttle roller.




1. Idle speed control lever
2. Throttle roller

13. Check the voltage reading shown on the software. If the reading is between the target voltage range, then proceed to step 17. If the reading is not within this range, adjustment must be made as described in steps 14 to 16.
14. Slacken the screws on the throttle position sensor.
15. Gently turn the throttle position sensor until the voltage reading shown on the software is between the target voltage range.
16. Tighten the sensor retaining screws to **2 Nm** and recheck the voltage reading shown on the software. Repeat the adjustment if the reading is outside the specified range.
17. Click the OK button to progress to the next adjustment.

Note:

- The diagnostic software will calculate the target voltage range for when the throttle is in the fully open position.
18. On pressing the OK button, the diagnostic tool will send a command that drives the throttle to the fully open position. The tool will also display the voltage reading coming from the throttle position sensor which should be between the target voltage range calculated by the software and shown on the screen.
 19. With the stepper fully opened, check the voltage shown on the software and, if necessary, adjust the nut on the top of the stepper arm until the software shows a voltage within the target voltage range shown on the screen. The reading on the screen will change from red to green, indicating that the reading is correct.



1. Adjustment nut

20. Click the OK button to fully close the idle speed control stepper motor. After a minimum of 15 seconds (the tool will show 'Adapting' and not allow further actions to take place during this period), click the OK button again to return the ECM to normal control.



Caution

Do not operate the throttle while the stepper motor is being adjusted, otherwise the incorrect value will be adapted and the engine will not start.

21. Turn the ignition to the 'OFF' position.
22. Disconnect the diagnostic tool.
23. Disconnect the battery, negative (black) lead first.
24. Check and adjust the throttle cable settings (see page 10-103).



Warning

Move the handlebars to left and right full lock while checking that the cables and harnesses do not bind. A cable or harness which binds will restrict the steering and may cause loss of control and an accident.

25. Refit the airbox (see page 10-96).
26. Refit the fuel tank (see page 10-90).
27. Reconnect the battery, positive (red) lead first.
28. Refit the rider's seat (see page 16-17).

Engine Management Adaption

General Information

The engine management system fitted to the Daytona 675, Street Triple and Street Triple R is adaptive. This means that the system is able to learn about new or changing operating conditions and continuously adapt itself without needing to constantly make major adjustments from a fixed baseline setting.

Adaptive changes can become necessary because of changing rider behaviour, changes in the region in which the bike is operated (i.e. operation at high altitude where it was previously used at sea level) or because a new part may have been fitted which has slightly different characteristics to the old part. All adaptive changes are automatic and require no intervention by rider or dealer.

Adaption Status

To see if a motorcycle has fully adapted, a facility named 'ADAPTION STATUS' is provided on the diagnostic software. The following adaption details can be examined:

Function Examined	Report Method
Closed throttle position reference status	adapted/not adapted
Idle speed control adaption status	%
Oxygen sensor adaption status (off idle)	%
Oxygen sensor adaption range (off idle)	%
Oxygen sensor adaption status (idle)	%
Oxygen sensor adaption range (idle)	%

Terminology

Where the term 'status' is used, this indicates how far the present operating parameter is from the stored (baseline) value. The nearer these figures are to zero the better as it indicates the motorcycle has adapted to its current operating conditions.

The term 'range' indicates how much (in percentage terms) of the adjustment range has been used to reach the current operating status.

Typical Values

In a correctly adapted motorcycle, the following will be typical:

Function Examined	Read Out
Closed throttle position reference status	Yes (Adapted)
Idle speed control adaption status	Between +100 and -100%
Oxygen sensor adaption status (off idle)	0% +/- 10%
Oxygen sensor adaption range (off idle)	Between +100 and -100%
Oxygen sensor adaption status (idle)	0% +/- 10%
Oxygen sensor adaption range (idle)	Between +100 and -100%

Forcing adaption to take place

If the read out indicates that the motorcycle is not adapted, the following will force the system to make adaptations:

1. Ensure the engine is cold.
2. WITHOUT TOUCHING THE THROTTLE, start the engine and allow it to warm up until the cooling fan comes on.
3. Leave the engine to idle for a further 12 minutes.

Note:

- As an alternative to the above process, connect the diagnostic tool, select **ADJUST TUNE** (see the Triumph Diagnostic Tool User Guide) and select **RESET ADAPTIONS**. This will force a fast adaption routine to take place in around 5 seconds. For this to happen, the engine **MUST** be running, it must be at normal operating temperature and in closed loop control mode. Under any other conditions fast adaption will not take place and may cause default values to be loaded, which may then require a normal 12 minute adaption routine to be run.

Fault Indications

If 'range' figures at 100% are seen, then the adjustment has reached maximum indicating a mechanical fault exists on the motorcycle. This can be due to a number of faults but the most likely causes will be low/high fuel pressure, faulty injectors or air leaks at the throttle bodies or airbox.

In these circumstances, locate and rectify the fault, and reset the adaptations as described above.


Exhaust System - Daytona 675

Removal

Warning


If the engine has recently been running, the exhaust system will be hot. Before working on or near the exhaust system, allow sufficient time for the exhaust system to cool as touching any part of a hot exhaust system could cause burn injuries.

1. Remove the seats (see page 16-17).
2. Disconnect the battery, negative (black) lead first.
3. Remove the rear bodywork (see page 16-18).
4. Disconnect the direction indicator and licence plate lamp electrical connector.
5. Release the clamp securing the silencer to the intermediate pipe.




- cdop
1. Silencer
 2. Intermediate pipe
 3. Clamp

6. Support the silencer and release the bolt and nut securing the silencer mounting bracket to the rear frame.




1. Silencer mounting bracket fixing

7. Move the silencer rearwards to disengage it from the intermediate pipe and remove.
8. If the rear light bracket is to be removed, release the four silencer heatshield fixings and remove the two heatshields.



- cdov
1. Silencer
 2. Heatshields
 3. Fixings


9. Release the four fixings and remove the rear light bracket from the silencer.



cdow

- 1. Silencer
- 2. Rear light bracket
- 3. Fixings (left hand shown)


10. Remove the lower fairings (see page 16-20).
11. Release the clamp securing the intermediate pipe to the header pipe.



cdog

- 1. Intermediate pipe
- 2. Clamp
- 3. Header pipe


12. Disconnect the oxygen sensor from the main harness.



cdoz

- 1. Oxygen sensor


13. Remove the cover from the butterfly valve cables on the actuator.



cdpv

- 1. Cover
- 2. Fixings

14. Slacken both cable adjusters at the actuator to give the maximum amount of slack in the cables.




cdwz

- 1. Actuator
- 2. Adjusters

Fuel System/Engine Management

15. Remove and discard the actuator pulley wheel fixing.




1. Actuator pulley wheel

2. Fixing

16. Slide the actuator pulley off the actuator shaft.

17. Slide the outer portion of the cables out of the actuator.

18. Detach the inner portion of the cables from the actuator pulley wheel.




1. Actuator pulley wheel

2. Opening cable

3. Closing cable

19. Remove the radiator (see page 11-13).


20. Release the fixings securing the header pipe joints to the cylinder head. Discard the fixings.



1. Header pipes

2. Fixings

21. Remove the bolt from the header pipe rear mounting point.




1. Header pipe

2. Header pipe rear mounting point

22. Detach the header pipe assembly and collect the seals from the cylinder head ports.

23. Remove the intermediate pipe fixing and remove the intermediate pipe downwards through the swinging arm.



1. Intermediate pipe
2. Fixing

Inspection


1. Using an open ended spanner on the flats of the spindle, check that the exhaust valve in the header pipes is free to rotate and operates smoothly. If the exhaust valve is seized or does not operate smoothly, proceed as follows:
 - Spray penetrating fluid into the spindle bushes of the butterfly valve, and again using an open-ended spanner on the flats of the spindle, turn the spindle end until it rotates freely.
 - Once free, check the spindle end-float. The standard end-float is 0.5 to 1.5 mm but, if end float is less than 0.5 mm, the header pipes must be renewed.
 - Once satisfied that the valve is in a serviceable condition, refit the header pipes to the motorcycle and adjust the butterfly valve cables (see page 10-137).

Assembly

1. Refit the intermediate pipe upwards through the swinging arm and tighten the fixing to **22 Nm**.
2. Fit new seals to the cylinder head. Ensure that the face of the seal with the tab is facing the cylinder head.

Note:

- A smear of grease may be used to retain the seals in the cylinder head during assembly.



1. Cylinder head
2. Seals
3. Seal tab

3. Locate the header pipes and align the header pipe flanges to the fixing points. Fit new nuts and hand tighten.
4. Assemble the rear mounting point fixing but do not tighten at this stage.


5. Tighten the header pipe to cylinder head nuts in the sequence shown below:

Up to VIN 381274

- **Stage 1:** Tighten the header pipe nuts in sequence to **2 Nm**.
- **Stage 2:** Tighten the header pipe nuts in sequence to **19 Nm**.

From VIN 381275

- **Stage 1:** Tighten the header pipe nuts in sequence to **2 Nm**.
- **Stage 2:** Tighten the header pipe nuts in sequence to **15 Nm**.



Header Pipe Tightening Sequence


6. Tighten the rear mounting point fixing to **19 Nm**.
7. Refit the radiator and refill the cooling system (see page 11-14).
8. Connect the butterfly valve control cables and pulley wheel to the actuator (see page 10-129, from paragraph 3 to paragraph 6).
9. Adjust the butterfly valve control cables (see page 10-131, from paragraph 6 to paragraph 24).
10. Refit the oxygen sensor and tighten to **25 Nm**.



Warning

Incorrect alignment of the exhaust clamp may cause interference with the rear suspension which may lead to loss of motorcycle control and an accident.

11. Align the clamp to the intermediate to header pipe joint and tighten to **15 Nm**. Ensure the clamp is aligned as shown below.




1. Exhaust clamp position

2. Exhaust cut-out

3. Exhaust clamp alignment feature

12. If removed, refit the rear light bracket to the silencer. Tighten the fixings to **12 Nm**.
13. Refit the silencer heatshields. Tighten the fixings to **6 Nm**.
14. Position and engage the silencer to the intermediate pipe. Ensure the front of the outer (cosmetic) heatshield is located over the two rubber mounting grommets on the rear subframe.
15. Align the silencer mounting bracket to the frame. Tighten the fixing to **27 Nm**.




1. Silencer mounting bracket fixing



Warning

Incorrect alignment of the exhaust clamp may cause interference with the rear suspension which may lead to loss of motorcycle control and an accident.

16. Align the clamp to the silencer to exhaust pipe joint and tighten to **15 Nm**. Ensure the clamp is aligned as shown below.



1. Exhaust clamp position
2. Exhaust cut-out
3. Exhaust clamp alignment feature

17. Reconnect the battery, positive (red) lead first.



Caution

Do not install the exhaust system or run the engine without the exhaust heatshields fitted. Components protected by the exhaust heatshields may suffer severe damage or a fire if the motorcycle is operated without the heatshields being fitted.

18. Start the engine and check for exhaust gas leaks. Rectify if necessary.
19. Refit the lower fairings (see page 16-20).
20. Reconnect the direction indicator and licence plate lamp electrical connector.
21. Refit the rear bodywork (see page 16-18).
22. Refit the seats (see page 16-17).

Exhaust System - Street Triple and Street Triple R


Removal



Warning


If the engine has recently been running, the exhaust system will be hot. Before working on or near the exhaust system, allow sufficient time for the exhaust system to cool as touching any part of a hot exhaust system could cause burn injuries.

1. Remove the seat (see page 16-17).
2. Disconnect the battery, negative (black) lead first.
3. Remove the rear bodywork (see page 16-19).
4. Release the clamps securing the silencers to the intermediate pipe.




1. Clamp bolts
2. Intermediate pipe
3. Left hand silencer
4. Right hand silencer

5. Support the right hand silencer and release the bolt and nut securing the silencer mounting bracket to the rear frame.




1. Silencer mounting bracket fixing
2. Nut

6. Move the silencer rearwards to disengage it from the intermediate pipe and remove. If fitted, collect the spacer from the rear subframe.
7. Repeat steps 5 and 6 above for the left hand silencer.
8. Release the clamp securing the intermediate pipe to the header pipes.




1. Intermediate pipe
2. Clamp
3. Header pipes

9. Remove the intermediate pipe to rear subframe fixing.



1. Intermediate pipe fixing


10. Loosen the rear subframe lower fixings to the main frame.
11. With the aid of an assistant support the rear subframe.
12. Remove the rear subframe upper fixings to the main frame.
13. Carefully raise the rear subframe until the intermediate pipe can be released from the header pipe.
14. With the rear subframe still supported, manoeuvre the intermediate pipe until it can be removed upwards through the swinging arm, taking care not to damage the swinging arm or intermediate pipe as you do so.
15. Align the rear subframe to the frame and refit the fixings. Do not fully tighten at this stage.



1. Oxygen sensor connector

2. Retaining points


17. Remove the radiator (see page 11-15).
18. Release the fixings securing the header pipe joints to the cylinder head. Discard the fixings.



1. Header pipes

2. Fixings

19. Remove the bolt from the header pipe rear mounting point.



1. Header pipe
2. Header pipe rear mounting point


20. Detach the header pipe assembly and collect the seals from the cylinder head ports.
21. If necessary, remove the oxygen sensor cover from the header pipe and then remove the oxygen sensor.

Assembly

1. If removed, install the oxygen sensor and tighten to **25 Nm**. Install the oxygen sensor cover and secure with the fixing, tightening to **12 Nm**.
2. Fit new seals to the cylinder head. Ensure that the face of the seal with the tab is facing the cylinder head.

Note:

- A smear of grease may be used to retain the seals in the cylinder head during assembly.




1. Cylinder head
2. Seal
3. Seal tab

3. Locate the header pipes and align the header pipe flanges to the fixing points. Fit new nuts and hand tighten.

4. Assemble the rear mounting point fixing but do not tighten at this stage.
5. Tighten the header pipe to cylinder head nuts in the sequence shown below:

- **Stage 1:** Tighten the header pipe nuts to **2 Nm**.
- **Stage 2:** Tighten the header pipe nuts to **19 Nm**.



Header Pipe Tightening Sequence


6. Tighten the rear mounting point fixing to **19 Nm**.
7. Refit the radiator and refill the cooling system (see page 11-16).
8. Reconnect the oxygen sensor and secure the harness behind its retaining points as noted on disassembly.
9. With the aid of an assistant support the rear subframe.
10. Remove the rear subframe upper fixings to the main frame.
11. Carefully raise the rear subframe until the intermediate pipe can be installed.
12. With the rear subframe still supported, manoeuvre the intermediate pipe until it can be installed downwards through the swinging arm, taking care not to damage the swinging arm or intermediate pipe as you do so.
13. Position and engage the intermediate pipe to the header pipe.
14. Align the rear subframe to the frame and refit the fixings. Tighten all four subframe fixings to **48 Nm**.
15. Refit the intermediate pipe to rear subframe fixing. Tighten to **22 Nm**.



Warning


Incorrect alignment of the exhaust clamp may cause interference with the rear suspension which may lead to loss of motorcycle control and an accident.

16. Align the intermediate pipe clamp to the header pipe as shown below and tighten to **15 Nm**.



1. Intermediate pipe
2. Clamp
3. Header pipe
4. Alignment marks


17. Position and engage the right hand silencer to the intermediate pipe.
18. Refit the spacer (if removed) to silencer bolt in the rear subframe, and align the silencer mounting bracket to the spacer. Refit the nut. Tighten the fixings to **15 Nm**.



1. Silencer mounting bracket fixing
2. Nut

19. Repeat steps 17 and 18 above for the left hand silencer.

20. Align the intermediate pipe joint clamps such that the bolts are vertical as shown below, and tighten to **10 Nm**.



1. Intermediate pipe joint clamps showing bolt alignment
2. Header pipes
3. Left hand silencer
4. Right hand silencer

21. Reconnect the battery, positive (red) lead first.



Caution

Do not install the exhaust system or run the engine without the exhaust heatshields fitted. Components protected by the exhaust heatshields may suffer severe damage or a fire if the motorcycle is operated without the heatshields being fitted.

22. Start the engine and check for exhaust gas leaks. Rectify if necessary.
23. Refit the rear bodywork (see page 16-18).
24. Refit the seat (see page 16-17).

Exhaust Butterfly Valve Actuator - Daytona 675 only


Removal



Warning

If the engine has recently been running, the exhaust system will be hot. Before working on or near the exhaust system, allow sufficient time for the exhaust system to cool as touching any part of a hot exhaust system could cause burn injuries.


1. Remove the rider's seat (see page 16-17).
2. Disconnect the battery, negative (black) lead first.
3. Remove the right hand lower fairing (see page 16-20).
4. Remove the cover from the butterfly valve cables on the actuator.



cdpv

1. Cover
2. Fixings


5. Slacken both cable adjusters at the actuator to give the maximum amount of slack in the cables.



cdwz

1. Actuator
2. Adjusters

6. Remove and discard the actuator pulley wheel fixing.




cdpu

1. Actuator pulley wheel
2. Fixing

7. Slide the actuator pulley off the actuator shaft.
8. Slide the outer portion of the cables out of the actuator.


9. Detach the inner portion of the cables from the actuator pulley wheel.
11. Disconnect the electrical connector and remove the actuator.



cdps

1. Actuator pulley wheel
2. Opening cable
3. Closing cable


10. Release the two fixings and detach the actuator.



1. Actuator
2. Connector

Installation

1. Check that the exhaust valve in the header pipes is free to rotate and operates smoothly (see page 10-119).
2. Position the actuator to the motorcycle and connect the electrical connector.
3. Refit the actuator to the frame and tighten the two fixings to **12 Nm**.
4. Connect the butterfly valve control cables and pulley wheel to the actuator (see page 10-129, from paragraph 3 to paragraph 6).
5. Adjust the butterfly valve control cables (see page 10-131, from paragraph 6 to paragraph 24).
6. Refit the right hand lower fairing (see page 16-20).
7. Reconnect the battery, red (positive) lead first.
8. Refit the rider's seat (see page 16-17).



cdxc

1. Actuator
2. Fixings


Exhaust Butterfly Valve Cables - Daytona 675 only

Removal

Warning


If the engine has recently been running, the exhaust system will be hot. Before working on or near the exhaust system, allow sufficient time for the exhaust system to cool as touching any part of a hot exhaust system could cause burn injuries.

1. Remove the rider's seat (see page 16-17).
2. Disconnect the battery, negative (black) lead first.
3. Remove the right hand lower fairing (see page 16-20).
4. Remove the cover from the butterfly valve cables on the actuator.



- cdpv
1. Cover
 2. Fixings


5. Slacken both cable adjusters at the actuator to give the maximum amount of slack in the cables.



cdwz

1. Actuator
2. Adjusters


6. Remove the cover from the butterfly valve cables on the exhaust header.



cdor

1. Cover
2. Fixings


7. Remove and discard the actuator pulley wheel fixing.



cdpu

1. Actuator pulley wheel
2. Fixing

8. Slide the actuator pulley off the actuator shaft.
9. Slide the outer portion of the cables out of the actuator.
10. Detach the inner portion of the cables from the actuator pulley wheel.



cdps


1. Actuator pulley wheel
2. Opening cable
3. Closing cable

11. Slacken the adjuster locknuts at the exhaust valve end of the cables such that they will allow the outer cables to be detached from the exhaust headers.

Note:

- The adjuster/locknuts are coloured black on the upper, opening cable and silver on the lower, closing cable.

12. Noting the orientation of the cables, detach the inner cable nipples from the exhaust valve pulley wheel and remove the cables.



xdot

1. Opening cable adjuster/locknuts
2. Closing cable adjuster/locknuts
3. Opening cable nipple
4. Closing cable nipple
5. Exhaust valve pulley wheel

Inspection

1. Check that both the exhaust valve cables operate smoothly, without sticking or binding. Replace the cables if there is any doubt as to their correct operation.
2. Using an open ended spanner on the flats of the spindle, check that the exhaust valve in the header pipes is free to rotate and operates smoothly. If the exhaust valve is seized or does not operate smoothly, proceed as follows:
3. Remove the header pipes (see page 10-116).
4. Spray penetrating fluid into the spindle bushes of the butterfly valve, and again using an open-ended spanner on the flats of the spindle, turn the spindle end until it rotates freely.
5. Once free, check the spindle end-float. The standard end-float is 0.5 to 1.5 mm but, if end float is less than 0.5 mm, the header pipes must be renewed.
6. Once satisfied that the valve is in a serviceable condition, refit the header pipes to the motorcycle and adjust the butterfly valve cables (see page 10-131).


Installation

1. Insert the cable threaded ends into the exhaust headers as noted on removal, ensuring the adjuster/locknuts are positioned one on either side of the cable retainer casting on the exhaust header. Do not tighten the adjuster/locknuts at this stage.

Note:

- For identification, the adjuster/locknuts are coloured black on the upper, opening cable and silver on the lower, closing cable.


- Fit the cable nipples into the exhaust valve pulley wheel.



- Opening cable adjuster/locknuts
- Closing cable adjuster/locknuts
- Opening cable nipple
- Closing cable nipple
- Exhaust valve pulley wheel


Note:

- Where the outer cables locate into the actuator, the cable outer sleeve is coloured black on the upper, opening cable and silver on the lower, closing cable.
- Fit the inner portion of the cables to the actuator pulley wheel, ensuring the pulley wheel is installed with the fixing boss facing outwards, and the opening (black) cable uppermost.



- Actuator pulley wheel (fixing boss facing outwards)
- Opening cable
- Closing cable
- Fixing boss
- Black coating on cable outer

- Insert the outer portion of the cables into the actuator.
- Slide the actuator pulley onto the actuator shaft.
- Install a new actuator pulley wheel fixing and tighten to 5 Nm.



- Actuator pulley wheel
- Fixing


- Adjust the exhaust valve cables (see page 10-131).
- Refit the right hand lower fairing (see page 16-20).
- Reconnect the battery, red (positive) lead first.
- Refit the rider's seat (see page 16-17).

Exhaust Butterfly Valve Cable Adjustment - Daytona 675 only

Warning


If the engine has recently been running, the exhaust system will be hot. Before working on or near the exhaust system, allow sufficient time for the exhaust system to cool as touching any part of a hot exhaust system could cause burn injuries.

1. Remove the rider's seat (see page 16-17).
2. Disconnect the battery, negative (black) lead first.
3. Remove the right hand lower fairing (see page 16-20).
4. Remove the cover from the butterfly valve cables on the actuator.




1. Cover
2. Fixings

5. Slacken both cable adjusters at the actuator to give the maximum amount of slack in the cables.




1. Actuator
2. Adjusters

6. Remove the cover from the butterfly valve cables on the exhaust header.



1. Cover
2. Fixings

7. Slacken the butterfly valve cable locknuts and, using the adjuster nuts, set the distance between the end of the cables and the cable retainer casting on the exhaust header to 5 mm. Tighten the locknuts to 5 Nm.




1. Locknuts
2. Adjuster nuts

8. Reconnect the battery, red (positive) lead first.
9. Attach the Triumph diagnostic tool to the dedicated plug, refer to the Triumph Diagnostic Tool User Guide.
10. Turn the ignition to the 'ON' position.
11. On the diagnostic software navigate to and select the 'ADJUST TUNE' option.

Warning

Clicking the adjust button will cause the exhaust valve actuator to move to the adjustment position. To prevent injury, never place loose clothing, fingers or hands near the exhaust valve actuator, cables or the valve on the header pipe, until the actuator has moved to the adjustment position. Loose clothing, fingers or the hands could become trapped during valve/actuator movement and cause crushing injury to the fingers, hands or other parts of the anatomy.


12. Select Exhaust Butterfly Valve Cable Adjust then click the adjust button.
13. On clicking the adjust button, the diagnostic software will send a command, which drives the exhaust valve actuator to the middle position. The diagnostic software will then show adjust cable on the screen. Click the OK button.
14. The exhaust butterfly cables can now be adjusted as follows:
15. Turn the adjuster shown in the illustration below until the butterfly valve pulley wheel arrow is level with the lower edge of the butterfly valve 'stop' casting.



1. Butterfly valve pulley wheel arrow
2. Butterfly valve 'stop' casting
3. Adjuster


16. Turn the adjuster shown in the illustration below to remove the slack from the cables. Measure the cable slack as follows:

- Using light finger pressure, squeeze the cables together at the position shown below.




1. Cable slack measurement position

- Whilst maintaining light finger pressure, measure the distance between the two cables.
- When the cable slack is correct, the distance between the two cables should be 12 - 14 mm.



1. Adjuster
2. Correct setting, 12 - 14 mm

17. Tighten the cable adjuster locknuts.



1. Actuator
2. Adjusters
3. Locknuts

Warning

Clicking the OK button will cause the exhaust valve actuator to move to the closed position and then the fully open position. To prevent injury, never place loose clothing, fingers or hands near the exhaust valve actuator, cables or the valve on the header pipe, until the actuator has stopped. Loose clothing, fingers or the hands could become trapped during valve/actuator movement and cause crushing injury to the fingers, hands or other parts of the anatomy.


18. On the diagnostic software, click the OK button to return the actuator to normal control and return the diagnostic software to the 'ADJUST TUNE' menu.

Note:

- If the cable adjustment procedure has been correctly carried out, the exhaust valve will now be in the closed position.
 - If the adjustment is not correct, the exhaust valve will be set in the open position and the Malfunction Indicator Light (MIL) will be illuminated, indicating the presence of DTCs (Diagnostic Trouble Codes).
 - The following screen will be displayed:
19. Rectify the DTCs as necessary by repeating the adjustment procedure.
 20. On the diagnostic software, scroll to the 'DIAGNOSTICS' menu and select 'READ STORED DTCs', refer to the Triumph Diagnostic Tool User Guide. Re-check for any stored DTCs and rectify as necessary.
 21. Turn the ignition to the 'OFF' position
 22. Disconnect the Triumph diagnostic tool
 23. Refit the cover to the butterfly valve cables on the actuator. Tighten the fixings to **2 Nm**.
 24. Refit the cover to the butterfly valve cables on the exhaust header. Tighten the fixings to **12 Nm**.
 25. Refit the right hand lower fairing (see page 16-20).
 26. Refit the rider's seat (see page 16-17).

Secondary Air Injection

System Purpose and Operation



The secondary air injection system is an aid to reducing levels of pollutants in the exhaust gases. It does this by introducing a small amount of air into each exhaust port as the exhaust valve opens. The introduced air helps promote further combustion of the fuel mixture in the exhaust system after it has left the combustion chamber.


At certain specific engine speeds (determined by the factory programming of engine management system), the secondary air injection control valve is opened by the ECM and allows an air feed into the secondary air system where, each time a pair of exhaust valves open, the exhaust gases in the exhaust port create a depression which causes reed valves in the secondary air injection system to open. When open, the depression in the exhaust port draws air from the control valve, through the open reed valves, into the exhaust port. This air promotes secondary combustion of the exhaust gases in the ports and the header system.

At other engine speeds, the system is disabled by closing the control valve in the system. This allows an oxygen sensor to control air to fuel ratios. If air was fed to the exhaust system when the oxygen sensor was operational, the incoming air would cause inaccuracies in the readings sensed by the oxygen sensor (which requires access to 'raw' combustion gases) which would lead to rough running.

Secondary Air Injection Solenoid Valve

Removal

1. Remove the rider's seat (see page 16-17).
2. Disconnect the battery, negative (black) lead first.
3. Remove the fuel tank (see page 10-89).
4. Remove the airbox (see page 10-95).
5. Release the hoses attached to the valve.
6. Disconnect the multi-plug.



1. Solenoid valve
2. Retainer
3. Spring hose clips
4. Multiplug

7. Gently pull the valve to detach from the retainer.

Installation


1. Refit the hoses to the valve.
2. Locate the valve to the retainer.
3. Reconnect the multi-plug.
4. Refit the airbox (see page 10-96).
5. Refit the fuel tank (see page 10-90).
6. Reconnect the battery, positive (red) lead first.
7. Refit the rider's seat (see page 16-17).

8. Detach the valves from the camshaft cover.

Secondary Air Injection Reed Valves


Removal

1. Remove the rider's seat (see page 16-17).
2. Disconnect the battery, negative (black) lead first.
3. Remove the fuel tank (see page 10-89).
4. Remove the airbox (see page 10-95).
5. Detach the secondary air injection feed hoses from the reed valves on the camshaft cover.




1. Secondary air injection hose
2. Spring-close clip

6. Release the bolts securing the valve covers to the camshaft cover.
7. Ease the valve covers from the valves.



1. Valves



cdma


1. Reed valves

Inspection

1. Check for cracks, bending or other damage to the valve flaps. Replace as necessary.
2. Check for damage to the seal areas. Replace as necessary.
3. Check the valve body to cylinder head seal for damage.

Installation

1. Fit the reed valves to the camshaft cover.
2. Refit the valve covers and tighten the fixings to **9 Nm**.
3. Refit the secondary air injection feed hoses to the reed valves.



cdqx

1. Secondary air injection hose

2. Spring-close hose clip

4. Refit the airbox (see page 10-96).
5. Refit the fuel tank (see page 10-90).
6. Reconnect the battery, positive (red) lead first
7. Refit the rider's seat (see page 16-17).

Evaporative Emissions Control System

California Models Only

All California models are fitted with a system to control the evaporation of fuel vapour to the atmosphere.


A carbon filled canister absorbs vapour while the engine is not running. When the engine is started, the vapour is returned to the engine and burnt.

There are two distinct phases to the system's operation, engine off and engine running. These two conditions are explained overleaf.

Component Locations

Carbon Filled Canister (2) - below the swinging arm.

Purge Control Valve (3)- adjacent to frame, left hand side (electronically controlled by the ECM)




- 1. Breather hoses
- 2. Carbon filled canister
- 3. Purge valve
- 4. Purge hose to throttle bodies

Fuel System/Engine Management

Evaporative Control System - Engine Off

When the engine is stationary any pressure increase in the fuel tank due to a rise in ambient temperature will cause the fuel vapour to pass down the breather hose (1) to a carbon filled canister (2) which stores the vapour.

Once in the canister, vapour cannot enter the engine because the purge valve is closed.




- 1. Breather hoses
- 2. Carbon filled canister
- 3. Purge valve (closed)
- 4. Purge hose to throttle bodies

Evaporative Control System - Engine Off

When the engine is stationary any pressure increase in the fuel tank due to a rise in ambient temperature will cause the fuel vapour to pass down the breather hose (1) to a carbon filled canister (2) which stores the vapour.

Once in the canister, vapour cannot enter the engine because the purge valve is closed.




- 1. Breather hoses
- 2. Carbon filled canister
- 3. Purge valve (closed)
- 4. Purge hose to throttle bodies

Evaporative Control System - Engine Running

When the engine is running, engine vacuum is applied to the purge hose (4) from the throttle bodies.

At certain times, the ECM opens the purge valve. The vacuum applied to the purge hose (4) now begins to draw stored vapour from the carbon filled area of the canister and returns it to the throttle bodies for burning in the engine.

In order to control the speed at which vapour is purged from the canister, the engine management system shuttles the purge control valve between open and closed positions.



- 1. Breather hoses
- 2. Carbon filled canister
- 3. Purge valve (open under ECM control)
- 4. Purge hose to throttle bodies


11 Cooling

Table of Contents


Exploded View - Cooling System - Daytona 675	11.2
Exploded View - Cooling System - Street Triple and Street Triple R	11.3
Coolant	11.4
Radiator Hoses	11.5
Radiator and Cooling Fan	11.5
Coolant Level Inspection - Daytona 675	11.5
Coolant Level Inspection - Street Triple and Street Triple R	11.6
Coolant Replacement - Daytona 675	11.6
Drainage	11.6
Filling	11.7
Coolant Replacement - Street Triple and Street Triple R	11.8
Drainage	11.8
Filling	11.9
Water Pump	11.10
Coolant Pressure Cap	11.11
Inspection	11.11
Thermostat	11.11
Removal	11.11
Inspection	11.12
Installation	11.12
Radiator - Daytona 675	11.13
Removal	11.13
Inspection	11.14
Installation	11.14
Radiator - Street Triple and Street Triple R	11.15
Removal	11.15
Inspection	11.16
Installation	11.16

Cooling

Exploded View - Cooling System - Daytona 675



Exploded View - Cooling System - Street Triple and Street Triple R



Coolant

A permanent type of anti-freeze is installed in the cooling system when the motorcycle leaves the factory.

Models built up to VIN 331531

The coolant is coloured blue, contains a 50% solution of ethylene glycol, and has a freezing point of -35°C (-15°F).

Models built from VIN 331532

A year-round, Hybrid Organic Acid Technology (known as Hybrid OAT or HOAT) coolant is installed in the cooling system. It is coloured green, contains a 50% solution of ethylene glycol based antifreeze, and has a freezing point of -35°C (-31°F).

Note:

- HD4X Hybrid OAT coolant, as supplied by Triumph, is pre-mixed and does not need to be diluted prior to filling or topping up the cooling system.

All models

Always change the coolant at the intervals specified in the scheduled maintenance chart.



Warning

The coolant mixture contains anti-freeze and corrosion inhibitors, which both contain toxic chemicals which are harmful to the human body. Never swallow anti-freeze or any of the motorcycle coolant.



Caution

The coolant mixture contains a corrosion inhibitor which helps prevent damage to the metal surfaces inside the cooling system. Without this inhibitor, the coolant would 'attack' the metals and the resulting corrosion would cause blockages in the cooling system leading to engine overheating and damage. Always use the correct anti-freeze as specified in the owner's handbook. Never use a methanol based anti-freeze as this does not contain the required corrosion inhibition properties.



Caution

Distilled water must be used with the anti-freeze (see specification for anti-freeze) in the cooling system. If hard water is used in the system, it causes scale accumulation in the water passages, and considerably reduces the efficiency of the cooling system. Reduced cooling system efficiency may cause the engine to overheat and suffer severe damage.

Radiator Hoses

Regularly check all radiator hoses and hose clips for cracks, leaks or deterioration in accordance with the scheduled maintenance chart.

Radiator and Cooling Fan

Check the radiator fins for obstruction by insects, mud, leaves and general debris. Clean off any obstructions by hand or with a stream of low pressure water.

Warning

The cooling fan operates automatically. To prevent injury, keep hands and clothing away from the fan blades at all times.

Caution

Using high-pressure water sprays can damage the radiator fins and impair the radiator's efficiency.


Do not obstruct or deflect airflow through the radiator by installing unauthorized accessories in front of the radiator or behind the cooling fan. Interference with the radiator airflow can lead to overheating and consequent engine damage.

Coolant Level Inspection - Daytona 675

Warning

Do not remove the coolant pressure cap when the engine is hot. When the engine is hot, the coolant inside the radiator is hot and also under pressure. Contact with the pressurised coolant will cause scalds and skin damage.

1. Position the motorcycle on level ground and in an upright position.
2. The expansion tank can be viewed from the left hand side of the motorcycle, between the rear of the lower fairing and the frame. The coolant level should be between the 'MAX' and 'MIN.' marks.



1. Expansion tank
2. Expansion tank filler cap
3. 'MAX' mark
4. 'MIN.' mark

3. If the level of coolant is low, remove the cap from the expansion tank and add coolant mixture as necessary to bring the level up to the 'MAX' mark. Refit the cap.

Caution


If the coolant level is found to be low, or if coolant has to be added regularly, inspect the cooling system for coolant leaks. If necessary, pressure test the system to locate the source of the leak and rectify as necessary. Loss of coolant may cause the engine to overheat and suffer severe damage.

Coolant Level Inspection - Street Triple and Street Triple R

Warning

Do not remove the coolant pressure cap when the engine is hot. When the engine is hot, the coolant inside the radiator is hot and also under pressure. Contact with the pressurised coolant will cause scalds and skin damage.

1. Position the motorcycle on level ground and in an upright position.
2. Remove the rider's seat (see page 16-17).
3. The expansion tank is positioned between the rear subframe rails beneath the seat.



1. Expansion tank
2. Expansion tank filler cap
3. 'MAX' mark
4. 'MIN' mark

4. Check the coolant level in the expansion tank. The coolant level must be between the 'MAX' and 'MIN' marks. If the coolant is below the minimum level, the coolant level must be adjusted.
5. If the level of coolant is low, remove the cap from the expansion tank and add coolant mixture as necessary to bring the level up to the 'MAX' mark. Refit the cap.

Caution

If the coolant level is found to be low, or if coolant has to be added regularly, inspect the cooling system for coolant leaks. If necessary, pressure test the system to locate the source of the leak and rectify as necessary. Loss of coolant may cause the engine to overheat and suffer severe damage.

Coolant Replacement - Daytona 675

Drainage

Note:


- Prior to disassembly of the coolant hoses, note the orientation and position of the hose clips to help ensure that they are returned to the same positions and orientation on assembly.

1. Position the motorcycle on level ground on the sidestand.
2. Remove the rider's seat (see page 16-17).
3. Disconnect the battery, negative (black) lead first.

Warning

Do not remove the coolant pressure cap when the engine is hot. When the engine is hot, the coolant inside the radiator is hot and also under pressure. Contact with the pressurised coolant will cause scalds and skin damage.

4. Remove the lower fairings (see page 16-20).
5. Remove the coolant pressure cap on the radiator.




cdmm

Radiator Cap


6. Position a container to collect the displaced coolant.

7. Slacken the clip then release the bottom hose from the radiator and allow the coolant to drain.



1. Bottom hose


8. Remove the drain bolt from the coolant outlet tube, located next to the heat exchanger and allow the coolant to drain. Discard the sealing washer.



1. Coolant outlet tube
2. Drain bolt

Filling

9. Incorporating a new sealing washer, refit the drain bolt to the coolant outlet tube and tighten to **10 Nm**.
10. Reconnect the bottom hose and tighten the hose clip.
11. Remove the bleed screw from the right hand side of the radiator.



1. Bleed screw

12. Slowly add coolant mixture to the system, through the filler opening in the radiator, until the system is full. If the system has filled correctly and fully, there should be coolant visible through the bleed screw opening as well as in the filler opening.
13. If there is no coolant visible through the bleed screw opening, but the filler side appears to be full, attach a length of clear tubing to the bleed screw spigot and syphon coolant into the bleed screw side of the radiator.

Note:

- **A hand operated vacuum pump or similar should be used to syphon the coolant through the system.**
14. If necessary, top up the system through the filler and refit the pressure cap.
 15. Fit and tighten the bleed screw to **1.5 Nm**.
 16. With the aid of an assistant, lean the motorcycle fully over to the right hand side, and then the left hand side, to release air trapped in the cooling system. Repeat as necessary.
 17. Reconnect the battery, positive (red) lead first.
 18. Start the motorcycle and allow to run for approximately 20 to 30 seconds. Briefly raise the engine speed several times to allow any air to be expelled from the system.
 19. Stop the engine. Check and top up the coolant level as necessary.

20. With the aid of an assistant, lean the motorcycle fully over to the right hand side, and then the left hand side, to release air trapped in the cooling system.
21. Start the motorcycle. Briefly raise the engine speed several times to allow any air to be expelled from the system.
22. Allow the engine to run until the cooling fan operates.
23. Stop the motorcycle and allow the engine to cool.



Warning

Do not remove the coolant pressure cap when the engine is hot. When the engine is hot, the coolant inside the cooling system is hot and also under pressure. Contact with the pressurised coolant will cause scalds and skin damage.

24. Check and top up the coolant level as necessary.
25. Check the expansion tank level and top up if necessary.
26. Refit the rider's seat (see page 16-17).
27. Refit the lower fairings (see page 16-22).

Coolant Replacement - Street Triple and Street Triple R

Drainage

Note:

- Prior to disassembly of the coolant hoses, note the orientation and position of the hose clips to help ensure that they are returned to the same positions and orientation on assembly.


1. Position the motorcycle on level ground on the sidestand.
2. Remove the rider's seat (see page 16-17).
3. Disconnect the battery, negative (black) lead first.



Warning

Do not remove the coolant pressure cap when the engine is hot. When the engine is hot, the coolant inside the radiator is hot and also under pressure. Contact with the pressurised coolant will cause scalds and skin damage.

4. Release the fixing securing the right hand direction indicator to the radiator cowl.
5. Release the three fixings securing the radiator cowl to the radiator.




1. Radiator cowl

2. Direction indicator fixing


3. Fixings

6. Without disconnecting the direction indicator connections, tie the radiator cowl aside. Do not allow the radiator cowl to hang from the direction indicator harness.
7. Repeat steps 4 to 6 above for the left hand radiator cowl.


8. Remove the coolant pressure cap on the radiator.



9. Position a container to collect the displaced coolant.
10. Slacken the clip then release the bottom hose from the radiator and allow the coolant to drain.




11. Remove the drain bolt from the coolant outlet tube, located next to the heat exchanger and allow the coolant to drain. Discard the sealing washer.




Filling

1. Incorporating a new sealing washer, refit the drain bolt to the coolant outlet tube and tighten to **10 Nm**.
2. Reconnect the bottom hose and tighten the hose clip.
3. Remove the bleed screw from the right hand side of the radiator.



4. Remove the bleed screw from the top hose.



5. Slowly add coolant mixture to the system, through the filler opening in the radiator, until the system is full. If the system has filled correctly and fully, there should be coolant visible through the bleed screw opening as well as in the filler opening.
6. If there is no coolant visible through the bleed screw opening, but the filler side appears to be full, attach a length of clear tubing to the bleed screw spigot and syphon coolant into the bleed screw side of the radiator.

Note:

- A hand operated vacuum pump or similar should be used to syphon the coolant through the system.

7. If necessary, top up the system through the filler and refit the pressure cap.
8. Fit the radiator and top hose bleed screws, and tighten to **1 Nm**.
9. With the aid of an assistant, lean the motorcycle fully over to the right hand side, and then the left hand side, to release air trapped in the cooling system. Repeat as necessary.
10. Reconnect the battery, positive (red) lead first.
11. Start the motorcycle and allow to run for approximately 20 to 30 seconds. Briefly raise the engine speed several times to allow any air to be expelled from the system.
12. Stop the engine. Check and top up the coolant level as necessary.
13. With the aid of an assistant, lean the motorcycle fully over to the right hand side, and then the left hand side, to release air trapped in the cooling system.
14. Start the motorcycle. Briefly raise the engine speed several times to allow any air to be expelled from the system.
15. Allow the engine to run until the cooling fan operates.
16. Stop the motorcycle and allow the engine to cool.



Warning

Do not remove the coolant pressure cap when the engine is hot. When the engine is hot, the coolant inside the cooling system is hot and also under pressure. Contact with the pressurised coolant will cause scalds and skin damage.

17. Check and top up the coolant level as necessary.
18. Reposition the right hand radiator cowl and direction indicator to the radiator.
19. Install the three radiator cowl fixings and the direction indicator fixing and tighten as follows:
 - Tighten the radiator cowl fixings to **5 Nm**.
 - Tighten the direction indicator fixing to **4 Nm**.
20. Repeat steps 18 and 19 above for the left hand radiator cowl.
21. Check the expansion tank level and top up if necessary.
22. Refit the rider's seat (see page 16-17).

Water Pump

Note:

- The oil pump and water pump are supplied as an assembly and cannot be separated. For additional information, refer to Oil Pump (see page 8-9 for removal and page 8-13 for installation).


Coolant Pressure Cap

Inspection

Warning

Do not remove the coolant pressure cap when the engine is hot. When the engine is hot, the coolant inside the radiator is hot and also under pressure. Contact with the pressurised coolant will cause scalds and skin damage.

1. Check the condition of the upper and lower seals of the coolant pressure cap.



cawr

1. Lower seal
2. Upper seal
3. Spring

Note:

- If there is any sign of damage or deterioration replace the cap.
2. Pressure test the cap to the blow off pressure of 1.1 bar. If the cap opens at a lower pressure or fails to open at 1.1 bar, replace the cap.

Thermostat

Removal

Note:


- Prior to disassembly of the coolant hoses, note the orientation and position of the hose clips to help ensure that they are returned to the same positions and orientation on assembly.

1. Remove the rider's seat (see page 16-17).
2. Disconnect the battery, negative (black) lead first.
3. Drain the coolant (see page 11-6 for Daytona 675 or page 11-8 for Street Triple and Street Triple R).
4. Remove the fuel tank (see page 10-89).
5. Remove the airbox (see page 10-95).
6. Remove the throttle bodies (see page 10-106).

Warning

Do not remove the coolant pressure cap when the engine is hot. When the engine is hot, the coolant inside the radiator is hot and also under pressure. Contact with the pressurised coolant will cause scalds and skin damage.


7. Detach the top hose from the thermostat elbow.
8. Release the fixings securing the thermostat elbow to the cylinder head.
9. Remove the thermostat housing. Discard the O-ring.




1. Thermostat housing
2. Fixings

10. Remove the thermostat from the cylinder head.

2. Fit a new O-ring to the thermostat elbow groove.



1. Thermostat
2. Bleed valve



cash

1. O-ring groove


3. Tighten the fixings to **9 Nm**.
4. Reconnect the top hose and tighten the clip.
5. Refit the throttle bodies (see page 10-108).
6. Refit the airbox (see page 10-96).
7. Refit the fuel tank (see page 10-90).
8. Reconnect the battery positive (red) lead first.
9. Refit the rider's seat (see page 16-17).
10. Refill the cooling system (see page 11-7 for Daytona 675 or page 11-9 for Street Triple and Street Triple R).

Inspection

1. Inspect the thermostat at room temperature. If the valve is open, the thermostat must be replaced.
2. To check the valve opening temperature, suspend the thermostat in a container of water and raise the temperature of the water until the thermostat opens. The thermostat should start to open at 71°C +/- 5°C.
3. If the temperature at which thermostat opening takes place is incorrect, replace the thermostat.

Installation

1. Locate the thermostat into the cylinder head. Ensure the bleed valve is uppermost as shown below.



1. Thermostat
2. Bleed valve


Radiator - Daytona 675

Removal

Note:

- Prior to disassembly of the coolant hoses, note the orientation and position of the hose clips to help ensure that they are returned to the same positions and orientation on assembly.

1. Remove the rider's seat (see page 16-17).
2. Disconnect the battery, negative (black) lead first.
3. Remove the lower fairings (see page 16-20).
4. Detach the vacuum reservoir and hose from the radiator and position aside.




1. Vacuum reservoir
2. Fixing

Warning

Do not remove the coolant pressure cap when the engine is hot. When the engine is hot, the coolant inside the radiator is hot and also under pressure. Contact with the pressurised coolant will cause scalds and skin damage.


5. Drain the coolant (see page 11-6).

6. Disconnect the top hose and bypass hose at the radiator.



1. Top hose
2. Bypass hose


7. Disconnect the heat exchanger hose from the radiator.
8. Release the radiator lower mounting.



1. Heat exchanger hose
2. Radiator lower mount fixing

9. Disconnect the cooling fan connection from above the camshaft cover.

10. Release the bolts securing the radiator to the frame.



1. Radiator to frame bolts

11. Remove the radiator.

Inspection

1. Check the radiator for stone damage.
2. Check the radiator core for damage to the fins or obstructions to air flow.
3. Repair any damage and clear all obstructions.




Caution

To avoid overheating and consequent engine damage, replace the radiator if the cores are blocked or if the fins are badly deformed or broken.

4. Check that the fan spins freely and without tight spots.
5. Check the fan blades for signs of heat distortion.

Installation

1. Align the radiator to the frame and lower mounting. Fit the upper mounting bolts and nuts. Tighten the left hand bolt to **12 Nm**, and the right hand bolt to **6 Nm**.
2. Fit and tighten the lower mounting bolt to **3 Nm**.
3. Reconnect the cooling fan.
4. Reconnect the bypass, heat exchanger, top and bottom hoses. Tighten the hose clips, ensuring they are repositioned as noted prior to disassembly.
5. Refit the vacuum reservoir and hose to the radiator and tighten the fixing to **6 Nm**.



1. Vacuum reservoir

2. Fixing

6. Reconnect the battery, positive (red) lead first.
7. Refit the rider's seat (see page 16-17).
8. Refit the lower fairings (see page 16-22).
9. Refill the cooling system (see page 11-7).

Radiator - Street Triple and Street Triple R

Removal

Note:

- Prior to disassembly of the coolant hoses, note the orientation and position of the hose clips to help ensure that they are returned to the same positions and orientation on assembly.


1. Remove the rider's seat (see page 16-17).
2. Disconnect the battery, negative (black) lead first.



Warning


Do not remove the coolant pressure cap when the engine is hot. When the engine is hot, the coolant inside the radiator is hot and also under pressure. Contact with the pressurised coolant will cause scalds and skin damage.

3. Drain the coolant (see page 11-8).
4. Disconnect the two horn electrical connectors.




1. Horn connectors

5. Disconnect the top hose and bypass hose at the radiator.



1. Top hose
2. Bypass hose


6. Disconnect the heat exchanger hose from the radiator.
7. Release the radiator lower mounting.



1. Heat exchanger hose
2. Radiator lower mount fixing

8. Disconnect the cooling fan connection, located above the camshaft cover.

9. Release the fixings securing the radiator to the frame.



1. Radiator to frame fixings

10. Remove the radiator.

Inspection

1. Check the radiator for stone damage.
2. Check the radiator core for damage to the fins or obstructions to air flow.
3. Repair any damage and clear all obstructions.



Caution

To avoid overheating and consequent engine damage, replace the radiator if the cores are blocked or if the fins are badly deformed or broken.

4. Check that the fan spins freely and without tight spots.
5. Check the fan blades for signs of heat distortion.

Installation

1. Align the radiator to the frame and lower mounting. Fit the upper mounting bolts and nuts. Tighten the left hand bolt to **12 Nm**, and the right hand bolt to **6 Nm**.
2. Fit and tighten the lower mounting bolt to **3 Nm**.
3. Reconnect the cooling fan.
4. Reconnect the bypass, heat exchanger, top and bottom hoses. Tighten the hose clips, ensuring they are repositioned as noted prior to disassembly.
5. Reconnect the battery, positive (red) lead first.
6. Refit the rider's seat (see page 16-17).
7. Refill the cooling system (see page 11-9).
8. Refit the radiator cowls (see page 16-25).

12 Rear Suspension


Table of Contents

Exploded View - Swinging Arm	12.2
Exploded View - Rear Hub and Wheel	12.3
Exploded View - Rear Suspension Unit - Daytona 675 and Street Triple R	12.4
Exploded View - Rear Suspension Unit - Street Triple	12.5
Exploded View - Drop/Drag Link	12.6
Drive Chain	12.7
Chain Lubrication	12.7
Chain Adjustment	12.7
Chain Free-movement Inspection	12.7
Chain Free-movement adjustment	12.8
Chain Wear Inspection	12.8
Rear Suspension Unit	12.9
Removal	12.9
Inspection	12.10
Installation	12.10
Drag Link	12.11
Removal	12.11
Inspection	12.12
Installation	12.12
Swinging Arm	12.12
Removal	12.12
Inspection	12.14
Assembly	12.14
Drive Chain Replacement	12.15
Rivet link type	12.15

Exploded View - Swinging Arm




Exploded View - Rear Hub and Wheel




Rear Suspension

Exploded View - Rear Suspension Unit - Daytona 675 and Street Triple R




Exploded View - Rear Suspension Unit - Street Triple



Rear Suspension

Exploded View - Drop/Drag Link



Drive Chain

For safety and to prevent excessive wear, the drive chain must be checked, adjusted and lubricated in accordance with scheduled maintenance requirements. Checking, adjustment and lubrication must be carried out more frequently for extreme conditions such as salty or heavily gritted roads.

If the chain is badly worn or incorrectly adjusted (either too loose or too tight) the chain could jump off the sprockets or break.



Warning

A chain that breaks or jumps off the sprockets could snag on the engine sprocket or lock the rear wheel, severely damaging the motorcycle and causing an accident. Never neglect chain maintenance.

Note:

- Lubrication of the drive chain should ideally be carried out with the motorcycle set up so that the rear suspension hangs free.
- The chain must be adjusted with the motorcycle in an upright position, resting on its wheels, and with no additional weight on it.

Chain Lubrication

Lubrication is necessary every 200 miles (300 Km) and also after riding in wet weather, on wet roads, or any time that the chain appears dry.

Use the special chain lubricant as recommended in the specification section.

Correct application is critical for chain lubrication. Apply the lubricant for one full chain revolution only, then leave for eight hours before riding. This allows the lubricant's solvent (used to thin the oil) to evaporate and the oil to 'soak' into all parts of the chain. If the lubricant is applied and the motorcycle is ridden shortly afterwards, the lubricant is unlikely to reach all parts and the majority will be flung off and wasted. Applying excessive amounts is not helpful under any circumstances.

It should be noted that the lubricant is applied to the chain to lubricate its action across the sprockets. In an O-ring chain, external lubrication does not penetrate to the bushes and rollers as the O-ring seals prevents this from happening.




Caution

Do not use a power 'jet' wash to clean the chain as this may cause damage to the chain components.

Chain Adjustment

Chain Free-movement Inspection



cdkv

1. Maximum movement position



Warning


Before starting work, ensure the motorcycle is stabilised and adequately supported. This will help prevent it from falling and causing injury to the operator or damage to the motorcycle.

1. Place the motorcycle on a level surface and hold it in an upright position with no weight on it.
2. Rotate the rear wheel by pushing the motorcycle to find the position where the chain has least slack. Measure the chain's vertical movement, mid-way between sprockets.
3. If correct, the vertical movement of the drive chain midway between the sprockets should be:
 - 24 - 30 mm for the Daytona 675;
 - 13 - 32 mm for the Street Triple and Street Triple R.

Rear Suspension

Chain Free-movement adjustment

1. Loosen the wheel spindle nut.
2. Release the locknuts on both the left hand and right hand chain adjuster bolts.



1. Adjuster bolt locknut
2. Adjuster bolt
3. Rear wheel spindle nut

3. Moving both adjusters by an equal amount, turn the adjuster bolts clockwise to increase chain free movement and counter clockwise to reduce chain free movement.
4. When the correct amount of chain free movement has been set, push the wheel into firm contact with the adjusters.

Note:

- Check for equal adjustment on both sides using the graduation marks on the swinging arm.
5. Tighten both adjuster locknuts to **20 Nm** and the rear wheel spindle nut to **110 Nm**.
 6. Repeat the chain adjustment check. Re-adjust if necessary.

Warning


Operation of the motorcycle with insecure adjuster locknuts or a loose wheel spindle may result in impaired stability and handling of the motorcycle. This impaired stability and handling may lead to loss of motorcycle control and an accident.

7. Check the rear brake effectiveness. Rectify if necessary.

Warning

It is dangerous to operate the motorcycle with defective brakes; you must have your authorised Triumph dealer take remedial action before you attempt to ride the motorcycle again. Failure to take remedial action may reduce braking efficiency leading to loss of motorcycle control and an accident.

Chain Wear Inspection



1. Measurement across 20 links
2. 10-20kg Weight

Warning


Before starting work, ensure the motorcycle is stabilised and adequately supported. This will help prevent it from falling and causing injury to the operator or damage to the motorcycle.

1. Remove the chain guard from the swinging arm.
2. Stretch the chain taut by hanging a 10-20 kg (20-40 lb) weight on the chain.
3. Measure a length of 20 links on the straight part of the chain from pin centre of the 1st pin to pin centre of the 21st pin. Repeat the test at various sections of the chain to establish an average reading. This is because the chain may wear unevenly.
4. If the length exceeds the service limit of 319 mm (12.56 in), the chain must be replaced.

Warning

A chain that breaks or jumps off the sprockets could snag on the engine sprocket or lock the rear wheel, severely damaging the motorcycle and causing loss of control and an accident.

5. Examine the whole length of the chain. If there are any excessively tight or loose sections, loose pins or damaged rollers, the chain should be replaced.
6. Inspect sprockets for unevenly or excessively worn teeth. Also examine the sprockets for damaged teeth.



Note:

- Sprocket wear is exaggerated for illustration purposes.

Warning

The use of non-approved chains may result in a broken chain or may cause the chain to jump off the sprockets. Use a genuine Triumph supplied chain as specified in the Triumph Parts Catalogue. Never neglect chain maintenance and always have chains installed by an authorised Triumph dealer.

7. If there is any irregularity found in any of the components, replace the drive chain and/or any other damaged components.
8. Refit the chain guard, tightening the fixings to **9 Nm**.

Rear Suspension Unit

Removal

Warning

If the engine has recently been running, the exhaust system will be hot. Before working on or near the exhaust system, allow sufficient time for the exhaust system to cool as touching any part of a hot exhaust system could cause burn injuries.

Warning


Before starting work, ensure the motorcycle is stabilised and adequately supported. This will help prevent it from falling and causing injury to the operator or damage to the motorcycle.

1. Raise and support the rear of the motorcycle under the frame or engine. Position a block to support the rear wheel.
2. Remove the seats (see page 16-17).
3. Disconnect the battery, negative (black) lead first.
4. Remove the rear panel(s) (see page 16-18 for Daytona 675 or page 16-19 for Street Triple and Street Triple R).
5. **Daytona 675 only:** Remove the lower fairings (see page 16-20).
6. Remove the exhaust system (see page 10-116 for Daytona 675 or page 10-122 for Street Triple and Street Triple R).
7. Remove the three drop link plate fixings. Discard the nuts.

Rear Suspension

Note:

- Both drop link plates are marked as shown below. Both plates are identical, and must be fitted with the bolt hole markings facing the right hand side of the motorcycle.




1. Swinging arm bolt position

2. Rear suspension bolt position

3. Drag link bolt position

8. Noting the orientation of the drop link plates, remove the plates and position the drag link clear.



1. Rear suspension unit

2. Drag link

3. Drop link

4. Fixings



Warning

Never attempt to disassemble the rear suspension unit or reservoir. It contains fluid under pressure and serious injury could result if any part of the system is disturbed.

9. Remove the rear suspension unit upper mounting nut and bolt, and manoeuvre the unit upwards through the swinging arm and clear of the motorcycle.

Inspection


- Clean all components and inspect for damage/wear to:
 - rear suspension unit upper and lower mountings,
 - lower mounting spacer, bearing and seals,
 - drop link bearings, sleeves and seals.
- Renew as necessary.
- Check the swinging arm drop link bearing for wear. Overhaul as necessary.
- Check the drag link bearings for wear. Overhaul as necessary (see page 12-12).
- Inspect the unit for damage and fluid leaks. If there is any damage, or fluid leaks are evident, the unit must be replaced.

Installation

- Remove the drag link sleeve and pack the bearing with fresh grease. Refit the sleeve.
- Remove the rear suspension lower sleeve and pack the bearing with fresh grease. Refit the sleeve.
- Remove the swinging arm drop link sleeve and pack the bearing with fresh grease. Refit the sleeve.
- Refit the rear suspension unit to the motorcycle by lowering the unit downwards through the hole in the swinging arm.
- Locate the rear suspension unit and loosely fit the upper mounting bolt and a new nut.

Note:

- The drop link plates are marked as shown below. Both plates are identical, and must be fitted with the bolt hole markings facing the right hand side of the motorcycle.




1. Swinging arm bolt position

2. Rear suspension bolt position

3. Drag link bolt position

6. Locate the drop link plates and, from the right hand side, loosely fit the bolts and new nuts.



1. Rear suspension unit
2. Drop link plate
3. Drag link
4. Fixings

7. Tighten the three drop link fixings to **48 Nm**.
8. With the weight of the motorcycle on its wheels, tighten the rear suspension unit upper mounting to **48 Nm**.
9. Refit the exhaust system (see page 10-119 for Daytona 675 or page 10-124 for Street Triple and Street Triple R).
10. **Daytona 675 only:** Refit the lower fairings (see page 16-22).
11. Fit the rear panel(s) (see page 16-18 for Daytona 675 or page 16-25 for Street Triple and Street Triple R).
12. Connect the battery, red (positive) lead first.
13. Fit the seats (see page 16-17).

Drag Link

Removal


Warning

If the engine has recently been running, the exhaust system will be hot. Before working on or near the exhaust system, allow sufficient time for the exhaust system to cool as touching any part of a hot exhaust system could cause burn injuries.

Warning

Before starting work, ensure the motorcycle is stabilised and adequately supported. This will help prevent it from falling and causing injury to the operator or damage to the motorcycle.

1. Raise and support the rear of the motorcycle beneath the frame or engine. Position a block to support the rear wheel.
2. Remove the seats (see page 16-17).
3. Disconnect the battery, negative (black) lead first.
4. Remove the rear panel(s) (see page 16-18 for Daytona 675 or page 16-19 for Street Triple and Street Triple R).
5. **Daytona 675 only:** Remove the lower fairings (see page 16-20).
6. Remove the exhaust system (see page 10-116 for Daytona 675 or page 10-122 for Street Triple and Street Triple R).
7. Remove the two fixings securing the drag link.
8. Remove the drag link.



1. Drag link
2. Fixings

Inspection

1. Clean all components and inspect the drag link and bearings for damage/wear.
2. Check the rear suspension unit lower bearings for wear.
3. Check the drop link upper bearings for wear.
4. Renew as necessary.

Installation

1. Remove the drag link sleeves and pack the bearings with fresh grease. Refit the sleeves.
2. Refit the drag link, fit the bolts and new nuts, and tighten to **48 Nm**.
3. Refit the exhaust system (see page 10-119 for Daytona 675 or page 10-124 for Street Triple and Street Triple R).
4. **Daytona 675 only:** Refit the lower fairings (see page 16-22).
5. Fit the rear panel(s) (see page 16-18 for Daytona 675 or page 16-25 for Street Triple) and Street Triple R.
6. Connect the battery, red (positive) lead first.
7. Fit the seats (see page 16-17).

Swinging Arm

Removal

Warning

If the engine has recently been running, the exhaust system will be hot. Before working on or near the exhaust system, allow sufficient time for the exhaust system to cool as touching any part of a hot exhaust system could cause burn injuries.

Warning


Before starting work, ensure the motorcycle is stabilised and adequately supported. This will help prevent it from falling and causing injury to the operator or damage to the motorcycle.

1. Remove the seats (see page 16-17).
2. Disconnect the battery, negative (black) lead first.
3. Remove the rear panel(s) (see page 16-18 for Daytona 675 or page 16-19 for Street Triple and Street Triple R).
4. **Daytona 675 only:** Remove the lower fairings (see page 16-20).
5. Remove the exhaust system (see page 10-116 for Daytona 675 or page 10-122 for Street Triple and Street Triple R).
6. Remove the rear wheel (see page 15-8).
7. Support the swinging arm and remove the rear suspension unit (see page 12-9).
8. Remove the sprocket cover.
9. Detach the chain from the output sprocket.

Warning

Do not allow the caliper to hang on the brake hose as this may damage the hose and could lead to an accident.


10. Release the brake hose clips from the swinging arm and tie the rear brake caliper to one side.



cdtl

1. Rear brake hose clips


11. Remove and discard the swinging arm spindle nut.
12. Partially withdraw the swinging arm spindle from the right hand side, to allow access to the frame adjuster sleeve located on the left hand side of the frame.



1. Swinging arm
2. Spindle

cdqg

13. Engage tool T3880104 in the slots of the frame adjuster sleeve and rotate anti-clockwise to slacken the sleeve fully.



cdqf


1. Frame adjuster sleeve

2. Tool T3880104

14. Withdraw the swinging arm spindle from the right hand side and remove the swinging arm, together with the drive chain.

- Support the drive chain while the swinging arm is being removed to protect it from contamination.
- If the swinging arm is to be replaced remove the drive chain (see page 12-15).

15. Remove the bearing sleeves from both sides.
16. Remove the right hand bearing by drifting through from the left.
17. Collect the spacer tube.



1. Frame adjuster sleeve
2. Sleeve
3. Seal
4. Needle roller bearing
5. Spacer tube
6. Ball Bearing
7. Circlip
8. Seal
9. Spacer

Note:

- **The needle roller bearing in the left hand side of the arm cannot be removed undamaged.**


18. Remove the drive chain rubbing strip.

Inspection

1. Check all swinging arm bearings for damage, pitting, and cracks. Replace as necessary.
2. Check the swinging arm for damage. Replace as necessary.
3. Check the wheel bearings for damage, pitting, and cracks. Replace as necessary.
4. Check all bearing seals for damage, splits etc. Replace as necessary.
5. Check the chain for wear, damage etc. Replace as necessary.
6. Check both sprockets for wear, damage etc. Replace as necessary.
7. Check the drive chain rubbing strip for wear and damage. Replace as necessary.

Assembly

1. Install the bearings (marked faces outwards), sleeves etc. into the swinging arm in the order shown on the previous page. Use new seals throughout.
2. Fit the drive chain rubbing strip and tighten the fixing to **9 Nm**.
3. Fit the drive chain to the swinging arm (see page 12-15).
4. Position the swinging arm to the frame ensuring the drive chain is in position on the rubbing strip.
5. Refit the swinging arm spindle from the right hand side such that it will support the swinging arm, but not pass all the way through the frame adjuster sleeve. This will allow tool T3880104 to engage in the slot in the frame adjuster sleeve.
6. Using tool T3880104, tighten the frame adjuster sleeve to **6 Nm**.




1. Frame adjuster

2. Tool T3880104

7. Fully insert the swinging arm spindle.
8. Fit a new swinging arm spindle nut and tighten to **110 Nm**.
9. Fit the drive chain to the output sprocket.
10. Refit the sprocket cover and tighten the bolts to **9 Nm**.

11. Release the caliper and refit the rear brake hose clips to the swinging arm. Tighten the fixings to **6 Nm**.



1. Rear brake hose clips

12. Refit the rear suspension unit (see page 12-10).
13. Refit the rear wheel (see page 15-8).
14. Refit the exhaust system (see page 10-119 for Daytona 675 or page 10-124 for Street Triple and Street Triple R).
15. **Daytona 675 only:** Refit the lower fairings (see page 16-22).
16. Fit the rear panel(s) (see page 16-18 for Daytona 675 or page 16-25 for Street Triple and Street Triple R).
17. Connect the battery, red (positive) lead first.
18. Fit the seats (see page 16-17).
19. Pump the rear brake pedal several times to position the brake pads in the caliper. Rectify as necessary if correct brake operation is not restored (see page 14-39).

! Warning

It is dangerous to operate the motorcycle with defective brakes; you must have your authorised Triumph dealer take remedial action before you ride the motorcycle again. Failure to take remedial action may result in reduced braking efficiency leading to loss of motorcycle control and an accident.

Drive Chain Replacement


Rivet link type

As the drive chain passes through the swinging arm casting, the chain must be split for removal from the motorcycle. Removal of the swinging arm is not required for drive chain replacement. The following instructions for the replacement of rivet link type drive chains requires the use of service tool T3880027.

! Warning

Before starting work, ensure the motorcycle is stabilised and adequately supported. This will help prevent it from falling and causing injury to the operator or damage to the motorcycle.


1. Support the motorcycle on a stand so the rear wheel is clear of the ground.
2. Insert the hollow chain cutting tail piece into the tool body so its larger diameter end is facing towards the large pressure screw as shown.



1. Tool T3880027
2. Large pressure screw
3. Chain cutting tail piece


Rear Suspension

3. Position the chain to the tool ensuring that the chain link pin which is to be removed is aligned with the holes in the chain cutting tail piece and the large pressure screw. Tighten the large pressure screw by hand to grip the chain.



1. Tool T3880027
2. Large pressure screw
3. Chain
4. Chain cutting tail piece

4. Insert the small pressure screw into the larger pressure screw as shown below, until the cutting pin on the small pressure screw contacts the link pin. Ensure that the cutting pin is centralised on the link pin to be removed.



1. Tool T3880027
2. Small pressure screw

5. Retain the tool body then tighten the small pressure screw until the link pin is pressed out from the chain.
6. Repeat steps 3 to 5 on the remaining chain link pin.
7. Remove the tool and separate the two ends of the chain.
8. Remove the chain cutting tail piece from the body.

Note:

- The replacement chain is supplied in a split condition, complete with a link kit to join the two ends.




Caution

The component parts of the new link kit are coated with a special grease which must not be removed. Removal of this special grease will severely reduce the service life of the chain.

9. Use the old drive chain to pull the new chain into position as follows: Temporarily attach the end of the new chain to a free end of the old chain using the old connector link. Carefully pull the other end of the old chain to pull the new chain around the sprockets.

Note:

- Do not use the new connector link as the special grease on it may be removed.
10. Using the new link supplied with the chain kit, join the two ends of the chain. Ensure that the O-rings are positioned as shown below and the link plate is fitted with its markings facing outwards.




1. O-rings
2. Link
3. Link plate

11. Insert the riveting tail piece into the tool body so its larger diameter end is facing towards the large pressure screw as shown.

Note:


- Tool T3880027 includes two link plate holders, one is for riveted link plates (marked PH5060R), the other is for link plates retained by a spring clip (marked PH4060C). The holder for riveted link plates has a shallow groove to allow for chain link clearance, the holder for clipped link plates has a deep groove to allow for chain link clearance.

12. Insert the link plate holder (marked PH5060R) into the large pressure screw.




1. Tool body
2. Large pressure screw
3. Link plate holder (marked PH5060R)
4. Riveting tail piece

13. Position the tool to the chain. Ensure the link plate holder is correctly located in the large pressure screw.




1. Tool body
2. Link plate holder (marked PH5060R)
3. Link plate
4. Link
5. Large pressure screw

14. Locate the split link pins such that the pins will enter the groove in the link plate holder when the link plate is pressed on to the link.



1. Link plate holder
2. Link plate
3. Chain link
4. Link plate holder groove

15. Retain the tool body and tighten the large pressure screw until the link plate is pressed fully onto the link.
16. Back off the pressure screw, slide the tool assembly to one side and check that the split link is correctly assembled.
17. Remove the link plate holder from the tool. Do not remove the riveting tail piece from the tool.
18. Insert the flare pin into the large pressure screw.




1. Tool body
2. Large pressure screw
3. Riveting tail piece
4. Flare pin

19. Locate one of the split link pins into the riveting tail piece and screw the large pressure screw in until the flare pin contacts the split link end. Ensure the split link pin is centrally located on the flare pin.


Rear Suspension

20. Retain the tool body and tighten the large pressure screw until the split link end is riveted-over.
22. Remove the tool from the chain and check that both the split link pins are correctly riveted as shown below.



1. Tool body
2. Large pressure screw
3. Flare pin

21. Back off the large pressure screw and rivet the remaining split link pin as described above.



1. Correct riveting
2. Insufficient riveting
3. Excessive riveting
4. Riveting off-centre



Warning

If either split link pin is not correctly riveted, the split link must be removed and replaced with a new link. Never operate the motorcycle with an incorrectly riveted split link as the link could fail resulting in an unsafe riding condition leading to loss of control and an accident.


13 Front Suspension

Table of Contents


Exploded View - Front Fork - Daytona 675 and Street Triple R	13.2
Exploded View - Handlebars - Daytona 675	13.3
Exploded View - Front Fork - Street Triple	13.4
Exploded View - Handlebars - Street Triple and Street Triple R	13.5
Front Suspension	13.6
Fork Inspection	13.6
Front Fork	13.6
Removal	13.6
Installation	13.8
Fork Oil Change	13.8
Draining	13.8
Oil Refilling	13.8
Fork Oil Level Chart	13.9
Front Fork	13.10
Disassembly	13.10
Inspection	13.12
Assembly	13.13
Headstock Bearing Check/Adjustment	13.15
Check	13.15
Adjustment - Daytona 675	13.16
Adjustment - Street Triple and Street Triple R	13.17
Headstock Bearing Removal	13.19
Inspection	13.19
Installation	13.20
Steering Damper - Daytona 675 only	13.21
Removal	13.21
Installation	13.21
Handlebars - Daytona 675	13.22
Removal	13.22
Installation	13.24
Handlebars - Street Triple and Street Triple R	13.25
Removal	13.25
Installation	13.26

Front Suspension


Exploded View - Front Fork - Daytona 675 and Street Triple R




Exploded View - Handlebars - Daytona 675




Exploded View - Front Fork - Street Triple



Exploded View - Handlebars - Daytona 675



Exploded View - Front Fork - Street Triple



Front Suspension

The Daytona 675 and Street Triple R are equipped with hydraulic, adjustable, telescopic front forks. Both forks are adjustable for spring pre-load, compression damping and rebound damping. From VIN 3 the Daytona 675 front forks have low stroke speed and high stroke speed compression damping adjusters.

The Street Triple is equipped with hydraulic, telescopic front forks. The Street Triple front suspension has no adjustments.

Periodic inspection for damage and fluid leaks is essential for safe riding. Always follow the inspection instructions at the intervals stated in the scheduled maintenance chart.

On Daytona 675, a hydraulic, non-adjustable, steering damper is fitted beneath the lower yoke. The damper rod is attached to the frame via a bracket above the radiator.

Fork Inspection

Examine each fork for any sign of damage or scratching of the slider surface or for oil leaks.

If any damage or oil leakage is found, strip and repair as described in this section or consult an authorised Triumph dealer.

Check for smooth operation of the forks as follows:

- Place the motorcycle on level ground.
- While holding the handlebars and applying the front brake, pump the forks up and down several times.

If roughness or excessive stiffness is detected, repair as described in this section or consult an authorised Triumph dealer.

Warning

Riding the motorcycle with defective or damaged suspension can cause loss of motorcycle control and an accident. Never ride with damaged or defective suspension.


Front Fork

Removal

Warning

Before starting work, ensure the motorcycle is stabilised and adequately supported. This will help prevent it from falling and causing injury to the operator or damage to the motorcycle.

1. Raise and support the front of the motorcycle.
2. Remove the front wheel (see page 15-6).
3. Release the four fixings and remove the front mudguard.



1. Right hand mudguard fixings (Daytona 675 shown)


4. Detach and support the front brake calipers;
 - see page 14-21 for Daytona 675 up to VIN 381274 and Street Triple R;
 - see page 14-17 for Daytona 675 from VIN 381275;
 - see page 14-26 for Street Triple.

Warning

Never allow the brake calipers to hang on the brake hoses as this may damage the hoses. A damaged brake hose can cause a reduction in braking efficiency leading to loss of motorcycle control and an accident.

Note:


- If the forks are to be dismantled, slacken the fork top caps.
5. **Daytona 675 only:** Slacken the handlebar and top yoke clamp bolts.



1. Handlebar clamp bolt

2. Top yoke clamp bolt

6. **Street Triple and Street Triple R:** Slacken the top yoke clamp bolts.




1. Top yoke clamp bolt

7. Slacken the bottom yoke clamp bolts.

Note:

- **Daytona 675 shown, Street Triple similar.**



1. Bottom yoke clamp bolts

8. Using a downward, twisting action, withdraw the forks from between the yokes.



Caution


Care must be taken when removing the forks, to ensure that the outer surfaces do not become scratched.

Installation

1. Position the forks within the yokes so that the lip of the outer tube, not the top cap, is 4 mm above the upper surface of the top yoke.

Note:

- **Daytona 675 shown, Street Triple similar.**



1. Outer tube

2. Top cap

3. Top yoke

2. Tighten the bottom yoke clamp bolts to **20 Nm**.
3. Tighten the top yoke clamp bolts to **26 Nm**.
4. **Daytona 675 only:** Tighten the handlebar clamp bolts to **26 Nm**.

Note:

- **If the forks have been dismantled, tighten the fork top caps to 25 Nm.**
5. Refit the front mudguard. Tighten the fixings to **6 Nm**.
 6. Install the front wheel (see page 15-7).
 7. Refit the front brake calipers;
 - see page 14-23 for Daytona 675 up to VIN 381274 and Street Triple;
 - see page 14-25 for Daytona 675 from VIN 381275;
 - see page 14-28 for Street Triple.
 8. Lower the motorcycle to the ground and park it on the side stand.

Fork Oil Change

Draining



Warning


Before starting work, ensure the motorcycle is stabilised and adequately supported. This will help prevent it from falling and causing injury to the operator or damage to the motorcycle.

1. Remove the fork (see page 13-6).
2. Remove the top cap assembly (see page 13-10).
3. Remove the fork spring (see page 13-10).
4. Holding the inner and outer tubes together, invert the fork and pour out the fork oil into a suitable container. Pump the damper rod to remove all the oil.

Oil Refilling

The oil level is measured from the upper surface of the fork outer tube, with the fork fully compressed and the spring removed.

For the measurement, refer to the table below.




Fork Oil Level (fully compressed)

Model	Oil Level
Daytona 675 up to VIN 381274	72 mm
Daytona 675 from VIN 381275	89 mm
Street Triple	107 mm
Street Triple R	93 mm

1. Fill the fork with the grade of oil specified in the fork oil table, to a level above that which will finally be required.
2. Pump the fork assembly and damper several times to expel any trapped air then fully compress the fork and support it in an upright position. Leave the fork for a few minutes to allow the oil to stabilise.

- Refer to the fork oil level chart and set the scale on tool 3880160-T0301 to the relevant distance, as shown below.

Refer to fork oil level chart



cbvg

1. Tool 3880160-T0301
2. Adjustment plate
3. Scale area
4. Hole (zero position)

Note:

- Zero level on the tool is set at the small exit hole in the side of the scale tube, **NOT AT THE END TIP**. Do not attempt to block this side hole as this will cause the final fluid level to be incorrect.
- Insert the scale end of the tool into the fork inner tube.
 - Hold the tool adjuster plate level with the upper surface of the fork inner tube and draw fluid into the syringe until fluid flow ceases (empty the syringe if the body becomes full before fluid flow stops).
 - The fluid level in the fork is now set to the height set on the tool scale. Check the tool scale setting and repeat the process if incorrectly set.



Warning

Incorrect fork oil levels could result in an unsafe riding condition leading to loss of control and an accident.

- Assemble the fork (see page 13-13).
- Refit the fork (see page 13-8).

Fork Oil Level Chart

Daytona 675 up to VIN 381274			
Oil Level*	Oil Volume	Oil Grade	Fork Pull Through
72 mm	495 cc	Kayaba KHL15-10	Top of the inner tube 4 mm above the upper face of the top yoke
Daytona 675 from VIN 381275			
Oil Level*	Oil Volume	Oil Grade	Fork Pull Through
89 mm	492 cc	Kayaba KHL15-10	Top of the inner tube 4 mm above the upper face of the top yoke
Street Triple			
Oil Level*	Oil Volume	Oil Grade	Fork Pull Through
107 mm	465 cc	Kayaba KHL15-10	Top of the inner tube 4 mm above the upper face of the top yoke
Street Triple R			
Oil Level*	Oil Volume	Oil Grade	Fork Pull Through
93 mm	475 cc	Kayaba KHL15-10	Top of the inner tube 4 mm above the upper face of the top yoke

*Fork Fully Compressed

Front Suspension

Front Fork

Disassembly


Warning

Before starting work, ensure the motorcycle is stabilised and adequately supported. This will help prevent it from falling and causing injury to the operator or damage to the motorcycle.

Note:

- Before removing the forks, slacken the top cap a little to allow easier removal during strip-down.
- The procedure for the disassembly of Daytona 675, Street Triple and Street Triple R front forks is identical unless otherwise stated.
- The fork seals can be renewed without removal of the damping cylinder. Unless removal of the damping cylinder is necessary, omit items 16 and 17 of this procedure.

1. Remove the forks (see page 13-6).
2. **Daytona 675 and Street Triple R only:** Note the position of the spring preload adjuster relative to the fork cap to ensure the setting is retained on re-assembly. Turn the spring load adjuster until 7 rings are shown on the adjuster.




cdli

1. Preload adjuster marks
2. Compression/rebound adjuster

Warning

Do not change the fork adjustment settings. If they are changed, this will change the handling of the motorcycle from those which the rider is used to. Riding with unfamiliar fork settings may cause unexpected handling characteristics leading to loss of motorcycle control and an accident.

3. Very gently clamp the fork in the soft jawed vice to prevent it from turning, hold the outer tube, then unscrew the top cap from the outer tube.



ccun

1. Fork
2. Soft jaws
3. Top cap

Caution

Never tightly clamp the outer tube as this will cause the tube to permanently distort. A distorted tube is not serviceable and must be replaced.

Note:

- The top cap is not under spring tension and will not spring upwards when the threads disengage.
4. Holding the inner and outer tubes together, invert the fork and pour out the fork oil into a suitable container. Pump the damper rod to remove all the oil.
 5. Return the fork to the soft jawed vice.


Warning

While compressing the fork spring and while the spring holder is in place always wear protective equipment for the face and eyes and never stand directly above or look directly down on the fork. If the spring compressor or holder should dislodge or detach, the resulting release of spring tension could cause parts to fly off resulting in injury to the user.

6. Fit tool T3880067 over the top cap. Position the two adjustable arms to the holes in the spring spacer. Screw in the arms until they positively engage in the spring spacer holes.

Note:

- An assistant may be required to insert the spring holder below the damper locknut.
7. Using tool T3880067, manually compress the fork spring and insert the spring holder as shown, below the damper locknut.



1. Damper locknut
2. Tool T3880067
3. Spring holder (part of T3880067)

8. Slacken the locknut, unscrew and remove the top cap and damper rod. If necessary, remove the O-ring seal from the top cap assembly. The top cap assembly cannot be dismantled.
9. Recompress the fork spring to remove the holder.


Warning

While compressing the fork spring and while the spring holder is in place always wear protective equipment for the face and eyes and never stand directly above or look directly down on the fork. If the spring compressor or holder should dislodge or detach, the resulting release of spring tension could cause parts to fly off resulting in injury to the user.

Note:


- The spring has a smaller coil diameter at its upper end. Note the orientation of the spring before removal.

10. Remove the washer, spring spacer and spring.



1. Washer
2. Spring spacer
3. Spring
4. Damper rod


11. Separate the inner and outer tubes leaving the seals and bushes in place on the outer tube.
12. Invert and mount the fork outer tube to tool T3880002.
13. Remove the dust cover from the outer tube.



1. Fork outer tube
2. Dust cover
3. Tool T3880002

Front Suspension

14. Carefully remove the circlip, oil seal and bushes from the outer tube. Note the relative positions of all parts before removal.




1. Bush
2. Washer
3. Oil seal
4. Circlip
5. Outer tube
6. Tool T3880002

Note:

- For Daytona 675 from VIN 381275 only: The tool T3880028 will not fit over the locknut on the damping rod. To use the tool when removing the damper bolt, remove the locknut.
 - For Daytona 675 from VIN 381275 only: The locknut for the damper rod is only threaded in the top half of the nut. The lower half of the nut is not threaded and the hole diameter is slightly wider.
15. For Daytona 675 from VIN 381275 only: Remove the locknut from the damper rod. Note the orientation of the locknut for installation.
16. Insert the end of tool T3880028 with the lugs over the damper rod and locknut, if fitted, engage the lugs on the tool into the slots in the damping cylinder inside the fork. Hold the flats of the tool to prevent the cylinder from turning while removing the damper bolt from the bottom of the fork. Discard the washer from the damper bolt.


Note:

- For all models except the Daytona 675 from VIN 381275, the tool T3880028 is designed to fit over the top of the damper rod locknut.



1. Tool T3880028
2. Damping cylinder bolt location

17. Remove the tool, then the damping cylinder from the inner tube.



1. Damping cylinder

Inspection

1. Inspect the inner tube for stone chips, scoring, scratches, excessive wear and any other damage. Renew as necessary.

Note:

- Small inclusions in the inner tube may be removed using a fine grade stone or similar.
2. Inspect the spring for damage, cracks and deformation. Renew the spring if necessary.
3. Inspect all the bushes and seals for damage. Renew any damaged items if necessary.

Assembly



Warning


The front forks comprise many precision machined parts. Total cleanliness must be observed at all times and assembly must take place in a dirt/dust-free environment.

Dirt ingress may cause damage to the fork parts, leading to incorrect operation, instability, loss of control or an accident.

Note:

- If the damping cylinder has not been removed, omit operations 1 and 2.

1. Fit the damping cylinder to the inner tube and engage tool T3880028 as during removal.
2. Clean the threads of the damping cylinder bolt and fit a new sealing washer. Apply a drop of ThreeBond 1342 to the threads then install the bolt. Prevent the cylinder from turning by holding the flats at the end of tool T3880028 while tightening the damping cylinder securing bolt to **24 Nm**.




cdnr

1. Tool T3880028

2. Damping cylinder bolt location

3. Invert and position the outer fork tube to tool T3880002.
4. Apply a smear of fork oil to the bushes and seals.

5. Position the seals and lower bush to the inner tube as noted prior to removal. Use a new circlip.



ccup1

1. Dust seal

2. Circlip


3. Oil seal

4. Washer

5. Lower bush

6. Upper bush

6. Using a suitable tool, fit the upper bush to the outer fork outer tube.
7. Position the inner tube assembly to the outer, ensuring that the oil and dust seal lips do not become damaged.
8. Using the narrow end of tool T3880003, push/tap the bush, washer and seal into position.



ccuq

1. Tool T3880003

2. Seal


3. Washer

4. Bush

5. Tool T3880002

Front Suspension

9. Retain the bush, washer and seal with the new circlip.




1. Dust seal


2. Circlip

3. Tool T3880002

10. Position the dust seal to the outer tube.
 11. Invert tool T3880003 and, using hand pressure only, push the dust seal squarely into the outer tube.
 12. Fill the fork with oil (see page 13-8).
 13. Position the fork assembly as for compression of the fork spring during strip down.
 14. **Daytona 675 and Street Triple R only:** Rethread the damper rod locknut leaving **13 mm** of thread exposed above the nut.



15. **Street Triple only:** Screw the damper rod locknut to the bottom of the damper rod threads.
 16. Refit the fork spring, close wound end uppermost, spring spacer and washer.



1. Washer

2. Spring spacer

3. Spring


4. Damper rod

17. Attach tool 3880085-T0301 to the threads of the damper rod and pull the damper upwards.

Warning

While re-compressing the fork spring and while the spring holder is in place always wear protective equipment for the face and eyes and never stand directly above or look directly down on the fork. If the spring compressor or holder should dislodge or detach, the resulting release of spring tension could cause parts to fly off resulting in injury to the user.

18. Refit tool T3880067 as previously described, compress the fork spring and refit the spring holder.



1. Damper locknut

2. Tool T3880067

3. Spring holder (part of T3880067)

19. Remove tool 3880085-T0301 from the damper rod.



Caution

If removed, the damping rod locknut must be fitted with the flat face facing to the top of the fork. The slightly tapered face must face the fork spring. Incorrect orientation may lead to a loosening of the locknut.

20. Fit a new O-ring to the top cap.
21. **Daytona 675 and Street Triple R only:** Ensure the damping adjuster rod is installed in to the damper rod.
22. **All models:** Refit the top cap to the damper rod.
23. **Daytona 675 and Street Triple R only:** Ensure the damper rod thread is screwed into the top cap to a depth of **13 mm**, as set by the locknut at step 14.
24. **Street Triple only:** Screw the top cap fully on the damper rod.
25. **All models:** Hold the top cap while tightening the damper rod locknut to **17 Nm**.



Warning

While compressing the fork spring and while the spring holder is in place always wear protective equipment for the face and eyes and never stand directly above or look directly down on the fork. If the spring compressor or holder should dislodge or detach, the resulting release of spring tension could cause parts to fly off resulting in injury to the user.

26. Recompress the spring to remove the spring holder.
27. Lubricate the O-ring on the top cap with a smear of fork oil then screw the top cap fully into the inner tube.
28. Tighten the top cap to **25 Nm**.

Note:

- **It is much easier to tighten the top cap when the fork has been refitted.**

29. Refit the fork (see page 13-8).

Headstock Bearing Check/Adjustment


Check

1. Raise and support the front of the motorcycle.



Warning

Before starting work, ensure the motorcycle is stabilised and adequately supported. This will help prevent it from falling and causing injury to the operator or damage to the motorcycle.



cdlh


Checking Headstock Bearing Adjustment (Daytona 675 shown)

2. Hold the lower end of the front forks as illustrated and 'rock' with a front-to-rear motion. If free play can be detected, the headstock bearings require adjustment.

Front Suspension

Adjustment - Daytona 675

1. Raise and support the front of the motorcycle.
2. Release the fixing securing each handlebar to the top yoke.



1. Handlebar (right hand side shown)
2. Fixing

Caution

To prevent paint damage, do not spill brake fluid onto any area of the bodywork. Spilled brake fluid will damage paintwork.

3. Detach the bracket for the front brake fluid reservoir from the handlebar. Taking care not to invert the brake fluid reservoir, move it to one side.
4. Slacken the top yoke clamp bolts.


Warning

If the lower yoke fixings are also slackened, the forks will no longer support the weight of the motorcycle. Do not slacken the lower yoke fixings as, in this condition, the motorcycle could topple over causing damage and/or risk of injury.

Caution

Care must be taken when removing the headstock top nut, to ensure that the top nut and top yoke do not become scratched. Protect the surfaces with a suitable cloth or tape to prevent scratching.

5. Slacken the headstock top nut.




1. Headstock top nut (Daytona 675 shown)

6. Ease the top yoke from the forks and support while detached.
7. Adjust the bearing free-play as follows, all using tool T3880023:
 - Remove the locknut and tab washer.
 - Slacken the adjuster nut then tighten to **40 Nm**.
 - Slacken the adjuster nut, then retighten to **15 Nm**.
 - Fit the tab washer and lock nut.

Warning

It is essential that the adjuster nut is not over-tightened. If the adjuster is over-tightened it will cause a pre-load on the headstock bearings. This will introduce tight steering, which could cause loss of control and an accident.

- Hold the adjuster nut in position while tightening the locknut to **40 Nm**.



1. Adjuster nut

2. Locknut

3. Tool T3880023

8. Refit the top yoke to the forks.
9. Tighten the top nut to **90 Nm**.
10. Install the handlebar to top yoke fixings and tighten to **5 Nm**.
11. Tighten the top yoke clamp bolts to **26 Nm**.
12. Fit the bracket for the front brake fluid reservoir and tighten the fixing to **15 Nm**.
13. Recheck the bearing adjustment (see page 13-15).

Adjustment - Street Triple and Street Triple R

1. Raise and support the front of the motorcycle.
2. Release the fixings securing the handlebar clamps to the risers, detach the clamps and release the handlebar.
3. As an assembly, raise the handle bars until clear of the top yoke. Rest the assembly forward of the steering stem such that access to the headstock top nut and the adjustment nuts is unrestricted. Ensure the master cylinder remains in an upright position.
4. Slacken the top yoke clamp bolts.



Warning

If the lower yoke fixings are also slackened, the forks will no longer support the weight of the motorcycle.


Do not slacken the lower yoke fixings as, in this condition, the motorcycle could topple over causing damage and/or risk of injury.



Caution

Care must be taken when removing the headstock top nut, to ensure that the top nut and top yoke do not become scratched. Protect the surfaces with a suitable cloth or tape to prevent scratching.

5. Slacken the headstock top nut.



1. Headstock top nut

6. Ease the top yoke from the forks and support while detached.
7. Adjust the bearing free-play as follows, all using tool T3880023:
 - Remove the locknut and tab washer.
 - Slacken the adjuster nut then tighten to **40 Nm**.


Front Suspension

- Slacken the adjuster nut, then retighten to **15 Nm**.
 - Fit the tab washer and lock nut.
12. Align the handlebar punch mark with the front right hand split line of the clamp/riser, then tighten the front clamp bolts to **26 Nm**, then the rears.

Warning


It is essential that the adjuster nut is not over-tightened. If the adjuster is over-tightened it will cause a pre-load on the headstock bearings. This will introduce tight steering, which could cause loss of control and an accident.

- Hold the adjuster nut in position while tightening the locknut to **40 Nm**.



1. Adjuster nut
2. Locknut
3. Tool T3880023

8. Refit the top yoke assembly to the forks.
9. Tighten the top nut to **90 Nm**.
10. Tighten the top yoke clamp bolts to **26 Nm**.
11. Locate the handlebar assembly in the lower halves of the clamps. Fit the upper clamps and bolts.



1. Right hand front clamp split line
2. Handlebar punch mark

13. Recheck the bearing adjustment (see page 13-15).

Headstock Bearing Removal

Warning


Before starting work, ensure the motorcycle is stabilised and adequately supported. This will help to prevent it falling and causing injury to the operator or damage to the motorcycle.

1. **Daytona 675 only:** Remove the steering damper (see page 13-21).
2. **All models:** Remove both forks (see page 13-6).

Caution

Care must be taken when removing the headstock top nut, to ensure that the top nut and headstock do not become scratched. Protect the surfaces with a suitable cloth or tape to prevent scratching.


3. Remove the headstock top nut.



1. Headstock top nut (Daytona 675 shown)

4. As an assembly, raise the top yoke and handle bars until clear of the steering stem. Rest the assembly forward of the steering stem such that access to the adjustment nuts is unrestricted. Ensure the master cylinder remains in an upright position.

5. Using tool T3880023, remove the locknut and tab washer. Discard the tab washer.



1. Locknut
2. Adjuster nut

6. Using the same tool, remove the adjuster nut.
7. Remove the bottom yoke from below the frame headstock.

Warning

Always wear eye, hand and face protection when using a hammer and drift. Use of a hammer and drift can cause bearings to fragment. Pieces of fragmented bearing could cause eye and soft tissue injuries if suitable protective apparel is not worn.

8. Using a suitable drift, evenly and progressively drive the bearing races from the frame headstock.
9. Remove the inner race and dust seal from the bottom yoke using a press or puller.

Inspection

Warning


Only remove raised witness marks from within the frame. Removal of material below any raised areas will reduce the level of interference between the frame and the bearings. Loss of interference could cause the bearing to become loose in the frame leading to loss of motorcycle control and an accident.

1. Examine the frame for any raised witness marks caused by the removal process. Remove any such marks with fine emery paper or a gentle file.

Front Suspension

Installation

1. Fit a new dust seal to the steering stem on the bottom yoke.



cdg01


1. Steering stem
2. Dust shield



Caution

Protect the threads of the bottom yoke when using a press or puller as damaged threads may mean replacing the yoke completely.

2. Press a new lower bearing inner race onto the steering stem of the bottom yoke.



1. Bearing
2. Bottom yoke
3. Press bed

3. Evenly and progressively drive a new complete upper bearing into the frame headstock.
4. Lubricate the lower bearing using multi-purpose grease.
5. Drive a new lower outer bearing into the frame headstock.

6. Lubricate the upper bearing using multi-purpose grease.
7. Insert the lower yoke to the frame, fit the upper bearing and race, and retain with the adjuster nut.
8. Adjust the headstock bearings (see page 13-15).
9. Locate the upper yoke to the steering stem. Install but do not fully tighten the headstock top nut at this stage.
10. Fit the forks (see page 13-8).
11. Tighten the headstock top nut to **90 Nm**.
12. **Daytona 675 only:** Refit the steering damper (see page 13-21).
13. Check that no freeplay exists in the headstock bearings. Adjust as necessary (see page 13-15).

Steering Damper - Daytona 675 only


Removal



Warning


Before starting work, ensure the motorcycle is stabilised and adequately supported. This will help to prevent it falling and causing injury to the operator or damage to the motorcycle.

1. Reposition the damper rod boot and remove the steering damper lower fixing. Noting its position, collect the steel washer located between the damper and the frame bracket.



1. Steering damper lower fixing
2. Damper rod boot
3. Steel washer position

2. Release the steering damper upper fixing and remove the steering damper. Noting its orientation, collect the flanged sleeve located between the damper body and the lower yoke.



1. Steering damper
2. Upper fixing
3. Flanged sleeve

Installation

1. Installation is the reverse of removal noting the following:

Note:

- Refit the steel washer as noted during removal.
- Refit the flanged sleeve as noted during removal.
- Tighten the fixings to 18 Nm.
- Refit the boot over the damper rod fixing.

Handlebars - Daytona 675



Warning


Before starting work, ensure the motorcycle is stabilised and adequately supported. This will help prevent it from falling and causing injury to the operator or damage to the motorcycle.

Removal

Note:

- This procedure describes the removal of both handlebars.


1. Remove the seat and disconnect the battery negative (black) lead first.
2. Remove and discard the fixings and remove the end weights from the handlebars.
3. Undo the screws and free the left switch gear assembly from the handlebar. Without disconnecting any wiring, lay the switch aside.
4. Unscrew the bolts and remove the clamp from the clutch lever assembly. Without disconnecting the clutch cable, lay the lever aside.
5. Slide off the rubber boot and release the screws which secure the two halves of the twist grip guide to each other.



1. Throttle grip guide
2. Screws
3. Rubber boot


6. Note the position of the guide relative to the handlebar then separate the two halves of the twist grip guide.
7. Note and mark the position of each cable relative to the twist grip in order to correctly identify their location during reassembly.

8. Release the inner cables from the twist grip.




1. Opening cable
2. Closing cable

9. Slide the twist grip off the handlebar.
10. Undo the screws and free the right hand switch gear assembly from the handlebar. Without disconnecting any wiring, lay the switch aside.
11. Unscrew the bolts and remove the clamp from the front brake master cylinder. Taking care to not invert the brake fluid reservoir, lay the assembly aside.
12. Release the fixing securing each handlebar to the top yoke.




1. Handlebar (right hand shown)
2. Fixing

13. Remove the headstock top nut.



1. Headstock top nut

14. Slacken the handlebar and top yoke clamp bolts.



1. Handlebar clamp bolt

2. Top yoke clamp bolt



Caution


Care must be taken when removing the top yoke or handlebars to ensure that the outer surfaces of the front forks do not become scratched.

15. Slide the top yoke off the front forks and lay aside.

16. Slide the handlebars off the front forks.

17. If required, remove the left hand handlebar grip.

18. If the handlebar end weight assembly is to be removed, gently squeeze the clip with suitable pliers and withdraw the assembly from the handlebar.



1. Fixing

2. End weight

3. Clip


4. Damper

5. Internal weight

6. Handlebar


Installation

1. If the bar end weight assembly has been removed from the handlebar, fit a new clip and install the weight into the handlebar. Ensure the two locking tangs on the clip engage fully into the holes in the handlebar.
2. Refit the handlebars to the front forks. Do not tighten the clamp bolts at this stage.
3. Refit the top yoke. Do not tighten the clamp bolts at this stage.
4. Refit the headstock top nut and tighten to **90 Nm**.
5. Install the handlebar to top yoke fixings and tighten to **5 Nm**.
6. Tighten the top yoke clamp bolts to **26 Nm**.
7. Tighten the handlebar clamp bolts to **26 Nm**.
8. If removed fit the left hand handlebar grip.
9. Position the clutch lever to the handlebar. Fit the clamp ('UP' arrow pointing upwards) and clamp bolts.
10. Align the split line of the clutch lever with the punch mark on the upper surface of the handlebar, then tighten the clamp bolts, upper first, to **12 Nm**.
11. Align the left hand switch cube to the handlebar and secure with the screws. Tighten the screws to **3 Nm**.
12. Slide the twist grip onto the right hand side of the handlebar.
13. Reconnect the inner throttle cables as noted during removal. Ensure that the positions of the opening and closing cables are not transposed.



1. Opening cable
2. Closing cable

14. Assemble the two halves of the cable guide ensuring that the outer cables are correctly located in the guide and the guide is positioned on the handlebars as noted prior to removal.



1. Throttle grip guide
2. Rubber boot
3. Screws

15. Tighten the cable guide fixings to **4 Nm**.
16. Position the right hand switch cube to the handlebar and tighten the fixings to **3 Nm**.
17. Position the front brake master cylinder assembly to the handlebar. Fit the clamp ('UP' arrow pointing upwards) and clamp fixings.
18. Align the split line of the master cylinder clamp to the punch mark on the upper surface of the handlebar and tighten the clamp fixings to **12 Nm**.
19. Fit the handlebar end weights, fit new fixings and tighten to **5 Nm**.
20. Check the throttle cable free play setting. Adjust as necessary. See page 10-103.
21. Reconnect the battery, positive (red) lead first.
22. Refit the seat.

23. Check for correct operation of the front brake and clutch. Check that the throttle opens and closes without sticking and that the cables do not bind or restrict the steering when the handlebars are turned from lock-to-lock. Rectify as necessary.



Warning

Operation of the motorcycle with incorrectly adjusted, incorrectly routed or damaged throttle cables could interfere with the operation of the brakes, clutch or the throttle itself. Any of these conditions could result in loss of control of the motorcycle and an accident.



Warning

Move the handlebars to left and right full lock while checking that cables and harnesses do not bind or that the steering feels tight or difficult to turn. A cable or harness that binds, or steering that is tight/difficult to turn will restrict the steering and may cause loss of control and an accident.

Handlebars - Street Triple and Street Triple R




Warning

Before starting work, ensure the motorcycle is stabilised and adequately supported. This will help prevent it from falling and causing injury to the operator or damage to the motorcycle.

Removal

1. Remove the seat and disconnect the battery negative (black) lead first.
2. Undo the fixing screws and remove the end weights from the handlebars.
3. Undo the screws and free the left switch gear assembly from the handlebar. Without disconnecting any wiring, lay the switch aside.
4. Unscrew the bolts and remove the clamp from the clutch lever assembly. Without disconnecting the clutch cable, lay the lever aside.
5. Slide off the rubber boot and release the screws which secure the two halves of the twist grip guide to each other.



1. Twist grip


2. Twist grip guide

3. Screws

6. Note the position of the guide relative to the handlebar then separate the two halves of the twist grip guide.
7. Note and mark the position of each cable relative to the twist grip in order to correctly identify their location during reassembly.

Front Suspension


8. Release the inner cables from the twist grip.



1. Closing inner cable

2. Opening inner cable

9. Slide the twist grip off the handlebar.
10. Undo the screws and free the right hand switch gear assembly from the handlebar. Without disconnecting any wiring, lay the switch aside.
11. **Street Triple R only:** Remove the fixing and detach the front brake fluid reservoir from the mounting bracket. Ensure the reservoir is supported in an upright position.
12. Unscrew the bolts and remove the clamp from the front brake master cylinder. Taking care to not invert the brake fluid reservoir, lay the assembly aside.
13. Release the fixings securing the handlebar clamps to the risers, detach the clamps and collect the handlebar.



1. Upper Clamp

2. Handlebar

3. Riser


14. Remove the left hand handlebar grip.

Installation

1. Locate the handlebar in the lower halves of the clamps. Fit the upper clamps and bolts.

Note:

- The Street Triple has a punch mark for the alignment of the handlebar.
 - The Street Triple R has an etched cross mark for the alignment of the handlebar.
2. Align the handlebar mark with the front right hand split line of the clamp/riser, then tighten the front clamp bolts to **26 Nm**, then the rears.




1. Right hand front clamp split line

2. Handlebar punch mark (Daytona 675 shown)


3. Fit the left hand handlebar grip.
4. Position the clutch lever to the handlebar. Fit the clamp (UP arrow pointing upwards) and clamp bolts.
5. Align the split line of the clutch lever with the punch mark on the upper surface of the handlebar, then tighten the clamp bolts, upper first, to **15 Nm**.
6. Align the left hand switch cube to the handlebar and secure with the screws. Tighten the screws to **3 Nm**.
7. Slide the twist grip onto the right hand side of the handlebar.

8. Reconnect the inner throttle cables as noted during removal. Ensure that the positions of the opening and closing cables are not transposed.



1. Closing inner cable
2. Opening inner cable

9. Assemble the two halves of the cable guide ensuring that the outer cables are correctly located in the guide and the guide is positioned on the handlebars as prior to removal.



1. Twist grip
2. Twist grip guide
3. Screws

10. Tighten the cable guide fixings to **4 Nm**.
11. Position the right hand switch cube to the handlebar and tighten the fixings to **4 Nm**.
12. Position the front brake master cylinder assembly to the handlebar. Fit the clamp (Up arrow pointing upwards) and clamp fixings.
13. Align the split line of the master cylinder clamp to the mark on the upper surface of the handlebar and tighten the clamp fixings to **15 Nm**.
14. **Street Triple R only:** Attach the front brake reservoir to its mounting bracket. Tighten the fixing to **7 Nm**.
15. Fit the handlebar end weights, tightening the fixings to **5 Nm**.
16. Check the throttle cable free play setting. Adjust as necessary. See page 10-103.
17. Reconnect the battery, positive (red) lead first.
18. Refit the seat.
19. Check for correct operation of the front brake and clutch. Check that the throttle opens and closes without sticking and that the cables do not bind or restrict the steering when the handlebars are turned from lock-to-lock. Rectify as necessary.



Warning

Operation of the motorcycle with incorrectly adjusted, incorrectly routed or damaged throttle cables could interfere with the operation of the brakes, clutch or the throttle itself. Any of these conditions could result in loss of control of the motorcycle and an accident.



Warning

Move the handlebars to left and right full lock while checking that cables and harnesses do not bind or that the steering feels tight or difficult to turn. A cable or harness that binds, or steering that is tight/difficult to turn will restrict the steering and may cause loss of control and an accident.

14 Brakes


Table of Contents

Exploded View - Front Brake Master Cylinder - Daytona 675 and Street Triple R	14.3
Exploded View - Front Brake Master Cylinder - Street Triple	14.4
Exploded View - Front Brake Caliper - Daytona 675 up to VIN 381274 and Street Triple R	14.5
Exploded View - Front Brake Caliper - Daytona 675 from VIN 381275	14.6
Exploded View - Front Brake Caliper - Street Triple	14.7
Exploded View - Rear Brake Master Cylinder - All Models	14.8
Exploded View - Rear Brake Caliper - All Models	14.9
Braking System Maintenance Safety Precautions	14.10
Front Brake Fluid Level Inspection - Daytona 675 and Street Triple R	14.11
Front Brake Fluid Level Inspection - Street Triple	14.11
Rear Brake Fluid Level Inspection - All Models	14.12
Changing Brake Fluid	14.12
Brake Pads	14.12
Brake Wear Inspection	14.12
Bleeding the Front Brakes, Renewing Brake Fluid	14.13
Front Brake Pads - Daytona 675 up to VIN 381274 and Street Triple R	14.15
Removal	14.15
Inspection	14.15
Installation	14.16
Front Brake Pads - Daytona 675 from VIN 381275	14.17
Removal	14.17
Inspection	14.17
Installation	14.18
Front Brake Pads - Street Triple	14.19
Removal	14.19
Inspection	14.19
Installation	14.20
Front Brake Caliper - Daytona 675 up to VIN 381274 and Street Triple R	14.21
Removal	14.21
Disassembly	14.21
Inspection	14.22
Assembly	14.22


Brakes

Installation	14.23
Front Brake Caliper - Daytona 675 from VIN 381275	14.23
Removal	14.23
Disassembly	14.24
Inspection	14.24
Assembly	14.25
Installation	14.25
Front Brake Caliper - Street Triple	14.26
Removal	14.26
Disassembly	14.26
Installation	14.28
Front Discs - All Models	14.28
Wear	14.28
Removal	14.29
Installation	14.29
Front Brake Master Cylinder - Daytona 675 and Street Triple R	14.30
Removal	14.30
Disassembly	14.30
Inspection	14.31
Assembly	14.31
Installation	14.31
Front Brake Master Cylinder - Street Triple	14.32
Removal	14.32
Disassembly	14.33
Inspection	14.33
Assembly	14.34
Installation	14.34
Bleeding the Rear Brakes, Renewing Brake Fluid	14.35
Rear Brake Pads	14.37
Installation	14.37
Rear Brake Caliper	14.39
Removal	14.39
Disassembly	14.39
Inspection	14.39
Assembly	14.39
Installation	14.40
Rear Brake Disc	14.41
Wear	14.41
Rear Master Cylinder	14.42
Removal	14.42
Disassembly	14.42
Inspection	14.42
Assembly	14.42
Installation	14.43


Exploded View - Front Brake Master Cylinder - Street Triple




Exploded View - Front Brake Caliper - Daytona 675 up to VIN 381274 and Street Triple R




Exploded View - Front Brake Caliper - Daytona 675 from VIN 381275




Exploded View - Front Brake Caliper - Street Triple



Exploded View - Rear Brake Master Cylinder - All Models



Exploded View - Rear Brake Caliper - All Models



Braking System Maintenance Safety Precautions

Warning

Brake fluid is hygroscopic which means it will absorb moisture from the air. The absorbed moisture will greatly reduce the boiling point of the brake fluid causing a reduction in braking efficiency.

Replace brake fluid in line with the scheduled maintenance chart. A dangerous riding condition could result if this important maintenance item is neglected.

Do not spill brake fluid onto any area of the bodywork as this will damage any painted or plastic surface.

Always use new brake fluid from a sealed container and never use fluid from an unsealed container or from one which has been previously opened.

Do not mix different brands of fluid. Check for fluid leakage around brake fittings, seals and joints.

Check regularly for brake hose damage.

FAILURE TO OBSERVE ANY OF THE ABOVE WARNINGS MAY REDUCE BRAKING EFFICIENCY LEADING TO AN ACCIDENT.

Warning

If there has been an appreciable drop in the level of the fluid in either brake fluid reservoir, consult your authorised Triumph dealer for advice before riding.

If the brake lever or pedal feels soft when it is applied, or if the lever/pedal travel becomes excessive, there may be air in the brake lines or the brake may be defective.

It is dangerous to operate the motorcycle under such conditions and remedial action must be taken by your authorised Triumph dealer before riding the motorcycle. Failure to take remedial action may reduce braking efficiency leading to an accident.

Warning

Use only DOT 4 specification brake fluid as listed in the general information section of this manual. The use of brake fluids other than those DOT 4 fluids listed in the general information section may reduce the efficiency of the braking system leading to an accident.

Failure to change the brake fluid at the interval specified in the scheduled maintenance chart may reduce braking efficiency resulting in an accident.

Warning

Never use mineral based grease (such as lithium or copper based grease) in any area where contact with the braking system hydraulic seals and dust seals is possible. Mineral based grease will damage the hydraulic seals and dust seals in the calipers and master cylinders. Damage caused by contact with mineral based grease may reduce braking efficiency resulting in an accident.


Front Brake Fluid Level Inspection - Daytona 675 and Street Triple R

Warning

Before starting work, ensure the motorcycle is stabilised and adequately supported. This will help prevent it from falling and causing injury to the operator or damage to the motorcycle.

In accordance with the scheduled maintenance chart, inspect the brake fluid level in the front and rear master cylinder reservoirs.

1. Ensure that the brake fluid level in the front brake fluid reservoir is between the upper and lower level lines (reservoir held horizontal).



jajc

1. Front reservoir upper level
2. Front reservoir lower level
3. Safety clip

2. To adjust the fluid level:
 - Remove the safety clip.
 - Fill the reservoir to the upper level line using new DOT 4 fluid from a sealed container.
 - Refit the reservoir cover ensuring that the diaphragm seal is correctly fitted.
 - Refit the safety clip.


Front Brake Fluid Level Inspection - Street Triple

Warning

Before starting work, ensure the motorcycle is stabilised and adequately supported. This will help prevent it from falling and causing injury to the operator or damage to the motorcycle.

In accordance with the scheduled maintenance chart, inspect the brake fluid level in the front and rear master cylinder reservoirs.

1. Ensure that the brake fluid level in the front brake fluid reservoir is between the upper and lower level lines (reservoir held horizontal).



kabi

1. Front reservoir upper level
2. Front reservoir lower level

2. To inspect the fluid level, check the level of fluid visible in the window at the front of the reservoir body.
3. To adjust the fluid level:
 - Release the cap screws and detach the cover noting the position of the sealing diaphragm.
 - Fill the reservoir to the upper level line using new DOT 4 fluid from a sealed container.
 - Refit the cover, ensuring that the diaphragm seal is correctly positioned between the cap and reservoir body. Tighten the cap retaining screws.


Rear Brake Fluid Level Inspection - All Models

Warning

Before starting work, ensure the motorcycle is stabilised and adequately supported. This will help prevent it from falling and causing injury to the operator or damage to the motorcycle.

In accordance with the scheduled maintenance chart, inspect the brake fluid level in the front and rear master cylinder reservoirs.

1. Ensure that the brake fluid level in the rear brake fluid reservoir is between the upper and lower level lines (reservoir held horizontal).



1. Rear reservoir
2. Rear reservoir upper level
3. Rear reservoir lower level

Changing Brake Fluid


Brake fluid should be changed at the interval specified in the scheduled maintenance chart.

Brake Pads

Front and rear pad wear is automatically compensated for and has no effect on brake lever or pedal action.

Brake Wear Inspection

In accordance with the scheduled maintenance chart, inspect the brake pads for wear. The minimum thickness of lining material for any front or rear brake pad is **1.5 mm**. If any pad has worn to the bottom of the groove in the pad centre, replace all the brake pads on that wheel.



cbmz

1. Lining material thickness
2. Centre groove

Warning

Do not replace individual brake pads, replace both pads in the brake caliper. On the front where two calipers are mounted on the same wheel, all the pads in both calipers must be replaced together. Replacing individual pads will reduce braking efficiency and may cause an accident.

Bleeding the Front Brakes, Renewing Brake Fluid


Warning

Before starting work, ensure the motorcycle is stabilised and adequately supported. This will help prevent it from falling and causing injury to the operator or damage to the motorcycle.

Note:

- **Daytona 675 and Street Triple R only:** The master cylinder should always be bled last. Bleed each caliper in turn before bleeding the master cylinder.

1. Note the original setting of the brake lever adjuster in order that it can be returned to the same position when the bleeding operation is complete. Set the brake lever adjuster to position No.1.



1. Lever (Daytona 675 shown)
2. Adjuster wheel
3. Triangular mark

2. Turn the handlebars to bring the fluid reservoir to a level position.


Warning

Ensure absolute cleanliness when adding brake fluid to the brake fluid reservoir. Do not allow moisture or debris to enter the cylinder, as this will adversely affect the fluid properties. Always use fluid from a sealed container and do not use fluid from a container that has been opened for any period of time. Always check for fluid leakage around hydraulic fittings and for damage to hoses. A dangerous riding condition leading to loss of motorcycle control and an accident could result if this warning is ignored.

Caution

To prevent paint damage, do not spill brake fluid onto any area of the bodywork. Spilled brake fluid will damage paintwork.

3. **Daytona 675 and Street Triple R only:** Remove the screw from the reservoir cover and collect the safety clip.
4. Carefully remove the reservoir cover taking care not to spill any fluid.
5. **Street Triple only:** Release the cap screws and detach the cover noting the position of the sealing diaphragm.
6. **All models:** Check the condition of the sealing diaphragm for the reservoir. Replace if necessary.
7. Remove the rubber cap from the bleed nipple on the right hand caliper.
8. Attach a transparent tube to the bleed nipple and place the other end of the tube in a suitable receptacle containing new brake fluid. Keep the tube end below the level of fluid.



1. Bleed nipple (Daytona 675 shown)
2. Bleed tube
3. Container

9. Release the bleed nipple.

Note:

- **During bleeding, do not allow the fluid level to fall below the lower level mark in the reservoir. If the fluid level is allowed to fall below this mark, air may enter the system and the sequence of bleeding must be repeated.**
10. Get an assistant to slowly pull the brake lever to the handlebar.

Brakes


11. With the lever held fully against the handlebar, close the bleed nipple. Once the bleed nipple is closed, release the brake lever.
12. Repeat steps 10 and 11 until no more air appears in the bleed tube.
13. When all air has been expelled from the system, hold the lever fully against the handlebar and close the bleed nipple.

Note:

- **Maintain the brake fluid level between the upper and lower reservoir levels whilst bleeding is being carried out.**

14. Tighten the bleed nipple to **6 Nm**.
15. Remove the bleed tube.
16. Replace the bleed nipple cap.
17. Fill the reservoir to the upper level with new DOT 4 fluid.

19. **Daytona 675 and Street Triple R only:** Repeat the bleed procedure for the bleed nipple on the master cylinder. Tighten the bleed nipple to **6 Nm**.



1. Bleed nipple (Daytona 675 shown)

2. Spanner

3. Bleed tube

4. Container

20. When both calipers (and the master cylinder on Daytona 675 and Street Triple R) have been bled, ensure the brake lever operation has a firm resistive feel to it, does not feel spongy and that the lever cannot be pulled directly back to the handlebar. Take remedial action as necessary.
21. **Daytona 675 and Speed Triple R only:** Refit the diaphragm and reservoir cover. Refit the safety clip and tighten the screw to **1 Nm**.
22. **Street Triple only:** Refit the diaphragm and reservoir cover. Refit the screws and tighten to **1.5 Nm**.



Warning

Use only DOT 4 specification brake fluid as listed in the general information section of this manual. The use of brake fluids other than those DOT 4 fluids listed in the general information section may reduce the efficiency of the braking system leading to loss of motorcycle control and an accident.

Observe the brake fluid handling warnings given earlier in this section of the manual.



Caution

To prevent paint damage, do not spill brake fluid onto any area of the bodywork. Spilled brake fluid will damage paintwork.

18. Repeat the bleed procedure for the left hand caliper.



Warning

Always return the lever adjuster to the original setting as noted in paragraph 1. Operating the motorcycle with lever settings that are unfamiliar may lead to loss of control or an accident.

23. **All models:** Reset the brake lever adjuster to the original setting.
24. Check the operation of the front brake. Rectify as necessary.



Warning

It is dangerous to operate the motorcycle with defective brakes; you must have your authorised Triumph dealer take remedial action before you attempt to ride the motorcycle again. Failure to take remedial action may reduce braking efficiency leading to loss of motorcycle control and an accident.

Front Brake Pads - Daytona 675 up to VIN 381274 and Street Triple R


Removal



Warning

Before starting work, ensure the motorcycle is stabilised and adequately supported. This will help prevent it from falling and causing injury to the operator or damage to the motorcycle.

1. Remove the brake pad retaining pin after removing the 'R' clip from its inner end. Inspect the pad retaining pin for damage.



1. 'R' clip

2. Remove the anti-rattle spring and inspect the spring for damage.




Caution

Never lever directly against the disc, caliper or the pad lining material as this will damage these components. Always use a levering tool made from a soft material which will not cause damage to the load bearing surfaces.

Brake fluid will be displaced as the caliper pistons are compressed. To prevent body damage, ensure that the displaced fluid does not come into contact with any part of the bodywork.

3. Ease the brake pads apart to force the caliper pistons back to allow withdrawal of the pads.

4. Remove both brake pads and inspect for damage and wear beyond the service limit.



1. Retaining pin
2. Anti-rattle spring
3. Brake pads

Note:

- Complete the assembly of the brake pads to one caliper (see assembly for details) before removing the pads from the other caliper.

Inspection

1. Check the 'R' clip, anti-rattle spring and retaining pin. Renew any component which shows signs of damage or corrosion.
2. Check there is no sign of leakage from the piston seals. Rectify any problems before installing the pads.

Note:

- Complete the assembly of the brake pads to one caliper (see assembly for details) before removing the pads from the other caliper.

Installation

! Warning


Never use mineral based grease (such as lithium or copper based grease) in any area where contact with the braking system hydraulic seals and dust seals is possible. Mineral based grease will damage the hydraulic seals and dust seals in the calipers and master cylinders. Damage caused by contact with mineral based grease may reduce braking efficiency resulting in an accident.

1. Fit new brake pads as an axle set or, if all the pads are in a serviceable condition, clean the pad grooves before refitting all pads in their original positions.

! Warning

Do not apply more than a minimum coating of grease to the pad retaining pins. Excess grease may contaminate the brake pads, hydraulic seals and discs causing reduced braking efficiency and an accident.

2. Lubricate the pad retaining pin using a minimum amount of proprietary high temperature 'Copperslip' type grease.
3. Fit the anti-rattle spring over the pads and push down in the centre to allow the pad retaining pin to slide across the top of the spring.
4. Tighten the pad retaining pin to **18 Nm**, and secure with the 'R' clip.



1. Retaining pin
2. Anti-rattle spring
3. Brake pads

5. Pump the brake lever to correctly position the caliper pistons.
6. Repeat the removal, inspection and installation process for the other caliper.

! Warning

Use only DOT 4 specification brake fluid as listed in the general information section of this manual. The use of brake fluids other than those DOT 4 fluids listed in the general information section may reduce the efficiency of the braking system leading to loss of motorcycle control and an accident.

Observe the brake fluid handling warnings given earlier in this section of the manual.

7. Check the front brake fluid level and top up as required with new DOT 4 fluid.
8. Check for correct brake operation. Rectify as necessary.

! Warning

It is dangerous to operate the motorcycle with defective brakes; you must have your authorised Triumph dealer take remedial action before you ride the motorcycle again. Failure to take remedial action may result in reduced braking efficiency leading to loss of motorcycle control and an accident.

Front Brake Pads - Daytona 675 from VIN 381275

Removal



Warning


Before starting work, ensure the motorcycle is stabilised and adequately supported. This will help prevent it from falling and causing injury to the operator or damage to the motorcycle.



Warning


Do not allow the calipers to hang on the brake hoses as this may damage the hoses and could lead to loss of motorcycle control and an accident.

1. Loosen the pad retaining pin, remove the caliper mounting bolts and slide the caliper off the disc. Recover the two dowels.



1. Pad retaining pin
2. Caliper mounting bolts

2. Remove the pad retaining pin and remove the pads from the caliper. Take care not to lose the anti-rattle spring from the caliper body.



ctds

1. Pad retaining pin
2. Brake pads
3. Dowels

Inspection

1. Check the anti-rattle spring and retaining pin. Renew any component which shows signs of damage or corrosion.
2. Check there is no sign of leakage from the piston seals. Rectify any problems before installing the pads.

Note:

- Complete the assembly of the brake pads to one caliper (see assembly for details) before removing the pads from the other caliper.

Installation

Warning

Never use mineral based grease (such as lithium or copper based grease) in any area where contact with the braking system hydraulic seals and dust seals is possible. Mineral based grease will damage the hydraulic seals and dust seals in the calipers and master cylinders. Damage caused by contact with mineral based grease may reduce braking efficiency resulting in an accident.

Caution

Never lever directly against the disc, caliper or the pad lining material as this will damage these components. Always use a levering tool made from a soft material which will not cause damage to the load bearing surfaces.

Brake fluid will be displaced as the caliper pistons are compressed. To prevent body damage, ensure that the displaced fluid does not come into contact with any part of the bodywork.


1. If new pads are being installed, push the pistons fully back into the caliper body. Keep an eye on the fluid level in the reservoir whilst retracting the pistons to prevent fluid spillage.
2. Ensure the anti-rattle spring is securely clipped onto the caliper body.

Warning

Do not apply more than a minimum coating of grease to the pad retaining pins. Excess grease may contaminate the brake pads, hydraulic seals and discs causing reduced braking efficiency and an accident.

3. Lubricate the pad retaining pin with a thin smear of proprietary high temperature 'Copperslip' type grease.
4. Ensure the heat isolation pads are fitted to the back of each brake pad. Fit the pads to the caliper with their friction material surfaces facing each other. Locate the pad upper ends in the mounting bracket retainer then align them with the caliper body and insert the retaining pin.
5. Slide the caliper onto the disc, ensuring the pads pass either side, and fit the mounting bolts. Tighten the mounting bolts to **35 Nm**.

6. Tighten the pad retaining pin to **18 Nm**.



1. Pad retaining pin

2. Caliper mounting bolts

7. Pump the brake lever to correctly position the caliper pistons.
8. Repeat the removal, inspection and installation process for the other caliper.

Warning

Use only DOT 4 specification brake fluid as listed in the general information section of this manual. The use of brake fluids other than those DOT 4 fluids listed in the general information section may reduce the efficiency of the braking system leading to loss of motorcycle control and an accident.

Observe the brake fluid handling warnings given earlier in this section of the manual.

9. Check the front brake fluid level and top up as required with new DOT 4 fluid.
10. Check for correct brake operation. Rectify as necessary.

Warning

It is dangerous to operate the motorcycle with defective brakes; you must have your authorised Triumph dealer take remedial action before you ride the motorcycle again. Failure to take remedial action may result in reduced braking efficiency leading to loss of motorcycle control and an accident.


Front Brake Pads - Street Triple

Removal

Warning


Before starting work, ensure the motorcycle is stabilised and adequately supported. This will help prevent it from falling and causing injury to the operator or damage to the motorcycle.

1. Unscrew the pad retaining pin plug from the caliper.



1. Pad retaining pin plug

2. Loosen the pad retaining pin.




1. Pad retaining pin

Warning

Do not allow the calipers to hang on the brake hoses as this may damage the hoses and could lead to loss of motorcycle control and an accident.

3. Slacken and remove the caliper mounting bolts and slide the caliper off the disc.

4. Remove the pad retaining pin and remove the pads from the caliper. Take care not to lose the pad retainer from the mounting bracket or the anti-rattle spring from the caliper body.



1. Caliper
2. Brake pad
3. Heat isolation pad
4. Anti-rattle spring
5. Pad retainer
6. Pad retaining pin
7. Pad retaining pin plug

Inspection

1. Check the pad retainer, anti-rattle spring and retaining pin. Renew any component which shows signs of damage or corrosion.
2. Check the caliper body slides easily on the mounting bracket pins and check there is no sign of leakage from the piston seals. Rectify any problems before installing the pads.

Note:

- Complete the assembly of the brake pads to one caliper (see assembly for details) before removing the pads from the other caliper.

Installation

Warning

Never use mineral based grease (such as lithium or copper based grease) in any area where contact with the braking system hydraulic seals and dust seals is possible. Mineral based grease will damage the hydraulic seals and dust seals in the calipers and master cylinders. Damage caused by contact with mineral based grease may reduce braking efficiency resulting in an accident.

Caution

Never lever directly against the disc, caliper or the pad lining material as this will damage these components. Always use a levering tool made from a soft material which will not cause damage to the load bearing surfaces.

Brake fluid will be displaced as the caliper pistons are compressed. To prevent body damage, ensure that the displaced fluid does not come into contact with any part of the bodywork.


1. If new pads are being installed, push the pistons fully back into the caliper body. Keep an eye on the fluid level in the reservoir whilst retracting the pistons to prevent fluid spillage.
2. Ensure the pad retainer is correctly fitted to the mounting bracket and the anti-rattle spring is securely clipped onto the caliper body.

Warning

Do not apply more than a minimum coating of grease to the pad retaining pins. Excess grease may contaminate the brake pads, hydraulic seals and discs causing reduced braking efficiency and an accident.

3. Lubricate the pad retaining pin with a thin smear of proprietary high temperature 'Copperslip' type grease.
4. Ensure the heat isolation pads are fitted to the back of each brake pad. Fit the pads to the caliper with their friction material surfaces facing each other. Locate the pad upper ends in the mounting bracket retainer then align them with the caliper body and insert the retaining pin.
5. Slide the caliper onto the disc, ensuring the pads pass either side, and fit the mounting bolts. Tighten the mounting bolts to **28 Nm**.
6. Tighten the pad retaining pin to **18 Nm**.

7. Fit the pad retaining pin plug to the caliper and tighten to **3 Nm**.



1. Pad retaining pin plug

8. Pump the brake lever to correctly position the caliper pistons.
9. Repeat the removal, inspection and installation process for the other caliper.

Warning

Use only DOT 4 specification brake fluid as listed in the general information section of this manual. The use of brake fluids other than those DOT 4 fluids listed in the general information section may reduce the efficiency of the braking system leading to loss of motorcycle control and an accident.

Observe the brake fluid handling warnings given earlier in this section of the manual.

10. Check the front brake fluid level and top up as required with new DOT 4 fluid.
11. Check for correct brake operation. Rectify as necessary.

Warning

It is dangerous to operate the motorcycle with defective brakes; you must have your authorised Triumph dealer take remedial action before you ride the motorcycle again. Failure to take remedial action may result in reduced braking efficiency leading to loss of motorcycle control and an accident.

Front Brake Caliper - Daytona 675 up to VIN 381274 and Street Triple R

Removal

! Warning

Before starting work, ensure the motorcycle is stabilised and adequately supported. This will help prevent it from falling and causing injury to the operator or damage to the motorcycle.

! Caution


To prevent paint damage, do not spill brake fluid onto any area of the bodywork. Spilled brake fluid will damage paintwork.

1. Disconnect the brake hose at the caliper (two hoses on right hand caliper), and place the free end of the hose(s) in a suitable container to collect the brake fluid.

Note:

- If the calipers are to be removed for access only, do not remove the brake pads.

2. Remove the brake pads (see page 14-15).
3. Remove the two caliper bolts.



1. Caliper bolts

4. Manoeuvre the caliper clear of the disc, taking care not to damage the wheel.

Disassembly

! Warning

To prevent injury, never place fingers or hands inside the caliper opening when removing the pistons. Always wear eye, hand and face protection when using compressed air. Eye, face and skin damage will result from direct contact with compressed air.

1. Undo and remove the four bolts which secure the two halves of the brake caliper together. Discard the bolts.
2. Carefully split the two halves of the caliper then remove and discard the joint seal.
3. Cover a caliper half with a clean, heavy cloth and, using compressed air, remove the pistons one at a time.

! Warning

Ensure the seal grooves in the caliper bores are not damaged during the removal of the seals. Damage to the seal grooves may allow brake fluid to leak past the seals resulting in a dangerous riding condition leading to loss of motorcycle control and an accident.

4. Remove the old piston seals and dust seals then thoroughly clean and dry the caliper bores and pistons. Discard the old seals, these must not be re-used.

Inspection

1. Check the pistons and caliper bores for corrosion, scoring and damage. Renew as necessary.

Warning

Always renew caliper seals and pistons after removal from the caliper. An effective hydraulic seal can only be made if new components are used.

A dangerous riding condition leading to an accident could result if this warning is ignored.

2. Inspect the brake pads for damage and wear beyond the service limit. Renew as necessary.

Assembly

Warning

Never use mineral based grease (such as lithium or copper based grease) in any area where contact with the braking system hydraulic seals and dust seals is possible. Mineral based grease will damage the hydraulic seals and dust seals in the calipers and master cylinders. Damage caused by contact with mineral based grease may reduce braking efficiency resulting in an accident.

Warning

Before installation, all internal brake components should be cleaned and lubricated with clean new DOT 4 brake fluid.


Never use solvents, petrol (gasoline), engine oil, or any other petroleum distillate on internal brake components as this will cause deterioration of the hydraulic seals in the calipers and master cylinders.

A dangerous riding condition leading to loss of motorcycle control and an accident could result if this warning is ignored.

1. Lubricate the piston seals with clean DOT 4 brake fluid. Fit the piston seals and the dust seals to the caliper bores in the positions shown below.

Note:

- The piston seals are slightly thicker than the dust seals.



1. Piston seals

2. Dust seals

Warning

Ensure that the caliper bores do not become scratched during piston removal and assembly. Ensure that the pistons remain square to their bores during fitment otherwise damage to the caliper could result.

A dangerous riding condition leading to an accident could result if this warning is ignored.

2. Carefully refit the pistons fully into the caliper bores by hand.
3. Once all seals and pistons have been fitted, carefully clean the mating faces of both calipers, then fit a new joint seal to the recess in one half of the caliper.


Warning

Ensure the mating faces of the caliper halves are clean and free from dust prior to assembly. Failure to ensure that the mating faces are clean and free from dust will result in a dangerous riding condition leading to loss of motorcycle control and an accident.

4. Apply a small drop of Loctite Hydraulic Sealant 569 to the threads of new caliper bolts and secure the two halves of the caliper together. Tighten the caliper bolts to **22 Nm**.

Installation

1. Position the caliper over the disc and tighten the caliper bolts to **35 Nm**.



cdfg

1. Caliper bolts

2. Fit the brake pads (see page 14-16).
3. Connect the brake hose(s) to the caliper incorporating new sealing washers on each side of all hose connections.
4. Tighten the banjo bolt to **25 Nm**.

! Warning

Use only DOT 4 specification brake fluid as listed in the general information section of this manual. The use of brake fluids other than those DOT 4 fluids listed in the general information section may reduce the efficiency of the braking system leading to loss of motorcycle control and an accident.

Observe the brake fluid handling warnings given earlier in this section of the manual.

5. Fill the master cylinder with new, DOT 4 brake fluid from a sealed container.
6. Bleed the front brake line (see page 14-13).
7. Check for correct brake operation.

! Warning

It is dangerous to operate the motorcycle with defective brakes; you must have your authorised Triumph dealer take remedial action before you ride the motorcycle again. Failure to take remedial action may result in reduced braking efficiency leading to loss of motorcycle control and an accident.

Front Brake Caliper - Daytona 675 from VIN 381275

Removal

! Warning

Before starting work, ensure the motorcycle is stabilised and adequately supported. This will help prevent it from falling and causing injury to the operator or damage to the motorcycle.

! Caution

To prevent paint damage, do not spill brake fluid onto any area of the bodywork. Spilled brake fluid will damage paintwork.

1. Disconnect the brake hose at the caliper (two hoses on right hand caliper), and place the free end of the hose(s) in a suitable container to collect the brake fluid.
2. Remove the brake pads (see page 14-17).

Brakes

Disassembly




Warning

To prevent injury, never place fingers or hands inside the caliper opening when removing the pistons. Always wear eye, hand and face protection when using compressed air. Eye, face and skin damage will result from direct contact with compressed air.

Note:

- Only the top two pistons (near the brake hose) are Nymfron coated;
- The Nymfron coated pistons appear to have a matt finish compared to the Nickel plated pistons;
- Note the position of the Nymfron coated pistons.

1. Cover the caliper opening with a clean heavy cloth and using either compressed air or by reconnecting the master cylinder and pumping the brake lever, remove the pistons one at a time.



cldr2

1. Piston seal
2. Dust seal
3. Pistons with Nymfron coating
4. Pistons with Nickel coating
5. Caliper
6. Pad retaining pin
7. Anti-rattle spring




Warning

Ensure the seal grooves in the caliper bores are not damaged during the removal of the seals. Damage to the seal grooves may allow brake fluid to leak past the seals resulting in a dangerous riding condition leading to loss of motorcycle control and an accident.

2. Extract the dust seals and piston seals, taking care not to damage the caliper bores. Discard the old seals, these must not be re-used.

Note:

- The piston seals are slightly thicker than the dust seals.



1. Piston seals

2. Dust seals

3. Check the pistons, caliper and mounting bracket for signs of damage, paying particular attention to the caliper bores and pistons. If damage is present, renew the worn component or the complete caliper assembly.

Inspection

1. Check the pistons and caliper bores for corrosion, scoring and damage. Renew as necessary.



Warning

Always renew caliper seals and pistons after removal from the caliper. An effective hydraulic seal can only be made if new components are used.

A dangerous riding condition leading to an accident could result if this warning is ignored.

2. Inspect the brake pads for damage and wear beyond the service limit. Renew as necessary.

Assembly

1. If all components are serviceable, obtain a piston seal kit and reassemble the caliper as follows:

Warning

Never use mineral based grease (such as lithium or copper based grease) in any area where contact with the braking system hydraulic seals and dust seals is possible. Mineral based grease will damage the hydraulic seals and dust seals in the calipers and master cylinders. Damage caused by contact with mineral based grease may reduce braking efficiency resulting in an accident.

Warning

Before installation, all internal brake components should be cleaned and lubricated with clean new DOT 4 brake fluid.

Never use solvents, petrol (gasoline), engine oil, or any other petroleum distillate on internal brake components as this will cause deterioration of the hydraulic seals in the calipers and master cylinders.

A dangerous riding condition leading to loss of motorcycle control and an accident could result if this warning is ignored.

2. Ensure all components are clean, then fit the new seals to their grooves in the caliper bores.
3. Lubricate the fluid seals, caliper bore and the outside of the pistons with clean DOT 4 brake fluid.
4. Ease the pistons squarely back into the bores as noted for removal, taking care not to displace the seals.

Installation

1. Fit the brake pads (see page 14-25).
2. Connect the brake hose(s) to the caliper incorporating new sealing washers on each side of all hose connections.
3. Tighten the banjo bolt to **25 Nm**.

Warning

Use only DOT 4 specification brake fluid as listed in the general information section of this manual. The use of brake fluids other than those DOT 4 fluids listed in the general information section may reduce the efficiency of the braking system leading to loss of motorcycle control and an accident.

Observe the brake fluid handling warnings given earlier in this section of the manual.

4. Fill the master cylinder with new, DOT 4 brake fluid from a sealed container.
5. Bleed the front brake line (see page 14-13).
6. Check for correct brake operation.

Warning

It is dangerous to operate the motorcycle with defective brakes; you must have your authorised Triumph dealer take remedial action before you ride the motorcycle again. Failure to take remedial action may result in reduced braking efficiency leading to loss of motorcycle control and an accident.

Front Brake Caliper - Street Triple

Disassembly

Removal

! Warning

Before starting work, ensure the motorcycle is stabilised and adequately supported. This will help prevent it from falling and causing injury to the operator or damage to the motorcycle.

! Caution


To prevent paint damage, do not spill brake fluid onto any area of the bodywork. Spilled brake fluid will damage paintwork.

1. Remove the brake pads (see page 14-19).
2. Disconnect the brake hose at the caliper (two hoses on right hand caliper), and place the free end of the hose(s) in a suitable container to collect the brake fluid.

! Warning

To prevent injury, never place fingers or hands inside the caliper opening when removing the pistons. Always wear eye, hand and face protection when using compressed air. Eye, face and skin damage will result from direct contact with compressed air.

1. Separate the caliper and mounting bracket.
2. Cover the caliper opening with a clean, heavy cloth and, using either compressed air or by reconnecting the master cylinder and pumping the brake lever, eject both pistons from the caliper at the same time.



1. Dust seals
2. Piston seals
3. Pistons

! Warning

Ensure the seal grooves in the caliper bores are not damaged during the removal of the seals. Damage to the seal grooves may allow brake fluid to leak past the seals resulting in a dangerous riding condition leading to loss of motorcycle control and an accident.

3. Extract the dust seals and piston seals, taking care not to damage the caliper bores.
4. Check the pistons, caliper and mounting bracket for signs of damage, paying particular attention to the caliper bores and pistons. If damage is present, renew the worn component or the complete caliper assembly.

5. If all components are serviceable, obtain a piston seal kit and reassemble the caliper as follows:

Warning

Always renew caliper seals after removal of the pistons. An effective hydraulic seal can only be made if new seals are fitted.

A dangerous riding condition leading to an accident could result if this warning is ignored.

Warning

Before installation, all internal brake components should be cleaned and lubricated with clean new DOT 4 brake fluid.

Never use solvents, petrol (gasoline), engine oil, or any other petroleum distillate on internal brake components as this will cause deterioration of the hydraulic seals in the calipers and master cylinders.


A dangerous riding condition leading to loss of motorcycle control and an accident could result if this warning is ignored.

6. Ensure all components are clean, then fit the new seals to their grooves in the caliper bores.
7. Lubricate the fluid seals, caliper bore and the outside of the pistons with clean DOT 4 brake fluid.
8. Ease the pistons squarely back into the bores, taking care not to displace the seals.

Warning

Never use mineral based grease (such as lithium or copper based grease) in any area where contact with the braking system hydraulic seals and dust seals is possible. Mineral based grease will damage the hydraulic seals and dust seals in the calipers and master cylinders. Damage caused by contact with mineral based grease may reduce braking efficiency resulting in an accident.

9. Lubricate the mounting bracket pins with a suitable silicone based brake grease then reassemble the bracket and caliper. Ensure the pin gaiters are correctly located on both the bracket and caliper.



1. Caliper sliding pin
2. Caliper bracket sliding pin

Installation

1. Fit the brake pads (see page 14-25).
2. Connect the brake hose(s) to the caliper incorporating new sealing washers on each side of all hose connections.
3. Tighten the banjo bolt to **25 Nm**.

Warning

Use only DOT 4 specification brake fluid as listed in the general information section of this manual. The use of brake fluids other than those DOT 4 fluids listed in the general information section may reduce the efficiency of the braking system leading to loss of motorcycle control and an accident.

Observe the brake fluid handling warnings given earlier in this section of the manual.

4. Fill the master cylinder with new, DOT 4 brake fluid from a sealed container.
5. Bleed the front brake line (see page 14-13).
6. Check for correct brake operation.

Warning

It is dangerous to operate the motorcycle with defective brakes; you must have your authorised Triumph dealer take remedial action before you ride the motorcycle again. Failure to take remedial action may result in reduced braking efficiency leading to loss of motorcycle control and an accident.

Front Discs - All Models

Warning

Before starting work, ensure the motorcycle is stabilised and adequately supported. This will help prevent it from falling and causing injury to the operator or damage to the motorcycle.

Wear

1. Replace any brake disc if worn beyond the service limit or that exceeds the disc run-out limit.


Front Disc Thickness

Standard:	4.0 mm
Service Limit:	3.5 mm

Disc Run-out

Service Limit:	0.3 mm
----------------	--------

Measure disc run-out using an accurate dial gauge mounted on a surface plate.



1. Disc
2. Dial gauge


Removal

Warning

Do not renew front brake discs individually. Discs must always be renewed in pairs even if one of a pair is serviceable.

A dangerous riding condition leading to an accident could result if this warning is ignored.

1. Remove the front wheel (see page 15-6).
2. Support the wheel on blocks as illustrated to avoid damage to the wheel centre.



1. Wheel

2. Support blocks

3. Remove and discard the bolts.
4. Detach the disc.
5. Repeat for the other disc.

Installation

1. Locate the first disc to the wheel.
2. Fit new bolts and tighten to **22 Nm**.
3. Fit the other disc in the same way.
4. Refit the front wheel (see page 15-7).
5. Check for correct brake operation. Rectify as necessary.

Warning

It is dangerous to operate the motorcycle with defective brakes; you must have your authorised Triumph dealer take remedial action before you ride the motorcycle again. Failure to take remedial action may result in reduced braking efficiency leading to loss of motorcycle control and an accident.

Front Brake Master Cylinder - Daytona 675 and Street Triple R

Removal

Warning


Before starting work, ensure the motorcycle is stabilised and adequately supported. This will help prevent it from falling and causing injury to the operator or damage to the motorcycle.

1. Remove the rider's seat (see page 16-17).
2. Disconnect the battery, negative (black) lead first.

Caution

To prevent paint damage, do not spill brake fluid onto any area of the bodywork. Spilled brake fluid will damage paintwork.

3. To drain the fluid from the master cylinder, attach a tube to the right hand caliper bleed nipple, slacken the nipple and allow the fluid to drain into a suitable container. Operate the brake lever until all fluid has been expelled.
4. Note the setting of the brake lever adjuster to ensure it is returned to the same position when the overhaul operation is complete.
5. Remove the pivot locknut and bolt securing the brake lever to the master cylinder, and remove the lever.




1. Pivot bolt
2. Nut

6. Disconnect from the master cylinder the:
 - brake hoses,
 - brake light switch connections.
7. Release the clamp screws from the handlebar to remove the master cylinder.

Disassembly


1. Support or remove the reservoir.
2. Detach the boot and push-rod from the lever end of the cylinder.
3. Remove the circlip from beneath the boot.



cdac

1. Circlip

4. Remove the piston set from the master cylinder bore noting the relative position of the seals and piston components.




cdac

1. Master cylinder
2. Spring
3. Piston seals
4. Piston
5. Circlip

Inspection

1. Check the following for wear, damage, cracks or deterioration:
 - Cylinder bore
 - Dust cover
 - Spring
 - Piston
 - Pivot Bolt
2. Always renew the piston and seal set if the cylinder is dismantled.
3. Check that the two ports in the master cylinder bore are not blocked.



1. Ports
2. Master cylinder bore

Assembly

Warning

Never use mineral based grease (such as lithium or copper based grease) in any area where contact with the braking system hydraulic seals and dust seals is possible. Mineral based grease will damage the hydraulic seals and dust seals in the calipers and master cylinders. Damage caused by contact with mineral based grease may reduce braking efficiency resulting in an accident.

Warning

Before installation, all internal brake components should be cleaned and lubricated with clean new DOT 4 brake fluid.

Never use solvents, petrol (gasoline), engine oil, or any other petroleum distillate on internal brake components as this will cause deterioration of the hydraulic seals in the calipers and master cylinders.

A dangerous riding condition leading to loss of motorcycle control and an accident could result if this warning is ignored.


1. Lubricate the piston and cylinder with new, clean brake fluid.

Warning

Ensure that the piston and piston seal are fitted facing the same way as noted during removal. A dangerous riding condition leading to an accident could result from incorrect assembly of the master cylinder.

2. Fit the new piston set into the master cylinder and retain with a new circlip.
3. Refit the master cylinder boot.

Installation



1. Arrow mark

1. Locate the master cylinder to the handlebars and position the clamp with the 'UP' arrow pointing upwards. Do not tighten the clamp bolts at this stage.
2. Connect the brake hose to the master cylinder incorporating new sealing washers. Tighten the banjo bolt to **25 Nm**.

3. Align the master cylinder/clamp split line with the 'dot' mark on the handlebar.
4. Tighten the clamp bolts, upper first and then the lower to **12 Nm**.
5. Connect the brake light switch.
6. Position the brake lever ensuring that the pivot boss is correctly aligned to the push rod. Fit and tighten the pivot bolt to **1 Nm**, and the locknut to **6 Nm**.

Warning

Use only DOT 4 specification brake fluid as listed in the general information section of this manual. The use of brake fluids other than those DOT 4 fluids listed in the general information section may reduce the efficiency of the braking system leading to loss of motorcycle control and an accident.

Observe the brake fluid handling warnings given earlier in this section of the manual.

7. Fill and bleed the front brakes (see page 14-13).

Warning

Always return the lever adjuster to the original setting noted during removal. Operating the motorcycle with lever settings which are unfamiliar may lead to loss of control or an accident.

8. Reset the brake lever adjuster to the original setting.
9. Examine the system for correct operation and fluid leaks. Rectify as necessary.
10. Connect the battery, positive (red) lead first.
11. Refit the rider's seat (see page 16-17).
12. Check for correct brake operation. Rectify as necessary.

Warning

It is dangerous to operate the motorcycle with defective brakes; you must have your authorised Triumph dealer take remedial action before you ride the motorcycle again. Failure to take remedial action may result in reduced braking efficiency leading to loss of motorcycle control and an accident.

Front Brake Master Cylinder - Street Triple

Removal

Warning

Before starting work, ensure the motorcycle is stabilised and adequately supported. This will help prevent it from falling and causing injury to the operator or damage to the motorcycle.

1. Remove the rider's seat (see page 16-17).
2. Disconnect the battery, negative (black) lead first.


Caution

To prevent paint damage, do not spill brake fluid onto any area of the bodywork. Spilled brake fluid will damage paintwork.

3. To drain the fluid from the master cylinder, attach a tube to the right hand caliper bleed nipple, slacken the nipple and allow the fluid to drain into a suitable container. Operate the brake lever until all fluid has been expelled.
4. Note the setting of the brake lever adjuster to ensure it is returned to the same position when the overhaul operation is complete.
5. Remove the pivot locknut and bolt securing the brake lever to the master cylinder, and remove the lever.
6. Disconnect from the master cylinder the:
 - brake hose,
 - brake light switch connections.
7. Release the clamp screws from the handlebar to remove the master cylinder.

Disassembly


1. Detach the rubber boot from the lever end of the cylinder.
2. Remove the circlip from beneath the boot.



ceqt

1. Circlip

3. Remove the piston set from the master cylinder bore noting the relative position of the seals and piston components.




cequ

1. Master cylinder
2. Spring and piston assembly
3. Circlip
4. Rubber boot

Inspection

1. Check the following for wear, damage, cracks or deterioration:
 - Cylinder bore
 - Rubber boot
 - Spring
 - Piston
 - Pivot Bolt
2. Always renew the piston and seal set if the cylinder is dismantled.
3. Check that the two ports in the master cylinder bore are not blocked.



ceqq

1. Ports

Assembly

Warning

Never use mineral based grease (such as lithium or copper based grease) in any area where contact with the braking system hydraulic seals and dust seals is possible. Mineral based grease will damage the hydraulic seals and dust seals in the calipers and master cylinders. Damage caused by contact with mineral based grease may reduce braking efficiency resulting in an accident.

Warning

Before installation, all internal brake components should be cleaned and lubricated with clean new DOT 4 brake fluid.

Never use solvents, petrol (gasoline), engine oil, or any other petroleum distillate on internal brake components as this will cause deterioration of the hydraulic seals in the calipers and master cylinders.

A dangerous riding condition leading to loss of motorcycle control and an accident could result if this warning is ignored.


1. Lubricate the piston and cylinder with new, clean brake fluid.

Warning

Ensure that the piston and piston seal are fitted facing the same way as noted during removal. A dangerous riding condition leading to an accident could result from incorrect assembly of the master cylinder.

2. Fit the new piston set into the master cylinder and retain with a new circlip.
3. Refit the master cylinder boot.

Installation



1. 'UP' Arrow
2. 'Dot' mark

1. Locate the master cylinder to the handlebars and position the clamp with the 'UP' arrow pointing upwards.
2. Align the master cylinder/clamp split line with the 'dot' mark on the handlebar.
3. Tighten the clamp bolts, upper first and then the lower to **12 Nm**.
4. Connect the brake hose to the master cylinder incorporating new sealing washers. Tighten the banjo bolt to **25 Nm**.
5. Connect the brake light switch connections.
6. Position the brake lever ensuring that the pivot boss is correctly aligned to the push rod. Fit and tighten the pivot bolt to **1 Nm**, and the locknut to **6 Nm**.

Warning

Use only DOT 4 specification brake fluid as listed in the general information section of this manual. The use of brake fluids other than those DOT 4 fluids listed in the general information section may reduce the efficiency of the braking system leading to loss of motorcycle control and an accident.

Observe the brake fluid handling warnings given earlier in this section of the manual.

7. Fill and bleed the front brakes (see page 14-13).

Warning

Always return the lever adjuster to the original setting noted during removal. Operating the motorcycle with lever settings which are unfamiliar may lead to loss of control or an accident.

8. Reset the brake lever adjuster to the original setting.
9. Examine the system for correct operation and fluid leaks. Rectify as necessary.
10. Connect the battery, positive (red) lead first.
11. Refit the rider's seat (see page 16-17).
12. Check for correct brake operation. Rectify as necessary.

Warning


It is dangerous to operate the motorcycle with defective brakes; you must have your authorised Triumph dealer take remedial action before you ride the motorcycle again. Failure to take remedial action may result in reduced braking efficiency leading to loss of motorcycle control and an accident.

Bleeding the Rear Brakes, Renewing Brake Fluid

Warning

Before starting work, ensure the motorcycle is stabilised and adequately supported. This will help prevent it from falling and causing injury to the operator or damage to the motorcycle.

1. Remove the cap from the rear bleed nipple.
2. Attach a transparent tube to the bleed nipple.




1. Bleed nipple
2. Spanner
3. Bleed tube

3. Place the other end of the tube in a suitable receptacle containing new brake fluid.

Caution

To prevent paint damage, do not spill brake fluid onto any area of the bodywork. Spilled brake fluid will damage paintwork.

4. Unscrew and remove the rear brake reservoir cover taking care not to spill any fluid.



1. Rear reservoir
2. Rear reservoir upper level
3. Rear reservoir lower level

Warning

Ensure absolute cleanliness when adding brake fluid to the brake fluid reservoir. Do not allow moisture or debris to enter the cylinder as this will adversely affect the fluid properties. Always use fluid from a sealed container and do not use fluid from a container which has been opened for any period of time. Always check for fluid leakage around hydraulic fittings and for damage to hoses.

A dangerous riding condition leading to an accident could result if this warning is ignored.

5. Check the condition of the sealing diaphragm. Replace the diaphragm as necessary.
6. Release the bleed nipple.

Note:

- **During bleeding, do not allow the fluid level to fall below the lower level mark in the reservoir. If the level is allowed to fall below this mark, air may enter the system and the sequence of bleeding must be repeated.**
7. Slowly depress the brake pedal and, holding the pedal fully down, close the bleed nipple.
 8. Repeat steps 6 and 7 until no more air appears in the bleed tube.
 9. Maintain the brake fluid level between the upper and lower reservoir levels whilst bleeding is being carried out.

10. When all air has been expelled from the system, hold down the brake pedal and close the bleed nipple. Tighten the nipple to **6 Nm**.
11. Fill the reservoir to the maximum level with new DOT 4 fluid.

Warning

Use only DOT 4 specification brake fluid as listed in the general information section of this manual. The use of brake fluids other than those DOT 4 fluids listed in the general information section may reduce the efficiency of the braking system leading to loss of motorcycle control and an accident.

Observe the brake fluid handling warnings given earlier in this section of the manual.

12. Fit the reservoir cover and diaphragm. Check for correct diaphragm fitment before final tightening of the cover.
13. Remove the bleed tube from the nipple.
14. Replace the bleed nipple cap.
15. Check for correct brake operation. Rectify as necessary.

Warning


It is dangerous to operate the motorcycle with defective brakes; you must have your authorised Triumph dealer take remedial action before you ride the motorcycle again. Failure to take remedial action may result in reduced braking efficiency leading to loss of motorcycle control and an accident.

Rear Brake Pads

Warning

Before starting work, ensure the motorcycle is stabilised and adequately supported. This will help prevent it from falling and causing injury to the operator or damage to the motorcycle.

1. Push the brake caliper inwards towards the wheel in order to displace the caliper piston.
2. Remove the plug protecting the pad retaining pin.



1. Plug
2. Pad retaining pin


Note:

- Before removing the brake pads, note the relationship of the pads to the caliper and ensure that, on assembly, they are fitted in the same way.

Warning


Do not allow the caliper to hang on the brake hoses as this may damage the hoses and could lead to loss of motorcycle control and an accident.

3. Remove the brake caliper bolts and raise the caliper.



1. Brake caliper bolt
2. Brake pads
3. Pad retaining pin

4. Remove the pad retaining pin and remove the pads.
5. Remove the anti-rattle spring and inspect for damage.



1. Anti-rattle spring

Installation

Warning

Never use mineral based grease (such as lithium or copper based grease) in any area where contact with the braking system hydraulic seals and dust seals is possible. Mineral based grease will damage the hydraulic seals and dust seals in the calipers and master cylinders. Damage caused by contact with mineral based grease may reduce braking efficiency resulting in an accident.

! Caution


To prevent paint damage, do not spill brake fluid onto any area of the bodywork. Spilled brake fluid will damage paintwork.

1. If fitting new pads, use hand pressure to compress the caliper piston fully into its bore.
2. Fit the anti rattle spring into the caliper.
3. Renew the brake pads as a pair or, if both pads are in a serviceable condition, clean the pad grooves before fitting them.
4. Fit the brake pads to the caliper in the positions noted during removal.

! Warning

Do not apply more than a minimum coating of grease to the pad retaining pins. Excess grease may contaminate the brake pads, hydraulic seals and discs causing reduced braking efficiency and an accident.

5. Lubricate the pad retaining pin using a minimum amount of proprietary high temperature 'Copperslip' type grease.
6. Install the pad retaining pin.
7. Lower the caliper over the brake disc ensuring that the pads remain in the correct positions.



1. Plug

2. Pad retaining pin

8. Fit the caliper bolts and tighten to **22 Nm** (M8 bolt) and **27 Nm** (M12 bolt).
9. Tighten the pad retaining pin to **18 Nm**.
10. Fit the retaining plug and tighten to **3 Nm**.
11. Pump the brake pedal to correctly position the caliper pistons.

12. Check the brake fluid level in the rear reservoir and top-up as required with new D.O.T. 4 fluid.

! Warning

Use only DOT 4 specification brake fluid as listed in the general information section of this manual. The use of brake fluids other than those DOT 4 fluids listed in the general information section may reduce the efficiency of the braking system leading to loss of motorcycle control and an accident.

Observe the brake fluid handling warnings given earlier in this section of the manual.

13. Check for correct brake operation. Rectify as necessary.

! Warning

It is dangerous to operate the motorcycle with defective brakes; you must have your authorised Triumph dealer take remedial action before you ride the motorcycle again. Failure to take remedial action may result in reduced braking efficiency leading to loss of motorcycle control and an accident.

Rear Brake Caliper

Removal


Warning

Before starting work, ensure the motorcycle is stabilised and adequately supported. This will help prevent it from falling and causing injury to the operator or damage to the motorcycle.

Caution

To prevent paint damage, do not spill brake fluid onto any area of the bodywork. Spilled brake fluid will damage paintwork.

1. Disconnect the rear brake hose at the caliper and place the free end of the hose in a suitable container to collect the brake fluid.
2. Remove the caliper mounting bolts.
3. Remove the brake caliper assembly.



1. Caliper mounting bolts

Disassembly

1. Remove the plug protecting the pad retaining pin.
2. Remove the pad retaining pin.
3. Remove the brake pads and anti-rattle spring.

Warning

To prevent injury, never place fingers or hands inside the caliper opening when removing the piston. Always wear eye, hand and face protection when using compressed air. Eye, face and skin damage will result from direct contact with compressed air.

4. Cover the caliper opening with a clean, heavy cloth and, using either compressed air or by reconnecting the master cylinder and pumping the brake lever, remove the piston.

Inspection

1. Check the piston and caliper bore for corrosion, scoring and damage. Renew as necessary.

Warning

Always renew caliper seals and pistons after removal from the caliper. An effective hydraulic seal can only be made if new components are used.

A dangerous riding condition leading to an accident could result if this warning is ignored.

2. Inspect the brake pads for damage and wear beyond the service limit. Renew as necessary.

Assembly

Warning

Never use mineral based grease (such as lithium or copper based grease) in any area where contact with the braking system hydraulic seals and dust seals is possible. Mineral based grease will damage the hydraulic seals and dust seals in the calipers and master cylinders. Damage caused by contact with mineral based grease may reduce braking efficiency resulting in an accident.

Warning

Ensure that the caliper bores do not become scratched during removal and assembly.

A dangerous riding condition leading to an accident could result if this warning is ignored.


Warning

Before installation, all internal brake components should be cleaned and lubricated with clean new DOT 4 brake fluid.

Never use solvents, petrol (gasoline), engine oil, or any other petroleum distillate on internal brake components as this will cause deterioration of the hydraulic seals in the calipers and master cylinders.

A dangerous riding condition leading to loss of motorcycle control and an accident could result if this warning is ignored.

1. Fit new fluid seals to the caliper. Apply brake fluid to the outside of the caliper piston and fluid seal.



1. Piston
2. Seals

Warning

Ensure that the piston does not tip during assembly as this could damage the caliper.


A dangerous riding condition leading to an accident could result if this warning is ignored.

2. Carefully push the piston into the caliper by hand.
3. Install the anti-rattle spring into the caliper.
4. Position the brake pads in the caliper.

Warning

Do not apply more than a minimum coating of grease to the pad retaining pins. Excess grease may contaminate the brake pads, hydraulic seals and discs causing reduced braking efficiency and an accident.

5. Lubricate the pad retaining pin using a minimum amount of proprietary high temperature 'Copperslip' type grease.
6. Fit and tighten the pad retaining pin to **18 Nm**.
7. Fit the retaining plug and tighten to **3 Nm**.
8. Apply a thin smear of silicone based brake grease to the outside of the sleeve and the sliding section of the bolt as shown below. Do not apply grease to the threads of the bolt.



1. Bolt
2. Sleeve

Installation

1. Position the caliper over the disc ensuring the pads are correctly aligned on both sides of the disc.
2. Fit the caliper retaining bolts and tighten to **22 Nm** (M8 bolt) and **27 Nm** (M12 bolt).
3. Connect the brake hose to the caliper incorporating new washers on each side of the banjo bolt.
4. Tighten the banjo bolt to **25 Nm**.

Warning

Use only DOT 4 specification brake fluid as listed in the general information section of this manual. The use of brake fluids other than those DOT 4 fluids listed in the general information section may reduce the efficiency of the braking system leading to loss of motorcycle control and an accident.

Observe the brake fluid handling warnings given earlier in this section of the manual.

5. Fill the master cylinder with new, DOT 4 brake fluid from a sealed container.
6. Bleed the rear brake (see page 14-35).
7. Check for correct brake operation. Rectify as necessary.

Warning

It is dangerous to operate the motorcycle with defective brakes; you must have your authorised Triumph dealer take remedial action before you ride the motorcycle again. Failure to take remedial action may result in reduced braking efficiency leading to loss of motorcycle control and an accident.

Rear Brake Disc

Wear

Warning

Before starting work, ensure the motorcycle is stabilised and adequately supported. This will help prevent it from falling and causing injury to the operator or damage to the motorcycle.

1. Replace any brake disc worn beyond the service limit or that exceeds the disc run-out limit.


Rear Disc Thickness

Standard:	5.0 mm
Service Limit:	4.5 mm

Disc Run-out

Service Limit:	0.30 mm
----------------	---------

Measure disc run-out using an accurate dial gauge mounted on a surface plate.



1. Disc
2. Dial gauge

Note:

- Details of rear brake disc removal and installation can be found in the wheel section.

Rear Master Cylinder

Removal

Warning


Before starting work, ensure the motorcycle is stabilised and adequately supported. This will help prevent it from falling and causing injury to the operator or damage to the motorcycle.

1. Remove the rider's seat (see page 16-17).
2. Disconnect the battery, negative (black) lead first.

Caution

To prevent paint damage, do not spill brake fluid onto any area of the bodywork. Spilled brake fluid will damage paintwork.

3. Drain the fluid from the master cylinder by bleeding the system at the rear caliper until all fluid has been expelled.
4. Remove the clip and washer from the clevis pin at the lower end of the brake pushrod.
5. Remove the clevis pin.
6. Disconnect from the master cylinder the:
 - rear brake hose (noting orientation),
 - reservoir hose.



1. Master cylinder fixings
2. Master cylinder
3. Heel guard

7. Remove the screws securing the master cylinder and heel guard to the frame to release the master cylinder.

Disassembly

1. Remove the boot from the cylinder and pushrod.
2. Remove the circlip retaining the pushrod to the cylinder.
3. Remove the pushrod and piston set from the master cylinder bore, noting the relative position of the seals and piston components.

Inspection

1. Visually inspect the master cylinder bore for wear, scratches or corrosion. Replace as necessary.
2. Check the piston and cylinder bore for damage, wear or deterioration. Replace as necessary.
3. Always renew the piston and seal set if the cylinder is dismantled.
4. Examine the pushrod for bends and damage. Replace as necessary.

Assembly

Warning

Never use mineral based grease (such as lithium or copper based grease) in any area where contact with the braking system hydraulic seals and dust seals is possible. Mineral based grease will damage the hydraulic seals and dust seals in the calipers and master cylinders. Damage caused by contact with mineral based grease may reduce braking efficiency resulting in an accident.

Warning

Before installation, all internal brake components should be cleaned and lubricated with clean new DOT 4 brake fluid.

Never use solvents, petrol (gasoline), engine oil, or any other petroleum distillate on internal brake components as this will cause deterioration of the hydraulic seals in the calipers and master cylinders.


A dangerous riding condition leading to loss of motorcycle control and an accident could result if this warning is ignored.

1. Clean the master cylinder bore, piston and seals, with new brake fluid.
2. Ensure all ports are clear of obstruction.

Warning

Ensure that the piston and piston seal are fitted facing the same way as noted during removal. A dangerous riding condition leading to an accident could result from incorrect assembly of the master cylinder.

3. Install the spring and piston set together.
4. Apply a small amount of brake grease to the pushrod.
5. Install the pushrod in the master cylinder and retain with a new circlip.
6. Refit the boot.



1. Reservoir hose

2. Piston set

3. Dust boot


4. Push rod

5. Clevis pin

6. Clip

7. Circlip

7. If the pushrod has been disassembled, adjust the length of the pushrod as shown below:



1. Pushrod

2. Locknut

8. Set the pushrod free length to 75.5 mm.
9. Tighten the locknut to **18 Nm**.

Installation

1. Fit the reservoir hose to the master cylinder.
2. Secure the master cylinder and heel guard to the frame. Tighten the securing screws to **18 Nm**.
3. Connect the push rod to the brake pedal using a new clevis pin and split pin.
4. Incorporating new washers, fit the brake hose to the master cylinder. Ensuring correct orientation of the brake hose, tighten the banjo bolt to **25 Nm**.

Warning

Use only DOT 4 specification brake fluid as listed in the general information section of this manual. The use of brake fluids other than those DOT 4 fluids listed in the general information section may reduce the efficiency of the braking system leading to loss of motorcycle control and an accident.


Observe the brake fluid handling warnings given earlier in this section of the manual.

5. Fill and bleed the rear brake system (see page 14-35).
6. Reconnect the battery, positive (red) lead first.
7. Refit the rider's seat (see page 16-17).
8. Check for correct brake operation. Rectify as necessary.



Warning

It is dangerous to operate the motorcycle with defective brakes; you must have your authorised Triumph dealer take remedial action before you ride the motorcycle again. Failure to take remedial action may result in reduced braking efficiency leading to loss of motorcycle control and an accident.




15 Wheels/Tyres

Table of Contents


Exploded view - Front Wheel	15.2
Exploded View - Rear Wheel & Final Drive	15.3
Tyres	15.4
Tyre Pressures.	15.4
Tyre Wear/Wheel Inspection.	15.4
Important Tyre Information	15.5
Front Wheel	15.6
Removal	15.6
Installation.	15.7
Rear Wheel	15.8
Removal	15.8
Installation.	15.8
Front Wheel Bearings	15.10
Removal	15.10
Inspection	15.10
Installation.	15.10
Rear Wheel Bearings.	15.11
Removal	15.11
Inspection	15.12
Installation.	15.12
Final Drive	15.13
Removal	15.13
Inspection	15.13
Installation.	15.13

Wheels/Tyres

Exploded view - Front Wheel




Exploded View - Rear Wheel & Final Drive




Tyres

This model is equipped with tubeless tyres, valves, and wheel rims. Only tyres marked 'TUBELESS' and tubeless type tyre valves mounted on rims marked 'SUITABLE FOR TUBELESS TYRES' can be used.



Typical Wheel Marking



Typical Tyre Marking

Warning

Tyres that have been used on a rolling road dynamometer may become damaged. In some cases, the damage may not be visible on the external surface of the tyre.

Tyres must be replaced after such use as continued use of a damaged tyre may lead to instability, loss of control and an accident.

Tyre Pressures

Correct inflation pressure will provide maximum stability, rider comfort and tyre life.

Tyre pressures should be checked frequently and adjusted as necessary. Correct tyre pressures are:

Daytona

Tyre Pressure - Front	2.35 bar (34 psi)
Tyre Pressure - Rear	2.50 bar (36 psi)

Street Triple and Street Triple R

Tyre Pressure - Front	2.35 bar (34 psi)
Tyre Pressure - Rear	2.90 bar (42 psi)

Warning

Incorrect tyre inflation will cause abnormal tread wear and instability problems which may lead to loss of control and an accident.


Under-inflation may result in the tyre slipping on, or coming off the rim. Over-inflation will cause instability and accelerated tread wear.

Both conditions are dangerous as they may cause loss of control leading to an accident.

Tyre Wear/Wheel Inspection

As the tyre tread wears down, the tyre becomes more susceptible to puncture and failure. It is estimated that 90% of all tyre failures occur during the last 10% of tread life (90% worn). It is false economy and unsafe to use tyres until they are worn to their minimum.

All tyres are fitted with tread wear indicators. When the tyre becomes worn down as far as the top of a tread wear indicator, the tyre is worn beyond its service life and must be replaced.



1. Tread wear indicator

In accordance with the scheduled maintenance chart, measure the depth of the tread with a depth gauge, and replace any tyre that has worn to, or beyond the minimum allowable tread depth.

Inspect wheels for cracks, splits and kerb damage. Always replace wheels that are suspected of having become damaged.

Warning

Operation with excessively worn tyres is hazardous and will adversely affect traction, stability and handling which may lead to loss of control or an accident.

When tubeless tyres become punctured, leakage is often very slow. Always inspect tyres very closely for punctures.

Check the tyres for cuts, embedded nails or other sharp objects.

Check the rims for dents or deformation. Operation with damaged or defective wheels or tyres is dangerous and loss of control or an accident could result.

Always consult your Triumph dealer for tyre replacement, or for a safety inspection of the tyres.

Minimum Recommended Tread Depth

The following chart can be used as a guide to the minimum safe tread depth.

Under 130 km/h (80 mph)	2 mm (0.08 in)
Over 130 km/h (80 mph)	Rear 3 mm (0.12 in) Front 2 mm (0.08 in)

Warning

Triumph motorcycles must not be operated above the legal road speed limit except in authorised closed course conditions.

Important Tyre Information

All Triumph motorcycles are carefully and extensively tested in a range of riding conditions to ensure that the most effective tyre combinations are approved for use on each model. It is essential that approved tyre combinations are used when purchasing replacement tyres as the use of non approved tyres or approved tyres in non approved combinations may lead to motorcycle instability. Always refer to the owner's handbook data section for details of approved tyres and tyre combinations.

Warning

If a tyre sustains a puncture, the tyre must be replaced. Failure to replace a punctured tyre, or operation with a repaired tyre can lead to instability, loss of control or an accident.

Never use an inner tube to repair a punctured tyre. The rough surface inside the tyre can chafe the tube leading to instability, rapid deflation, loss of control and an accident.

Warning

The use of tyres other than those listed in the specification section of the owner's handbook may adversely affect handling leading to loss of control or an accident.

Use the recommended tyre options only in the combinations given in the owner's handbook.

Do not mix tyres from different manufacturers or tyres from the same manufacturer but from another option.

Warning

Always check tyre pressures before riding when the tyres are cold. Operation with incorrectly inflated tyres may affect handling leading to loss of control and an accident.

Warning

Operation with excessively worn or damaged tyres will adversely affect handling and control leading to loss of control or an accident.

Warning

Do not install tube-type tyres on tubeless rims. The bead will not seat and the tyres could slip on the rims, causing tyre deflation that may result in a loss of vehicle control and an accident.

Do not install an inner tube inside a tubeless tyre. This may cause instability and excessive heat build-up may cause the tube to burst resulting in rapid tyre deflation, loss of vehicle control and an accident.

Warning

Accurate wheel balance is necessary for safe, stable handling of the motorcycle. Do not remove or change any wheel balance weights. Incorrect wheel balance may cause instability leading to loss of control and an accident.

When wheel balancing is required, such as after tyre replacement, see your authorised Triumph dealer.

Only use self-adhesive weights. Clip on weights will damage the wheel and tyre resulting in tyre deflation, loss of control and an accident.

Warning

When replacement tyres are required, consult your authorised Triumph dealer who will arrange for the tyres to be fitted according to the tyre manufacturers instructions.

When tyres are replaced, allow time for the tyre to seat itself to the rim (approximately 24 hours). During this seating period, ride cautiously as an incorrectly seated tyre could cause loss of control or an accident. Initially, the new tyre will not produce the same handling characteristics as the worn tyre and the rider must allow adequate riding distance (approximately 100 miles) to become accustomed to the new handling characteristics. After both 24 hours and 100 miles, the tyre pressures should be checked and adjusted and the tyre examined for correct seating and rectified as necessary.

Use of a motorcycle when not accustomed to its handling characteristics may lead to loss of control and an accident.

Front Wheel

Removal

Warning

Before starting work, ensure the motorcycle is stabilised and adequately supported. This will help prevent it from falling and causing injury to the operator or damage to the motorcycle.

1. Position the motorcycle on a paddock stand.
2. Detach and support the front brake calipers;
 - see page 14-21 for Daytona 675 up to VIN 381274 and Street Triple R;
 - see page 14-17 for Daytona 675 from VIN 381275;
 - see page 14-26 for Street Triple.

Note:


- It is not necessary to disconnect the brake hoses.

Warning

Do not allow the calipers to hang on the brake hoses as this may damage the hoses.

Damaged hoses could cause brake failure leading to loss of control and an accident.


3. Raise and support the front of the motorcycle.
4. Slacken both pinch bolts at the lower end of the left hand fork.



1. Fork pinch bolts

5. Release and remove the wheel spindle, which is threaded into the right hand fork.

- Remove the wheel and the wheel spacers.



1. Wheel spacers (left hand shown)

- Place the wheel on wooden blocks.



Warning

Do not allow the wheel to rest on either brake disc as this may damage the disc and could lead to an accident.




Caution

To prevent wheel and bearing damage, observe absolute cleanliness and ensure there is no dirt ingress to the wheel bearings while the wheel is removed.

- Thoroughly clean all components and inspect for wear or damage.


Installation

- Lightly smear the wheel spacers with grease and locate in the hubs.
- Position the wheel between the forks ensuring the spacers remain in position on both sides.



1. Wheel spacers

- Refit the wheel spindle from the left hand side and tighten to **65 Nm**.
- Lower the motorcycle to the ground and pump the front suspension to allow the left hand fork to 'float' to its natural position on the wheel spindle.
- Tighten the fork pinch bolts to **22 Nm**.



1. Fork pinch bolts

- Thoroughly clean and degrease the brake discs.
- Refit the front brake calipers;
 - see page 14-23 for Daytona 675 up to VIN 381274 and Street Triple R;
 - see page 14-25 for Daytona 675 from VIN 381275;
 - see page 14-28 for Street Triple.

Rear Wheel

Removal

Warning


Before starting work, ensure the motorcycle is stabilised and adequately supported. This will help prevent it from falling and causing injury to the operator or damage to the motorcycle.

1. Raise and support the rear of the motorcycle to allow removal of the rear wheel.

Warning

If the engine has recently been running, the exhaust system will be hot. Before working on or near the exhaust system, allow sufficient time for the exhaust system to cool as touching any part of a hot exhaust system could cause burn injuries.

2. Remove the nut from the rear wheel spindle.



1. Rear wheel spindle nut

3. Support the wheel and withdraw the wheel spindle.
4. Noting its position, release the brake caliper and carrier from the slot on the swinging arm and roll the wheel forward until the chain can be detached from the rear sprocket.

Warning

Do not allow the caliper to hang on the brake hose as this may damage the hose.


Damaged hoses could cause brake failure leading to loss of control and an accident.

5. Tie the rear brake caliper aside.

6. Withdraw the wheel and collect the flanged spacer from the right hand side and the plain spacer from the left hand side.
7. Place the wheel on wooden blocks with the drive sprocket uppermost.
8. Remove the final drive. (See page 15-13).
9. Reposition the wheel on wooden blocks with the rear brake disc uppermost.
10. If required, remove the rear brake disc and discard the disc bolts.


Installation

1. Thoroughly clean and degrease the brake disc.
2. Fit the brake disc and tighten new disc bolts to **22 Nm**.
3. Refit the final drive assembly (See page 15-13).
4. Position the wheel within the swinging arm and refit the chain to the final drive sprocket.




1. Fitting the chain

5. Position the rear brake caliper and carrier to the swinging arm as noted prior to removal. Align the boss on the carrier with the raised slot on the swinging arm.



1. Caliper carrier boss
2. Swinging arm slot

6. Refit the wheel spacers, flanged spacer to the right hand side (flange facing outwards) and plain spacer to the left.



1. Wheel spacer (right hand shown)


7. Lift the rear wheel into position, aligning the wheel, caliper carrier and swinging arm.

Warning

Check that the spacers are still correctly positioned. Incorrectly fitted wheel spacers will cause a dangerous riding condition leading to loss of motorcycle control and an accident.

8. Fit the wheel spindle with the threaded end facing to the left.

9. Keeping the chain adjuster blocks in contact with the adjuster bolts, tighten the wheel spindle nut to **110 Nm**.



1. Rear wheel spindle nut

10. Lower the motorcycle to the ground.

Warning

It is dangerous to operate the motorcycle with defective brakes and you must have your authorised Triumph dealer take remedial action before you attempt to ride the motorcycle again. Failure to take remedial action may reduce braking efficiency leading to loss of motorcycle control and an accident.

11. Check the operation of the rear brake.
12. Check and, if necessary, adjust the chain (see page 12-7).

Front Wheel Bearings

Removal

1. Remove the front wheel (see page 15-6).

Caution

Do not allow the wheel to rest on the brake discs, as this may damage the discs. Support the wheel on wooden blocks, equally spaced around the rim, such that the brake discs are raised above the ground.

2. Place the wheel on wooden blocks to prevent damage to the brake discs.
3. Remove and discard the seals and the bearing circlip.


Warning

Always wear eye, hand and face protection when using a hammer and drift. Use of a hammer and drift can cause bearings to fragment. Pieces of fragmented bearing could cause eye and soft tissue injuries if suitable protective apparel is not worn.

Caution

To prevent wheel damage and to aid bearing removal, always apply force evenly on both sides of the bearing to prevent it from 'tipping' and becoming stuck. Application of uneven force will lead to difficulty in removing the bearing and to a damaged wheel.

4. Using a suitable pin punch, through the centre of the wheel, drift out the wheel bearings. Collect the centre sleeve.



Wheel Bearing Removal

Inspection

Warning

Only remove raised witness marks from within the wheel. Removal of material below any raised areas will reduce the level of interference between the wheel and the bearings. Loss of interference could cause the bearing to become loose in the wheel leading to loss of motorcycle control and an accident.

1. Examine the wheel for any raised witness marks caused by the removal process. Remove any such marks with fine emery paper or a gentle file.


Installation

Note:

- Refer to the chart below for the correct tool and tool face when inserting bearings. Bearings are inserted by means of a draw-bolt acting on the insertion tool. A support tool is located on the opposite side of the wheel to the insertion tool and as the bolt is tightened, the bearing is drawn into the wheel.
- Insert bearings with the marked or shielded side facing outwards and always fit a new bearing circlip and seals.

	Bearing insertion tool	Support tool
Left bearing	T3880053 Small face to bearing	3880065 - T0301 Large face to Wheel
Right bearing	T3880053 Small face to bearing	3880065 - T0301 Large face to wheel

1. Fit the wheel bearings and centre sleeve using the method described on the previous page.



1. Tool T3880053

2. Tool 3880065 - T0301

2. Fit a new circlip.
3. Lubricate and fit new seals to the front wheel. Lubricate the seal's knife-edge with grease to NLGI 2 specification (we recommend Mobil HP222).
4. Fit the front wheel (see page 15-7).

Rear Wheel Bearings

Removal

1. Remove the rear wheel (see page 15-8).

! Caution

Do not allow the wheel to rest on the brake disc, as this may damage the disc. Support the wheel on wooden blocks, equally spaced around the rim, such that the brake disc is raised above the ground.

2. Place the wheel on wooden blocks to prevent damage to the brake disc.
3. Remove and discard the seals and the bearing circlip.


! Warning

Always wear eye, hand and face protection when using a hammer and drift. Use of a hammer and drift can cause bearings to fragment. Pieces of fragmented bearing could cause eye and soft tissue injuries if suitable protective apparel is not worn.

! Caution

To prevent wheel damage and to aid bearing removal, always apply force evenly on both sides of the bearing to prevent it from 'tipping' and becoming stuck. Application of uneven force will lead to difficulty in removing the bearing and to a damaged wheel.

4. Using a suitable pin punch, through the centre of the wheel, drift out the wheel bearings. Collect the centre sleeve.



Rear Wheel Bearing Removal

Inspection



Warning

Only remove raised witness marks from within the wheel. Removal of material below any raised areas will reduce the level of interference between the wheel and the bearings. Loss of interference could cause the bearing to become loose in the wheel leading to loss of motorcycle control and an accident.

1. Examine the wheel for any raised witness marks caused by the removal process. Remove any such marks with fine emery paper or a gentle file.


Installation

Note:

- Refer to the chart below for the correct tool and tool face when inserting bearings. Bearings are inserted by means of a draw-bolt acting on the insertion tool. A support tool is located on the opposite side of the wheel to the insertion tool and as the bolt is tightened, the bearing is drawn into the wheel.
- Insert bearings with the marked or shielded side facing outwards and always fit a new bearing circlip and seals.

	Bearing insertion tool	Support tool
Left bearing	3880070 - T0301 Small face to bearing	3880065 - T0301 Large face to Wheel
Right bearing	3880070 - T0301 Small face to bearing	3880065 - T0301 Large face to wheel

1. Fit the wheel bearings and centre sleeve using the method described on the previous page.



1. Tool T3880070

2. Fit a new circlip.
3. Lubricate and fit new seals to the rear wheel. Lubricate the seal's knife-edge with grease to NLGI 2 specification (we recommend Mobil HP222).
4. Fit the rear wheel (see page 15-8).

Final Drive

Removal

! Warning


Before starting work, ensure the motorcycle is stabilised and adequately supported. This will help prevent it from falling and causing injury to the operator or damage to the motorcycle.

1. Remove the rear wheel (see page 15-8).

! Caution


Do not allow the wheel to rest on the brake disc, as this may damage the disc. Support the wheel on wooden blocks, equally spaced around the rim, such that the brake disc is raised above the ground.

2. Place the wheel on wooden blocks with the drive sprocket uppermost.
3. Gently lever the drive flange from the wheel hub.



1. Rear wheel
2. Drive flange

4. Remove the cush drive rubbers.



1. Cush drive

Inspection

1. Check the cush drive rubbers for deterioration, cracks etc.
2. Inspect the sprocket teeth for wear, damage and chips.
3. Check the wheel and drive flange for wear, cracks and damage.

Installation

1. Install the cush drive rubbers to the wheel.
2. Refit the drive flange to the wheel.
3. Refit the rear wheel (see page 15-8).

16 Frame and Bodywork


Table of Contents

Exploded View - Frame - all Models	16.3
Exploded View - Rear Subframe - Daytona 675	16.4
Exploded View - Rear Subframe - Street Triple and Street Triple R	16.5
Exploded View - Cockpit and Mountings - Daytona 675 up to VIN 381274	16.6
Exploded View - Cockpit and mountings - Daytona 675 from VIN 381275	16.7
Exploded View - Lower Fairings - Daytona 675	16.8
Exploded View - Rear Panels - Daytona 675	16.9
Exploded View - Rear Panels - Street Triple and Street Triple R	16.10
Exploded View - Footrests and Mountings - Daytona 675	16.11
Exploded View - Footrests and Mountings - Street Triple and Street Triple R	16.12
Exploded View - Sidestand - all Models	16.13
Exploded View - Front Mudguard - all Models	16.14
Exploded View - Rear Mudguard - Daytona 675	16.15
Exploded View - Rear Mudguard - Street Triple and Street Triple R	16.16
Rider's Seat - all models	16.17
Removal	16.17
Refit	16.17
Rear Seat - Daytona 675 only	16.17
Removal	16.17
Refit	16.17
Frame, Footrests and Fixings	16.18
Inspection	16.18
Rear Panel - Daytona 675	16.18
Removal	16.18
Installation	16.18
Rear Panel - Street Triple and Street Triple R	16.19
Removal	16.19
Installation	16.19
Cockpit Infill Panels - Daytona 675	16.20
Removal	16.20
Installation	16.20


Frame and Bodywork

Lower Fairing - Daytona 675	16.20
Removal	16.20
Installation	16.22
Windscreen - Daytona 675 up to VIN 381274	16.22
Removal	16.22
Installation	16.22
Windscreen - Daytona 675 from VIN 381275	16.23
Removal	16.23
Installation	16.23
Cockpit - Daytona 675	16.23
Removal	16.23
Installation	16.24
Radiator Cowl - Street Triple and Street Triple R	16.25
Removal	16.25
Installation	16.25


Exploded View - Frame - all Models




Exploded View - Rear Subframe - Daytona 675




Exploded View - Rear Subframe - Street Triple and Street Triple R




Exploded View - Cockpit and Mountings - Daytona 675 up to VIN 381274




Explode View - Cockpit and mountings - Daytona 675 from VIN 381275




Exploded View - Lower Fairings - Daytona 675




Exploded View - Rear Panels - Daytona 675




Exploded View - Rear Panels - Street Triple and Street Triple R




Exploded View - Footrests and Mountings - Daytona 675




Exploded View - Footrests and Mountings - Street Triple and Street Triple R




Exploded View - Sidestand - all Models



Exploded View - Front Mudguard - all Models




Exploded View - Rear Mudguard - Daytona 675



Frame and Bodywork


Exploded View - Rear Mudguard - Street Triple and Street Triple R



Rider's Seat - all models

Removal

The seat lock is located on the left hand side of the battery tray, in line with the footrest mounting rail. To remove the seat, insert the ignition key into the seat lock and turn it anti-clockwise while pressing down on the rear of the seat. This will release the seat from its lock and allow it to be slid rearwards for complete removal from the motorcycle.



1. Seat lock

Refit

To refit the seat, engage the seat's tongue under the fuel tank and press down at the rear to engage in the seat lock.

Warning

To prevent detachment of the seat during riding, after fitting always grasp the seat and pull firmly upwards. If the seat is not correctly secured it will detach from the lock. A loose or detached seat could cause loss of motorcycle control and an accident.


Caution

To prevent damage to the seat and its cover, care must be taken not to drop the seat. Do not lean the seat against the motorcycle or a wall as it may fall. Instead, place the seat, with the seat cover facing up, on a flat surface which is covered with a soft cloth.

Rear Seat - Daytona 675 only

Removal

To remove the rear seat cover or rear seat (where fitted): Remove the fixing located beneath the padding. This will allow the rear seat/seat cover to be slid forwards for complete removal from the motorcycle.



1. Fixing


Refit

To refit the rear seat, engage the seat's tag under the rear subframe rail and install the fixing. Tighten the seat fixing to **9 Nm**.

Frame, Footrests and Fixings

Inspection

1. Inspect the frame, footrests and fairings for damage, cracks, chafing and other dangerous conditions. Check fairing and frame fixings for security.
2. Inspect the bank angle indicators on the rider's footrests for wear. The bank angle indicators are worn out when **5mm** of the bank indicator remains.



1. Bank angle indicator (Daytona 675 shown)

Warning

Use of a motorcycle with bank angle indicators worn beyond the maximum limit will allow the motorcycle to be banked to an unsafe angle.

Banking to an unsafe angle may cause instability, loss of control and an accident causing injury or death.

Warning

If the motorcycle is involved in an accident or collision it must be taken to an authorised Triumph dealer for repair or inspection.

Any accident can cause damage to the motorcycle which, if not correctly repaired, may cause another accident which may result in injury or death.


Warning

The frame must not be modified as any modification to the frame such as welding or drilling may weaken the frame resulting in an accident.

Rear Panel - Daytona 675

Removal

1. Remove the seats (see page 16-17).
2. Disconnect the battery, negative (black) lead first.
3. To release the rear panel assembly, remove the fixings shown in the illustration below.



Rear panel fixings

4. Gently pull the panel outwards.
5. Lift and withdraw the rear panel assembly in a rearward direction.
6. Disconnect the rear lamp multi-plug.

Installation

1. Installation is the reverse of removal noting the following:


Note:

- Tighten the fixings to 3 Nm.
- Reconnect the battery, positive (red) lead first.

Rear Panel - Street Triple and Street Triple R

Removal


1. Remove the seat (see page 16-17).
2. Disconnect the battery, negative (black) lead first.
3. To release the rear panel assembly, remove the fixings shown in the illustration below.



1. Rear panel (right hand shown)

2. Fixings

4. Gently pull the panel outwards.
5. Release the rear panel locating peg from the grommet on the subframe.



1. Subframe grommet

2. Rear panel locating peg

Installation

1. Installation is the reverse of removal noting the following:

Note:

- Ensure the locating peg is correctly inserted in the subframe grommet.
- Tighten the rear panel fixings to 3 Nm.
- Reconnect the battery, positive (red) lead first.

Cockpit Infill Panels - Daytona 675

Removal

Note:


- Follow the same procedure for both left and right hand sides.

- Remove the rider's seat (see page 16-17).
- Disconnect the battery, negative (black) lead first.

Note:

- From VIN 381275, the front fixing for the right hand infill panel also secures the front of the regulator/rectifier bracket to the fairing.

- Remove the two screws securing the cockpit infill panel.



- Cockpit infill panel
- Fixings
- Remove the panel.

Installation

- Installation is the reverse of removal noting the following:

Note:

- Tighten the fixings to 5 Nm.
- Reconnect the battery, positive (red) lead first.


Lower Fairing - Daytona 675

Removal

Note:


- Follow the same procedure for both left and right hand sides.
- The cockpit does NOT need to be removed in order to remove the lower fairings.

- Remove the rider's seat (see page 16-17).
- Disconnect the battery, negative (black) lead first.
- Remove the cockpit infill panels (see page 16-20).
- Remove the four fixings securing the fairing lower halves to each other.



1. Lower fairing fixings


- Remove the three fixings securing the radiator infill panel to the fairing.



- Radiator infill panel (right hand shown)
- Fixings (one fixing is not shown)

Note:


- From VIN 381275, the fixing for the front right hand indicator also secures the rear of the regulator/rectifier bracket to the fairing
6. From VIN 381275 only: If the left hand fairing is being removed, remove the fixing for the indicator.
 7. Remove the three screws securing the fairing to the fairing brackets.
 8. Remove the screw securing the fairing to the cockpit.
 9. Detach the lower fairing stud from the frame grommet.



1. Lower fairing
2. Fairing retaining screws
3. Fairing to cockpit screw
4. Fairing stud/grommet location (one on each fairing)

Note:

- If the left hand fairing half is being removed, detach the rear fuse box grommet from the fairing stud. The fuse box will remain attached to its forward fixing stud on the headlamp when the lower fairing is removed.



1. Fuse box grommet/stud


10. Ease the panel away from the cockpit to remove it.

11. Disconnect the direction indicator connectors.

Note:

- When the lower fairing is removed the lower infill panel may remain in either fairing half.


12. Remove the lower fairing infill panel.



1. Right hand lower fairing
2. Infill panel
3. Fixing stud/grommet

Installation

1. Refit the lower fairing infill panel to either fairing half.
2. Position the fairing to the rear of the cockpit.
3. Reconnect the direction indicator connectors.
4. Align the fairing stud to the frame grommet and refit.
5. Align the fairing stud to the fuse box grommet and refit.



1. Fuse Box grommet/stud


6. Refit the lower fairing infill panel to the opposite fairing half.
7. Refit the fairing to cockpit lower fixing, and tighten to **3 Nm**.
8. Refit the fairing to the fairing brackets, tighten the fixings to **4 Nm**.
9. **From VIN 381275 only:** If fitting the right hand fairing, fit the indicator fixing and tighten to **3 Nm**. Ensure the fixing secures the alternator rectifier/regulator to the fairing.
10. Refit the radiator infill panel fixings.
11. Refit the lower fairing fixings.
12. Refit the cockpit infill panels (see page 16-20).
13. Reconnect the battery, positive (red) lead first.
14. Refit the rider's seat (see page 16-17).

Windscreen - Daytona 675 up to VIN 381274

Removal

Note:

- It is not necessary to remove the mirrors to remove the windscreen.



1. Windscreen

2. Fixings

1. Release the eight windscreen fixings.
2. Slide the windscreen upwards and to the rear.

Installation

Installation is the reverse of removal noting the following.


Note:

- Tighten the fixings to **0.5 Nm**.

Windscreen - Daytona 675 from VIN 381275


Removal

1. Remove the caps on the mirror securing nuts, release the two nuts and remove the mirror, on both sides.



1. Mirror fixings

2. Release the four windscreen fixings.



1. Windscreen

2. Windscreen fixings

3. Slide the windscreen upwards and to the rear.

Installation

1. Installation is the reverse of removal noting the following:

Note:

- Tighten the windscreen fixings to 0.5 Nm.
- Tighten the mirror fixings to 9 Nm. Refit the nut covers.


Cockpit - Daytona 675

Removal

Note:


- The cockpit is removed as an assembly. It is not necessary to remove the lower fairings, instruments or windscreen. The headlight will remain in the cockpit upon removal.

1. Remove the rider's seat (see page 16-17).
2. Disconnect the battery, negative (black) lead first.
3. Remove the cockpit infill panels (see page 16-20).
4. Remove the caps on the mirror securing nuts and release the two nuts holding each mirror.
5. Remove both mirrors.




1. Mirror fixings

6. Remove the two screws (one on each side) securing the cockpit to each lower fairing.



1. Fairing to cockpit screw

7. Remove the two fixings (one on each side) securing the radiator infill panel to the cockpit.
6. Refit the mirrors, tighten the fixings to **9 Nm**. Refit the nut covers.



1. Cockpit


2. Radiator infill panel fixing (left hand shown)

8. With the aid of an assistant detach the cockpit and disconnect the headlight multi-plug.

Note:

- Before removing the cockpit from the motorcycle, note the exact routing of the cockpit harness.

9. Detach the cockpit wiring harness from the cockpit.
10. Remove the cockpit in a forward direction.



1. Mirror fixings

7. Refit the cockpit infill panels (see page 16-20).
8. Connect the battery, positive (red) lead first.
9. Refit the rider's seat (see page 16-17).


Installation

1. With the aid of an assistant position the cockpit to the motorcycle.
2. Refit the cockpit harness following the routing noted during removal.
3. Reconnect the headlight multi-plug.
4. Refit the cockpit to the lower fairings, tighten the two fixings to **3 Nm**.
5. Refit the two fixings (one on each side) securing the radiator infill panel to the cockpit.

Radiator Cowl - Street Triple and Street Triple R


Removal

1. Remove the rider's seat (see page 16-17).
2. Disconnect the battery, negative (black) lead first.
3. Remove the fuel tank (see page 10-89).
4. Remove the airbox (see page 10-95).
5. Disconnect the front direction indicator connections, located under the airbox.



1. Left hand direction indicator connections
2. Right hand direction indicator connections

6. Release the fixing securing the direction indicator to the radiator cowl.
7. Release the three fixings securing the radiator cowl to the radiator.



1. Radiator cowl
2. Direction indicator fixing
3. Fixings


8. Remove the radiator cowl and, noting the routing of the direction indicator harness, carefully feed the harness through the radiator bracket as the cowl is removed.

Installation

1. Pass the direction indicator harness through the radiator cowl and position the direction indicator to the radiator cowl.
2. Pass the direction indicator harness through the radiator bracket and align the radiator cowl to its fixing holes.

Note:


- Ensure the direction indicator harness passes through the hole in the radiator bracket and is not trapped by the radiator cowl as it is installed.



1. Radiator bracket
2. Direction indicator harness hole
3. Direction indicator fixing hole

3. Route the direction indicator harness inside the frame rail to a position above the camshaft cover. Reconnect the electrical connectors to the main harness.
4. Install the three radiator cowl fixings and the direction indicator fixing and tighten as follows:
 - Tighten the radiator cowl fixings to 5 Nm.
 - Tighten the direction indicator fixing to 4 Nm.
5. Refit the airbox (see page 10-96).
6. Refit the fuel tank (see page 10-90).
7. Reconnect the battery, positive (red) lead first.

- Installation**
1. Turn the direction indicator harness through the radiator cover and position the direction indicator in the radiator cover.
 2. Run the direction indicator harness through the radiator bracket and align the radiator cover to its locking tabs.
- Notes:**
- Ensure the direction indicator harness passes through the hole in the radiator bracket and is not trapped by the radiator cover as it is installed.



This page intentionally left blank

1. Radiator bracket
 2. Direction indicator harness take
 3. Direction indicator harness take
 4. Direction indicator harness take
1. Remove the direction indicator harness inside the frame rail to a position above the control cover. Reconnect the electrical connector to the main harness.
 2. Install the three radiator cover hinges and the direction indicator hinge and tighten as follows:
 - Tighten the radiator cover hinges to 2 Nm.
 - Tighten the direction indicator hinge to 2 Nm.
 3. Refit the radiator cover page 10-94.
 4. Refit the fuel tank page 10-95.
 5. Reconnect the battery, negative earth lead first.

Radiator Cover - Street Triple and Street Triple R

- Removal**
1. Disconnect the battery, negative earth lead first.
 2. Remove the fuel tank page 10-95.
 3. Remove the radiator cover page 10-94.
 4. Disconnect the fuel tank electrical connector.
 5. Remove the fuel tank page 10-95.



1. Tighten the three hinges securing the radiator cover to a radiator.
2. Remove the three hinges securing the radiator cover to the radiator cover.
3. Remove the radiator cover and disconnect the electrical connector.



1. Radiator cover
2. Direction indicator harness
3. Hinge
4. Remove the radiator cover and noting the routing of the direction indicator harness, carefully feed the harness through the radiator bracket in the rear of the radiator cover.

17 Electrical

Table of Contents

Exploded View - Instruments - Daytona 675.....	17.5
Exploded View - Instruments - Street Triple and Street Triple R.....	17.6
Exploded View - Headlight - Daytona 675.....	17.7
Exploded View - Headlights - Street Triple and Street Triple R.....	17.8
Exploded View - Rear Light & Licence Plate Light - all Models.....	17.9
Exploded View - Direction Indicators - Daytona 675 up to VIN 381274.....	17.10
Exploded View - Direction Indicators - Daytona 675 from VIN 381275.....	17.11
Exploded View - Direction Indicators - Street Triple and Street Triple R.....	17.12
Exploded View - Alternator and Starter - All Models.....	17.13
Battery.....	17.14
Battery Removal.....	17.14
Battery Refit.....	17.15
Battery Commissioning and Charging.....	17.15
New Battery.....	17.15
Battery Maintenance.....	17.16
Battery Already in Service.....	17.17
Table of Battery Charging Times.....	17.17
Relays - Daytona 675.....	17.18
Relay Identification.....	17.18
Direction Indicator Unit.....	17.18
Fuel Pump Relay.....	17.18
Relays - Street Triple and Street Triple R.....	17.18
Relay Identification.....	17.18
Fuses.....	17.19
Fuse Identification - Daytona 675.....	17.19
Fuse Identification - Street Triple and Street Triple R.....	17.20
Instrument Pack - Daytona 675.....	17.20
Removal.....	17.20
Installation.....	17.21
Instrument Pack - Street Triple and Street Triple R.....	17.21
Removal.....	17.21
Installation.....	17.22


Electrical

Headlights - Daytona 675	17.22
Headlight Adjustment	17.22
Headlight Bulb Replacement	17.23
Installation	17.23
Position Lamp Bulb Replacement	17.23
Headlight Assembly - Daytona 675	17.24
Removal	17.24
Installation	17.24
Headlights - Street Triple and Street Triple R.	17.24
Headlight Adjustment	17.24
Headlight Bulb Replacement	17.25
Position Lamp Bulb Replacement	17.25
Rear Light - Daytona 675	17.26
Removal	17.26
Installation	17.26
Rear Light - Street Triple and Street Triple R.	17.26
Removal	17.26
Installation	17.27
Direction Indicators	17.27
Bulb Replacement	17.27
Rear Direction Indicator - Daytona 675	17.28
Removal	17.28
Installation	17.28
Rear Direction Indicator - Street Triple and Street Triple R	17.28
Removal	17.28
Installation	17.29
Front Direction Indicator - Daytona 675	17.30
Removal	17.30
Installation	17.30
Front Direction Indicator- Street Triple and Street Triple R	17.30
Removal	17.30
Installation	17.31
Licence Plate Light	17.31
Bulb Replacement	17.31
Starter Motor	17.32
Removal	17.32
Inspection	17.32
Installation	17.32
Alternator	17.33
Removal	17.33
Assembly	17.34
Alternator Rectifier	17.35
Daytona 675 up to VIN 381274, Street Triple and Street Triple R all VINs.	17.35
Daytona 675 from VIN 381275	17.35


Alternator Stator	17.36
Pinpoint Tests	17.36
Rectifier/Regulator	17.38
Pinpoint Tests	17.38
Lighting Circuit - Daytona 675 up to VIN 381274	17.40
Key to circuit diagram	17.40
Key to wiring colours	17.40
Lighting Circuit - Daytona 675 up to VIN 381274	17.41
Lighting Circuit - Daytona 675 from VIN 381275	17.42
Key to circuit diagram	17.42
Key to wiring colours	17.42
Lighting Circuit - Daytona 675 from VIN 381275	17.43
Starting and Charging Circuit - Daytona 675 up to VIN 381274	17.44
Key to circuit diagram	17.44
Key to wiring colours	17.44
Starting and Charging Circuit - Daytona 675 up to VIN 381274	17.45
Starting and Charging Circuit - Daytona 675 from VIN 381275	17.46
Key to circuit diagram	17.46
Key to wiring colours	17.46
Starting and Charging Circuit - Daytona 675 from VIN 381275	17.47
Auxiliary and Accessory Circuit - Daytona 675 up to VIN 381274	17.48
Key to circuit diagram	17.48
Key to wiring colours	17.48
Auxiliary and Accessory Circuit - Daytona 675 up to VIN 381274	17.49
Auxiliary and Accessory Circuit - Daytona 675 from VIN 381275	17.50
Key to circuit diagram	17.50
Key to wiring colours	17.50
Auxiliary and Accessory Circuit - Daytona 675 from VIN 381275	17.51
Lighting Circuit - Street Triple and Street Triple R	17.52
Key to circuit diagram	17.52
Key to wiring colours	17.52
Lighting Circuit - Street Triple and Street Triple R	17.53
Starting and Charging Circuit - Street Triple and Street Triple R	17.54
Key to circuit diagram	17.54
Key to wiring colours	17.54
Starting and Charging Circuit - Street Triple and Street Triple R	17.55
Auxiliary and Accessory Circuit - Street Triple and Street Triple R	17.56
Key to circuit diagram	17.56
Key to wiring colours	17.56
Auxiliary and Accessory Circuit - Street Triple and Street Triple R	17.57
Complete System - Daytona 675 up to VIN 300525 with/without Fuel Pump Relay Modification	17.58
Key to circuit diagram	17.58

Complete System - Daytona 675 from VIN 300526 to VIN 323544 with Fuel Pump Relay	17.60
Key to circuit diagram.....	17.60
Complete System - Daytona 675 - from VIN 323545 to VIN381274	17.62
Key to circuit diagram.....	17.62
Key to wiring colours.....	17.62
Complete System - Daytona 675 - from VIN 381275	17.64
Key to circuit diagram.....	17.64
Complete System - Street Triple and Street Triple R	17.66
Key to circuit diagram.....	17.66
Key to wiring colours.....	17.66


Exploded View - Instruments - Daytona 675




Exploded View - Instruments - Street Triple and Street Triple R




Exploded View - Headlight - Daytona 675




Exploded View - Headlights - Street Triple and Street Triple R




Exploded View - Rear Light & Licence Plate Light - all Models




Exploded View - Direction Indicators - Daytona 675 up to VIN 381274




Exploded View - Direction Indicators - Daytona 675 from VIN 381275



Exploded View - Direction Indicators - Street Triple and Street Triple R



Exploded View - Alternator and Starter - All Models



Battery

Warning

The battery gives off explosive gases; keep sparks, flames and cigarettes away. Provide adequate ventilation when charging or using the battery in an enclosed space.

The battery contains sulphuric acid (electrolyte). Contact with skin or eyes may cause severe burns. Wear protective clothing and a face shield.

- If electrolyte gets on your skin, flush with water immediately.
- If electrolyte gets in your eyes, flush with water for at least 15 minutes and SEEK MEDICAL ATTENTION IMMEDIATELY.
- If electrolyte is swallowed, drink large quantities of water and SEEK MEDICAL ATTENTION IMMEDIATELY.

KEEP ELECTROLYTE OUT OF THE REACH OF CHILDREN.

Warning

The battery contains harmful materials. Always keep children away from the battery whether or not it is fitted in the motorcycle.


Do not jump start the battery, touch the battery cables together or reverse the polarity of the cables as any of these actions may cause a spark which would ignite battery gasses causing a risk of personal injury.

Warning

The battery electrolyte is corrosive and poisonous. Never swallow battery electrolyte or allow electrolyte to come into contact with the skin. Always wear eye and skin protection when adjusting the electrolyte level.

Battery Removal


Daytona 675



cdlt

1. Battery
2. Negative (-) terminal
3. Positive (+) terminal
4. Battery strap

Street Triple and Street Triple R



1. Battery
2. Negative (-) terminal
3. Positive (+) terminal
4. Battery strap
5. Battery strap band

1. Remove the rider's seat (see page 16-17).
2. Disconnect the battery, negative (black) lead first.
3. Remove the battery strap. On Street Triple, note the orientation of the strap and the fitted position of the band around the rear of the battery.
4. Take the battery out of the case.

Warning

Ensure that the battery terminals do not touch the motorcycle frame as this may cause a short circuit or spark which would ignite battery gases causing a risk of personal injury.

Battery Refit

Warning

Ensure that the battery terminals do not touch the motorcycle frame as this may cause a short circuit or spark which would ignite battery gases causing a risk of personal injury.

1. Place the battery in the battery case.
2. Reconnect the battery, positive (red) lead first.
3. Apply a light coat of grease to the terminals to prevent corrosion.
4. Cover the terminals with the protective caps.
5. Refit the battery strap. On Street Triple, ensure the strap is fitted with the band towards the rear of the motorcycle. Hook the battery strap band around the rear of the battery as noted on removal.
6. Refit the rider's seat (see page 16-17).

Battery Commissioning and Charging

New Battery

In order to correctly and safely commission a new battery, the battery commissioning procedure listed below must be carefully followed. This is the only battery commissioning procedure that Triumph recommends. The procedure is designed to ensure that the battery is at its best when fitted to the motorcycle, and will provide the best possible performance and reliability.

Failure to comply with this procedure may lead to reduced battery performance and/or shorten the life of the battery.

Warning

The battery gives off explosive gases; keep sparks, flames and cigarettes away. Provide adequate ventilation when charging or using the battery in an enclosed space.

The battery contains sulphuric acid (electrolyte). Contact with skin or eyes may cause severe burns. Wear protective clothing and a face shield.

- If electrolyte gets on your skin, flush with water immediately.
- If electrolyte gets in your eyes, flush with water for at least 15 minutes and **SEEK MEDICAL ATTENTION IMMEDIATELY.**
- If electrolyte is swallowed, drink large quantities of water and **SEEK MEDICAL ATTENTION IMMEDIATELY.**

KEEP ELECTROLYTE OUT OF THE REACH OF CHILDREN.

1. Ensure the VIN number printed on the anti-tamper label attached to the battery matches the motorcycle VIN.
2. Read the instructions and warnings delivered with the battery.
3. Place the battery on a flat level surface and remove the sealing foil.

Caution

Ensure the electrolyte container part number matches the battery part number to be filled. Battery life will be greatly reduced if the incorrect volume (either too little or too much) of acid is added to the battery.

4. Remove the battery sealing strip from the electrolyte container (if applicable) and save for later in this procedure. Place the sealing strip on a clean surface, with the upper side facing downwards to avoid contamination of the sealing strip. Do not break the seal on the electrolyte container.
5. Place the electrolyte container and adapter (if applicable) on the battery and fill the battery according to the manufacturers instructions.
6. After starting to fill the battery with electrolyte, allow the battery to stand for 30 minutes with the filling container in place.
7. Check that all of the electrolyte has drained from the container. Do not remove the container at this point. If the container has not completely drained, tap the sides of the container to start the electrolyte flowing again.

8. After the electrolyte has drained into the battery, allow the battery to stand with the electrolyte container in place for a further 30 minutes for batteries 3Ah - 12Ah or 1 hour for batteries greater than 12Ah.
9. Remove the electrolyte container and adapter carefully, and dispose of immediately.
10. Place the sealing cap strip LOOSELY over the filling holes of the battery.
11. Charge the battery using the BatteryMate 150-9. Refer to the instructions supplied with the BatteryMate 150-9.



Caution

The caps must be fitted (after charging) within two hours of filling the battery with acid. Leaving the battery open to the atmosphere for longer than is necessary will start to reverse the chemical reaction which takes place within the battery, greatly reducing the battery life.

12. After charging is complete, press down firmly with both hands to seat the caps (do not use tools or force the caps into position).
13. Disconnect the charger and allow the battery to stand for 1 hour before fitting to the motorcycle.
14. Fit the battery to the motorcycle, positive (red) lead first.

Battery Maintenance

The battery is a sealed type and does not require any maintenance other than routine recharging such as during storage.

It is not possible to adjust the electrolyte level in the battery.

Note:

- **The charge level in the battery must be maintained to maximise the battery life.**

With normal use of the motorcycle, the charging system will keep the battery charged. If the motorcycle is unused the battery will gradually discharge due to battery self discharge and the continuous current drain for the clock and the engine control module memory.

The rate of battery discharge can be greatly increased by the addition of electrical security systems or other accessories.

If the motorcycle is used for very short journeys, the alternator will not have enough time to replenish the charge used to start and run it. Therefore, the battery should be charged after each return journey following the instructions and advice given here and in the owner handbook under the sections Battery Discharge and Battery Discharge During Storage and Infrequent Use of the Motorcycle.

Allowing a battery to discharge, or leaving it discharged over a period of time, causes sulphation of the lead plates within the battery.

Sulphation is a normal chemical reaction inside the battery and over a period of time sulphate will crystallise on to the lead plates making charging difficult or impossible. The result is a permanently damaged battery, which would not be covered by the motorcycle warranty.

Keeping a battery at full charge reduces the chance of it freezing in cold conditions. Allowing a battery to freeze can cause serious internal damage to the battery.

When leaving the motorcycle standing for more than a few days, regularly check the battery Voltage using a digital multimeter. Should the battery Voltage fall below 12.8V, charge the battery using the BatteryMate 150-9. Refer to the instructions supplied with the BatteryMate 150-9.

For extended periods of storage (beyond two weeks) the battery should be removed and the battery Voltage checked regularly and charged when below 12.8V.

Battery Already in Service

Use the guidelines in the table below for charging. Always verify the battery condition before charging, and 30 minutes after charging.

Note:

- A fully charged battery should read **12.8 volts or higher** after the battery has been off the charger for **30 minutes or more**.


Table of Battery Charging Times

State of charge	Voltage	Action	Charge time (using BatteryMate 150-9)
100%	12.8V - 13.0V	None. Check at 6 months from date of manufacture	None required
75% - 100%	12.5V - 12.8V	May need slight charge. If no charge given, check in 3 - 4 months	3 - 6 hours
50% - 75%	12.0V - 12.5V	Needs charge	5 - 11 hours
25% - 50% V	11.5V - 12.0V	Needs charge	at least 13 hours
0% - 25%	11.5V or less	Needs recovery using BatteryMate 150-9. Re-test after recovery	20 hours

Relays - Daytona 675

The relay pack is located beneath the left hand fairing infill panel, adjacent to the fuse box. To gain access to the relays, remove the left hand infill panel (see page 16-20).


Relay Identification



1. Cooling fan relay
2. Engine management system (EMS) main relay
3. Starter relay
4. Fuse box


Direction Indicator Unit

The direction indicator unit is located behind the left hand lower fairing, adjacent to the vacuum reservoir for the intake air flap.



1. Direction indicator unit
2. Vacuum reservoir


Fuel Pump Relay



Relays - Street Triple and Street Triple R

The relay pack is located beneath the fuel tank. To gain access to the relays, raise and support the fuel tank (see page 10-91).

Relay Identification



1. Fuel Pump relay
2. Cooling fan relay
3. Engine management system (EMS) main relay
4. Starter relay
5. Direction indicator unit
6. Fuse box

Fuses

If a fuse fails during operation, inspect the electrical system to determine the cause, and then replace it with a new fuse of the correct current rating.

A blown fuse is indicated when all of the systems protected by that fuse become inoperative. When checking for a blown fuse, use the table below to establish which fuse has blown.

Note:

- On both models, the starter solenoid has an additional 30 Amp fuse attached directly to the solenoid, beneath the rider's seat.




Warning

Always replace blown fuses with new ones of the correct current rating (as specified on the fuse box cover) and never use a fuse of higher rating. Although no spare 5 Amp. fuse is supplied in the fuse box, it is strongly recommended that a spare 5 Amp. fuse be carried.

Fuse Identification - Daytona 675

Fuses are arranged in the fuse box located beneath the left hand fairing infill panel.

To gain access to the fuse box, remove the left hand infill panel (see page 16-20).




cdmm

Arrowed: Fuse Box

Fuse No.	Circuits Protected	Fuse Rating
1	Dip and main beam headlights, starter relay	15
2	Ignition switch, starter circuit	10
3	Auxiliary lighting	5
4	Horn, indicators, alarm	10
5	Cooling fan	15
6	Engine management system	20

The fuse identification numbers listed correspond with those printed on the fuse box cover.




1. Fuse box
2. Fuse box cover
3. Spare fuses

Fuse Identification - Street Triple and Street Triple R

Fuses are arranged in the fuse box located beneath the fuel tank.


To gain access to the fuse box, raise and support the fuel tank (see page 10-91).



Arrowed: Fuse Box

Fuse No.	Circuits Protected	Fuse Rating
1	Dip and main beam headlights, starter relay	20
2	Ignition switch, starter circuit	10
3	Auxiliary lighting	5
4	Horn, indicators, alarm	10
5	Cooling fan	15
6	Engine management system	20

The fuse identification numbers listed correspond with those printed on the fuse box cover.




1. Fuse box
2. Fuse box cover
3. Spare fuses


Instrument Pack - Daytona 675

Removal

1. Remove the rider's seat (see page 16-17).
2. Disconnect the battery, negative (black) lead first.
3. Remove the cockpit (see page 16-23).
4. Release the four fixings securing the instrument bracket to the air intake duct. Collect the fall detection switch and bracket from the right hand side of the instrument bracket.



1. Instrument bracket
2. Instrument pack
3. Instrument bracket fixings (right hand shown)
4. Fall detection switch and bracket
5. Raise the instrument pack and disconnect the electrical connection to the main harness. Remove the pack and bracket.
6. Release the fixing securing the instrument pack to the bracket.




1. Instrument pack
2. Instrument bracket
3. Fixing
4. Bayonet fixings

7. Remove the instrument pack from the bracket.

Installation

1. Position the instrument pack to the bracket.
2. Insert the bayonet fixings into the grommets.
3. Refit the fixing and tighten to **3 Nm**.
4. Connect the instruments to the harness.
5. Place the instrument bracket in position on the air intake duct and reposition the fall detection switch and its bracket. Refit the fixings.



1. Instrument bracket
2. Instrument pack
3. Instrument bracket fixings (right hand shown)
4. Fall detection switch and bracket

6. Tighten the bracket fixings to **7 Nm**.
7. Refit the cockpit (see page 16-24).
8. Reconnect the battery, positive (red) lead first.
9. Refit the rider's seat (see page 16-17).

Instrument Pack - Street Triple and Street Triple R

Removal


1. Remove the rider's seat (see page 16-17).
2. Disconnect the battery, negative (black) lead first.
3. Remove the cover and gasket attached to the rear of the instruments.

Note:

- The cover is held in place by bayonet type fixings. Gently pull on the cover to release it.




1. Instrument cover
2. Bayonet fixings
3. Gasket
4. Disconnect the electrical connector from the instruments.
5. Remove the screw and release the instrument pack from the bracket bayonet fixings.



1. Screw
2. Washer
3. Bayonet fixings
4. Electrical connector

Installation

1. Position the instrument pack to the bracket.
2. Insert the bayonet fixings into the grommets.
3. Refit the fixing and tighten to **3 Nm**.
4. Connect the instruments to the harness.



ced

1. Screw
2. Washer
3. Bayonet fixings
4. Electrical connector


5. Install the cover and gasket to the rear of the instruments, ensuring the bayonet fixings are fully inserted in the grommets on the instrument bracket.
6. Reconnect the battery, positive (red) lead first.
7. Refit the rider's seat (see page 16-17).

Headlights - Daytona 675

Headlight Adjustment

Note:

- Each headlight can be adjusted by means of vertical and horizontal adjustment screws located on the rear of each headlight.



odnw

1. Horizontal adjustment screw (left hand)
2. Vertical adjustment screw (left hand)
3. Horizontal adjustment screw (right hand)
4. Vertical adjustment screw (right hand)
5. Pivot screws (DO NOT adjust these screws)

1. Switch the headlight dipped beam on.



Caution

Do not adjust the pivot screws as this could cause the headlight reflector to become detached from the pivot screw, leading to irreparable damage to the headlight.


2. Turn the vertical adjustment screws on each headlight clockwise to raise the beam or anti-clockwise to lower the beam.
3. On the right hand headlight turn the horizontal adjustment screw clockwise to move the beam to the left or anti-clockwise to move the beam to the right.
4. On the left hand headlight turn the horizontal adjustment screw clockwise to move the beam to the right or anti-clockwise to move the beam to the left.
5. Switch the headlights off when both beam settings are satisfactorily set.



Warning

Adjust road speed to suit the visibility and weather conditions in which the motorcycle is being operated. Ensure that the beam is adjusted to illuminate the road surface sufficiently far ahead without dazzling oncoming traffic. An incorrectly adjusted headlight may impair visibility causing an accident.

Headlight Bulb Replacement



1. Headlight unit
2. Bulb retainer

Each headlight bulb can be replaced as follows:



Warning

The bulb becomes hot during use. Always allow sufficient time for the bulb to cool before handling. Avoid touching the glass part of the bulb. If the glass is touched or gets dirty, clean with alcohol before re-use.



Warning

Do not reconnect the battery until the assembly process has been completed. Premature battery reconnection could result in ignition of the battery gases causing risk of injury.

1. Remove the rider's seat (see page 16-17).
2. Disconnect the battery, negative (black) lead first.
3. Remove the fairing infill panel (see page 16-20).
4. Remove the four screws and remove the bulb cover from the bulb to be replaced.
5. Disconnect the multi-plug from the bulb retainer.

6. Detach the bulb retainer from the headlight assembly by rotating it anti-clockwise.
7. Remove the bulb from the bulb retainer.

Installation

1. Installation is the reverse of removal, noting the following:


Note:

- When reconnecting the battery, connect the positive (red) lead first.

Position Lamp Bulb Replacement

The position lamps are fitted to the left and right of each headlight. To replace a bulb, remove the two screws and remove the bulb cover, detach the rubber retainer from the headlight and pull out the bulb.

Installation is the reverse of the removal procedure.




1. Bulb holder
2. Position lamp bulb

Headlight Assembly - Daytona 675

Removal

1. Remove the rider's seat (see page 16-17).
2. Disconnect the battery, negative (black) lead first.
3. Remove the cockpit (see page 16-23).
4. Release the four fixings securing the headlight to the cockpit. Remove the headlight.



1. Headlight
2. Fixings

Installation

1. Installation is the reverse of removal, noting the following:

Note:

- Tighten the headlight fixings to 3 Nm.
- Reconnect the battery, positive (red) lead first.

Headlights - Street Triple and Street Triple R

Headlight Adjustment


Note:

- The vertical beams of the left hand and right hand headlights can only be adjusted together. Independent adjustment is not possible.



1. Vertical adjuster fixings

1. Switch the headlight dipped beam on.
2. Remove the adjuster cover.
3. Slacken the clamp bolt sufficient to allow restricted movement of the headlights.
4. Adjust the position of the headlights to give the required beam setting.
5. Tighten the clamp bolt to 30 Nm.
6. Re-check the headlight beam settings.
7. Switch the headlights off when both beam settings are satisfactorily set.
8. Refit the adjuster cover.



1. Horizontal beam adjusters

Note:


- The horizontal beams of both headlights can be adjusted individually. The same procedure is used to adjust either headlight.
9. Switch the headlight dipped beam on.
 10. Slacken the headlight bowl fixing.
 11. Adjust the horizontal position of the headlight to give the required beam setting.
 12. Tighten the clamp bolt to **15 Nm**.
 13. Repeat for the second headlight.
 14. Re-check the headlight beam settings.
 15. Switch the headlights off when both beam settings are satisfactorily set.

Warning

Adjust road speed to suit the visibility and weather conditions in which the motorcycle is being operated.

Ensure that the headlight beam is adjusted to illuminate the road surface sufficiently far ahead without dazzling oncoming traffic. An incorrectly adjusted headlight may impair visibility causing an accident.

Headlight Bulb Replacement



- cbnnp
1. Headlight bulb
 2. Bulb clip
 3. Position lamp

Each headlight bulb can be replaced as follows:

Warning

The bulb becomes hot during use. Always allow sufficient time for the bulb to cool before handling. Avoid touching the glass part of the bulb. If the glass is touched or gets dirty, clean with alcohol before re-use.

Warning

Do not reconnect the battery until the assembly process has been completed. Premature battery reconnection could result in ignition of the battery gases causing risk of injury.

1. Disconnect the battery, negative (black) lead first.
2. Release the clamp screw for the headlight bezel.
3. Support the headlight and remove the bezel. Ease the headlight from the headlight bowl.
4. Disconnect the multi-pin electrical connector from the headlight bulb, then remove the rubber cover.
5. Unhook the wire retaining clip from behind the bulb.
6. Remove the bulb from the headlight unit.
7. Installation is the reverse of the removal procedure. Tighten the clamp screw to **4 Nm**.

Note:

- When reconnecting the battery, connect the positive (red) lead first.

Position Lamp Bulb Replacement

Position lamp bulbs are fitted to both headlight units. To replace a position light bulb, remove the headlight unit from the headlight bowl to gain access for position light bulb replacement.


Rear Light - Daytona 675

Removal

Note:

- The rear light is a sealed for life unit and must be replaced in the event of a failure.

1. Remove the seats (see page 16-17).
2. Disconnect the battery, negative (black) lead first.
3. Remove the rear panel (see page 16-18).
4. Release the fixings securing the light unit to the rear panel.



- cdwt
1. Rear light unit
 2. Rear light fixings
5. Remove the rear light.

Installation

1. Installation is the reverse of the removal procedure.

Note:

- Tighten the rear light to rear panel fixings to 4 Nm.
- Reconnect the battery, positive (red) lead first.


Rear Light - Street Triple and Street Triple R

Removal


Note:

- The rear light is a sealed for life unit and must be replaced in the event of a failure.

1. Remove the seat (see page 16-17).
2. Disconnect the battery, negative (black) lead first.
3. Remove the rear panels (see page 16-19).
4. Loosen the rear light finisher fixing, located below the rear mudguard.




- oerm
1. Rear light finisher fixing
5. Remove the rear light finisher.



- oero
1. Rear light finisher

6. Release the fixings securing the rear light unit to the rear subframe.



1. Rear light unit
2. Rear light fixings

7. Disconnect the electrical connector and remove the rear light.

Installation

1. Installation is the reverse of the removal procedure.


Note:

- Tighten the rear light to rear subframe fixings to 4 Nm.
- Tighten the rear light finisher fixing to 3 Nm.
- Reconnect the battery, positive (red) lead first.

Direction Indicators

Bulb Replacement

Daytona 675 up to VIN 381274




1. Direction indicator lens
2. Screw

The lens on each direction indicator is held in place by a securing screw located in the body of the light.

Release the screw and remove the amber lens to gain access to the bulb for replacement.

Daytona 675 from VIN 381275, Street Triple and Street Triple R all VINs



1. Direction indicator lens
2. Screw


The lens on each direction indicator is held in place by a securing screw located in the lens of the light.

Release the screw and remove the lens to gain access to the bulb for replacement.

Rear Direction Indicator - Daytona 675

Removal

1. Remove the rider's seat (see page 16-17).
2. Disconnect the battery, negative (black) lead first.
3. Release the fixing securing the direction indicator to the licence plate bracket and detach the light unit.
4. Disconnect the two direction indicator electrical connectors and remove the light unit.



1. Direction indicator (left hand shown)
2. Fixing

Installation

1. Installation is the reverse of the removal procedure, noting the following.


Note:

- Tighten the direction indicator fixing to 3 Nm.
- Reconnect the battery, positive (red) lead first.

Rear Direction Indicator - Street Triple and Street Triple R


Removal

1. Remove the seat (see page 16-17).
2. Disconnect the battery, negative (black) lead first.
3. Remove the rear panels (see page 16-19).
4. Loosen the rear light finisher fixing, located below the rear mudguard.




1. Rear light finisher fixing

5. Remove the rear light finisher.




1. Rear light finisher

6. Release the fixings securing the light unit to the rear subframe.



1. Rear light unit
2. Rear light fixings


7. Disconnect the electrical connector and remove the rear light.
8. Remove and discard the two fixings securing the indicator mount panel.



1. Indicator mount panel
2. Fixings

9. Release the fixings securing the direction indicators to the licence plate bracket and detach the direction indicators together with the indicator mount panel.
10. Disconnect the direction indicator and licence plate light electrical connectors.

11. Noting the routing of the indicator and licence plate harnesses, remove the direction indicators from the indicator mount panel.



1. Indicator mount panel
2. Right hand direction indicator harness
3. Left hand direction indicator harness
4. Licence plate light harness

Installation

1. Installation is the reverse of the removal procedure, noting the following.


Note:

- Ensure the direction indicator and licence plate harnesses are routed as noted on removal.
- Tighten the direction indicator fixings to 3 Nm.
- Fit new fixings for the indicator mount panel and tighten to 4 Nm.
- Tighten the rear light to rear subframe fixings to 4 Nm.
- Tighten the rear light finisher fixing to 3 Nm.
- Reconnect the battery, positive (red) lead first.

Front Direction Indicator - Daytona 675

Removal

1. Remove the rider's seat (see page 16-17).
2. Disconnect the battery, negative (black) lead first.
3. Remove the lower fairing (see page 16-20).
4. Release the fixing securing the direction indicator to the lower fairing and remove the light unit.



- 1. Direction indicator (right hand shown)**
2. Fixing

Installation

1. Installation is the reverse of the removal procedure, noting the following.


Note:

- Tighten the direction indicator fixing to 3 Nm.
- Reconnect the battery, positive (red) lead first.

Front Direction Indicator- Street Triple and Street Triple R


Removal

1. Remove the rider's seat (see page 16-17).
2. Disconnect the battery, negative (black) lead first.
3. Remove the fuel tank (see page 10-89).
4. Remove the airbox (see page 10-95).
5. Disconnect the front direction indicator connections, located under the airbox.



- 1. Left hand direction indicator connections**
2. Right hand direction indicator connections

6. Release the fixing securing the direction indicator to the radiator cowl.
7. Release the three fixings securing the radiator cowl to the radiator.



- 1. Radiator cowl**
2. Direction indicator fixing
3. Fixings

8. Remove the radiator cowl and, noting the routing of the direction indicator harness, carefully feed the harness through the radiator bracket as the cowl is removed.


9. Remove the direction indicator from the radiator cowl.

Installation

1. Pass the direction indicator harness through the radiator cowl and position the direction indicator to the radiator cowl.
2. Pass the direction indicator harness through the radiator bracket and align the radiator cowl to its fixing holes.

Note:

- Ensure the direction indicator harness passes through the hole in the radiator bracket and is not trapped by the radiator cowl as it is installed.



0689

1. Radiator bracket

2. Direction indicator harness hole


3. Direction indicator fixing hole

3. Route the direction indicator harness inside the frame rail to a position above the camshaft cover. Reconnect the electrical connectors to the main harness.
4. Install the three radiator cowl fixings and the direction indicator fixing and tighten as follows:
 - Tighten the radiator cowl fixings to **5 Nm**.
 - Tighten the direction indicator fixing to **4 Nm**.
5. Refit the airbox (see page 10-96).
6. Refit the fuel tank (see page 10-90).
7. Reconnect the battery, positive (red) lead first.
8. Refit the rider's seat (see page 16-17).

Licence Plate Light

Bulb Replacement

1. Release the screw and detach the licence plate light from the licence plate bracket.
2. Carefully remove the rubber bulb holder from the back of the light unit and remove the bulb.



cbhz

1. Bulb holder


2. Bulb

3. Installation is the reverse of the removal procedure.

Starter Motor

Removal

1. Remove the rider's seat (see page 16-17).
2. Disconnect the battery, negative (black) lead first.
3. Remove the fuel tank (see page 10-89).
4. Remove the airbox (see page 10-95).
5. Remove the throttle bodies (see page 10-106).
6. Disconnect the low oil pressure warning light switch.
7. Ease the boot from the starter cable terminal and then release the cable bolt.
8. Detach the cable.
9. Release the fixings securing the starter to the crankcase.



1. Starter motor

2. Starter cable fixing

3. Fixings

10. Ease the starter motor from the upper crankcase.

Inspection

1. Ensure the starter turns freely and without binding.
2. Check the starter O-ring for damage and deterioration. Replace as necessary.


Installation

1. Lubricate the starter motor O-ring with a small amount of petroleum jelly.
2. Fit the starter motor to the upper crankcase ensuring that the O-ring does not become damaged during installation.
3. Fit and tighten the starter bolts to **10 Nm**.
4. Refit the starter cable and secure with the bolt. Tighten to **3 Nm**.
5. Refit the starter cable boot.
6. Connect the low oil pressure warning light switch.
7. Refit the throttle bodies (see page 10-108).
8. Refit the airbox (see page 10-96).
9. Refit the fuel tank (see page 10-90).
10. Reconnect the battery, positive (red) lead first.
11. Refit the rider's seat (see page 16-17).

Alternator

Removal

1. Remove the rider's seat (see page 16-17).
2. **Daytona 675 only:** Remove the left hand lower fairing (see page 16-20).
3. Disconnect the battery, negative (black) lead first.
4. Release the bolts securing the left hand engine cover, noting the position of the copper washer under the head of one of the upper bolts. Collect the solenoid/fairing bracket from under the front two bolts.




1. Left hand engine cover
2. Copper washer position
3. Solenoid/fairing bracket

5. Withdraw the cover from the crankcase against the pull of the alternator magnet.

Note:

- The stator and crankshaft position sensor are supplied as an assembly and cannot be separated.
6. To remove the stator and crankshaft position sensor from the cover, release the three bolts in the centre of the cover and release the bolt securing the cable bracket. Discard the bolts.

7. Release and discard the fixings securing the crankshaft position sensor to the cover.




1. Stator
2. Stator fixings
3. Crankshaft position sensor
4. Crankshaft position sensor fixings
5. Cable bracket
6. Cable bracket fixing
8. Withdraw the stator and crankshaft position sensor.



Caution

Do not use tools to tighten service tool T3880375. Tighten the tool by hand only. Over-tightening of the tool will lead to damage to the alternator rotor.


9. To remove the rotor, clean the alternator rotor to remove all traces of oil, and fit tool T3880375 to the rotor as shown below. Retain the tool to prevent the crankshaft from rotating and remove the centre bolt from the crankshaft.



cdwv1

1. Rotor
2. Tool T3880375
3. Centre bolt

10. With the bolt removed, locate the spigot from the larger of the two thrust pads supplied with tool T3880365 to the crankshaft.



cdwv1


1. Thrust pad

11. Assemble tool T3880365 to the threaded centre section of the rotor.

Note:

- Ensure that the thrust pad does not fall out during assembly of the tool.

12. Hold the centre of the tool to prevent rotation then tighten the draw-bolt in the centre of the tool to release the taper seating of the rotor from the crankshaft.



cdwv

1. Rotor
2. Tool T3880365

13. Withdraw the rotor and tool as an assembly and then separate the tool from the rotor. Collect the Woodruff Key and the tool thrust pad from the crankshaft.

Assembly

1. Refit the Woodruff key to the crankshaft.
2. Assemble the rotor to the keyway on the crankshaft, ensuring the Woodruff key remains in position.




Caution

Do not use tools to tighten service tool T3880375. Tighten the tool by hand only. Over-tightening of the tool will lead to damage to the alternator rotor.

3. Refit tool T3880375 to prevent the crankshaft from rotating, ensuring the rotor is free from oil and the tool is not over-tightened.

4. Tighten the rotor retaining bolt to **120 Nm**.




1. Rotor

2. Tool T3880375

3. Centre bolt

5. Remove tool T3880375.
6. Locate the stator and crankshaft position sensor to the engine cover.
7. Apply silicone sealer to the cable grommet (at the factory, ThreeBond 1215 is used) and align the cable to the exit slot.
8. Fit the cable retainer bracket and tighten a new retainer bolt to **6 Nm**.
9. Tighten the new stator bolts to **12 Nm**.
10. Tighten the new crankshaft position sensor bolts to **6 Nm**.
11. Position a new gasket to the crankcase dowels then refit the left hand engine cover.
12. Ensure the bolt with the copper washer is correctly located. Refit the solenoid/fairing bracket to the front two bolts. Tighten the cover bolts to **9 Nm**.



1. Left hand engine cover

2. Copper washer position

3. Solenoid bracket

13. **Daytona 675 only:** Refit the left hand lower fairing (see page 16-22).

14. Reconnect the battery, positive (red) lead first.

15. Refit the seat (see page 16-17).

Alternator Rectifier

The rectifier does not contain any serviceable parts and must be replaced if faulty.

Daytona 675 up to VIN 381274, Street Triple and Street Triple R all VINs

The alternator rectifier is located in between the rear suspension unit and the gearbox. To access the rectifier connector, remove the fuel tank (see page 10-89).

Daytona 675 from VIN 381275

The alternator rectifier is located under the cockpit's right hand infill panel. To access the rectifier, remove the right hand lower fairing (see page 16-20).

Alternator Stator

The stator is an assembly of 18 coils, arranged into three phases. It is possible to check for continuity, and short circuits through the coils to earth.

Note:

- Only repairs to the stator harness between the connector and the harness entry point into the crankcase are permitted.


- Do not attempt to repair the stator coils.
- If the battery is not fully charged, the charging voltage may be lower than specified when checking at 2000 rpm.
- Ensure all additional accessories (auxiliary lights, heated grips etc.) are switched off.

Fault Code	Possible cause	Action
Battery not charging	Fuse at the starter solenoid	Check the condition of fuse.
	Battery	Check the condition of the battery. Test the battery using the BatteryMate 150-9. Refer to the instructions supplied with the BatteryMate 150-9. Ensure the battery is serviceable:-
	Alternator	Proceed to pinpoint test 1.
	Rectifier/Regulator	Test the rectifier/regulator (see page 17-38).

Pinpoint Tests

Test	Result	Action
1 Check cable and terminal integrity: - Battery positive (+) - Battery negative (-) - Rectifier/regulator to main wiring harness connector pin 1 - Rectifier/regulator to main wiring harness connector pin 2 - Rectifier/regulator to main wiring harness connector pin 3 - Rectifier/regulator to main wiring harness connector pin 4	OK	Proceed to test 2
	Faulty	Rectify fault, proceed to test 6
2 Check cable and terminal integrity: - Rectifier/regulator to alternator harness connector pin 1 - Rectifier/regulator to alternator harness connector pin 2 - Rectifier/regulator to alternator harness connector pin 3	OK	Disconnect the battery leads, negative (black) lead first. Disconnect rectifier/regulator to main wiring harness connector (4 pin). Proceed to test 3
	Faulty	Rectify fault, proceed to test 6

Test	Result	Action
3 Check cable continuity: - Rectifier/regulator main harness connector pin 1 to battery lead negative - Rectifier/regulator main harness connector pin 2 to battery lead negative - Rectifier/regulator main harness connector pin 3 to battery lead positive - Rectifier/regulator main harness connector pin 4 to battery lead positive	OK	Reconnect the battery leads, positive (red) lead first. Reconnect the rectifier/regulator to main wiring harness connector (4 pin). Disconnect the rectifier/regulator to alternator harness connector (3 pin). Proceed to test 4
	Open circuit	Locate and rectify wiring fault, proceed to test 6
4 Check resistance through the coils: - Alternator harness pin 1 to 2 - Alternator harness pin 2 to 3 - Alternator harness pin 3 to 1	0.4Ω to 0.6Ω	Proceed to test 5
	Open circuit or short circuit	If the fault is between the connector and the crankcase, repair the harness. Proceed to test 6 If the fault is after the crankcase, replace the unit. Proceed to test 6
5 Check for short to earth: - Alternator harness pin 1 to metal frame - Alternator harness pin 2 to metal frame - Alternator harness pin 3 to metal frame	Open circuit	Proceed to test 6
	Short circuit	Replace unit. Proceed to test 6
6 Reconnect the harness and run the engine. Check the charging voltage at 2000 rpm:	13.5V to 15V	Action complete - quit test
	Fault still present	Test rectifier/regulator (see page 17-38) If rectifier/regulator is serviceable, contact Triumph service



Rectifier/Regulator

Internally the rectifier/regulator consists of:

- six diodes;
- a voltage controller and three thyristors.

The diodes are arranged with one diode connected between each yellow input wire and each pair of red and black output wires.

The diodes convert the ac voltage to dc voltage.

Each yellow input wire is also connected to a thyristor which is in turn connected to ground. When the dc voltage at the battery reaches the required level, the voltage controller sends a signal to all three thyristors. The

thyristors then conduct and effectively short circuit the stator until the dc voltage drops to an acceptable level.

It is possible for any number of these diodes to fail, reducing the power output of the unit. This may not be obvious until maximum power is required by the ignition, lighting and accessories etc.

The diodes can be checked using a multimeter on DIODE setting.

Note:


- **This test does not check for voltage regulation.**

Fault Code	Possible cause	Action
Battery not charging	Fuse at the starter solenoid	Check the condition of the fuse:
	Battery	Check the condition of the battery. Test the battery using the BatteryMate 150-9. Refer to the instructions supplied with the BatteryMate 150-9. Ensure the battery is serviceable.
	Rectifier/Regulator	Disconnect the rectifier regulator connectors from the main wiring harness and the alternator harness. Proceed to pinpoint test 1.
	Alternator	Test the alternator stator (see page 17-36).

Pinpoint Tests

Test	Result	Action
1 Check the earth and power for continuity: - Rectifier/regulator connector pin 1 to pin 2 - Rectifier/regulator connector pin 3 to pin 4	OK	Proceed to test 2
	Open circuit	Rectify wiring fault. Proceed to test 5 If no wiring fault found, replace unit. Proceed to test 5
2 Check diodes forward bias: - Positive (+) probe to Rectifier/regulator connector pin 1 to: Negative (-) probe to alternator connector pin 1 Negative (-) probe to alternator connector pin 2 Negative (-) probe to alternator connector pin 3	0.4V to 0.7V	Proceed to test 3
	Open circuit or short circuit	Replace unit. Proceed to test 5

3 Check diodes forward bias: - Negative (-) probe to Rectifier/regulator connector pin 4 to: Positive (+) probe to alternator connector pin 1 Positive (+) probe to alternator connector pin 2 Positive (+) probe to alternator connector pin 3	0.4V to 0.7V	Proceed to test 3
	Open or short circuit	Replace unit. Proceed to test 5
3 Check diodes reverse bias: - Positive (+) probe to Rectifier/regulator connector pin 4 to: Negative (-) probe to alternator connector pin 1 Negative (-) probe to alternator connector pin 2 Negative (-) probe to alternator connector pin 3	Open circuit or 'OL' on meter	Proceed to test 4
	A voltage reading or short circuit	Replace unit. Proceed to test 5
4 Check diodes reverse bias: - Negative (-) probe to Rectifier/regulator connector pin 1 to: Positive (+) probe to alternator connector pin 1 Positive (+) probe to alternator connector pin 2 Positive (+) probe to alternator connector pin 3	Open circuit or 'OL' on meter	Proceed to test 5
	A voltage reading or short circuit	Replace unit. Proceed to test 5
5 Reconnect the harness and run the engine. Check the charging voltage at 2000 rpm:	13.5V to 15V	Action complete - quit test
	Fault still present	Test rectifier/regulator (see page 17-36) If rectifier/regulator is serviceable, contact Triumph service



Lighting Circuit - Daytona 675 up to VIN 381274


Key to circuit diagram

Key	Item Description
1	Ignition switch
2	Fuse box (Fuse 1 and 3)
3	Starter relay
4	Number plate lamp
5	Tail light
6	Left hand switch cube assembly
7	Main / dip beam switch
8	Pass switch
9	Instrument assembly
10	Oil pressure switch
11	Oil pressure warning light
12	Main beam warning light
13	Headlight

Key to wiring colours

Key	Wiring Colour
B	Black
U	Blue
N	Brown
G	Green
S	Slate / Grey
O	Orange
K	Pink
R	Red
P	Purple
W	White
Y	Yellow
LG	Light Green
LU	Light Blue

Lighting Circuit - Daytona 675 up to VIN 381274



Lighting Circuit - Daytona 675 from VIN 381275


Key to circuit diagram

Key	Item Description
1	Ignition switch
2	Fuse box (Fuse 1 and 3)
3	Starter relay
4	Number plate lamp
5	Tail light
6	Left hand switch cube assembly
7	Main / dip beam switch
8	Pass switch
9	Instrument assembly
10	Oil pressure switch
11	Oil pressure warning light
12	Main beam warning light
13	Headlight

Key to wiring colours

Key	Wiring Colour
B	Black
U	Blue
N	Brown
G	Green
S	Slate / Grey
O	Orange
K	Pink
R	Red
P	Purple
W	White
Y	Yellow
LG	Light Green
LU	Light Blue

Lighting Circuit - Daytona 675 from VIN 381275



Starting and Charging Circuit - Daytona 675 up to VIN 381274


Key to circuit diagram

Key	Item Description
1	Battery
2	Starter solenoid
3	Starter motor
4	Alternator
5	Regulator / rectifier
6	Starter relay
7	Engine control module
8	Ignition switch
9	Fuse box (Fuses 1, 2 and 6)
10	Engine control module relay
11	Instrument assembly
12	RH switchcube
13	Engine stop switch
14	Starter switch
15	Alarm

Key to wiring colours

Key	Wiring Colour
B	Black
U	Blue
N	Brown
G	Green
S	Slate / Grey
O	Orange
K	Pink
R	Red
P	Purple
W	White
Y	Yellow
LG	Light Green
LU	Light Blue

Starting and Charging Circuit - Daytona 675 up to VIN 381274



Starting and Charging Circuit - Daytona 675 from VIN 381275


Key to circuit diagram

Key	Item Description
1	Battery
2	Starter solenoid
3	Starter motor
4	Alternator
5	Regulator / rectifier
6	Starter relay
7	Engine control module
8	Ignition switch
9	Fuse box (Fuses 1, 2 and 6)
10	Engine control module relay
11	Instrument assembly
12	RH switchcube
13	Engine stop switch
14	Starter switch
15	Alarm
16	Fuel pump relay

Key to wiring colours

Key	Wiring Colour
B	Black
U	Blue
N	Brown
G	Green
S	Slate / Grey
O	Orange
K	Pink
R	Red
P	Purple
W	White
Y	Yellow
LG	Light Green
LU	Light Blue

Starting and Charging Circuit - Daytona 675 from VIN 381275



Auxiliary and Accessory Circuit - Daytona 675 up to VIN 381274


Key to circuit diagram

Key	Item Description
1	Fuse box (Fuse 4)
2	Ignition switch
3	Indicator relay
4	Front brake light switch
5	Horn switch
6	Direction indicator switch
7	Horn
8	Rear brake light switch
9	Brake light
10	Instrument assembly
11	Diagnostic connector
12	Direction indicator (Instruments)
13	Alarm LED
14	Front right direction Indicator
15	Front left direction Indicator
16	Alarm unit
17	Rear right direction indicator
18	Rear left direction indicator

Key to wiring colours

Key	Wiring Colour
B	Black
U	Blue
N	Brown
G	Green
S	Slate / Grey
O	Orange
K	Pink
R	Red
P	Purple
W	White
Y	Yellow
LG	Light Green
LU	Light Blue

Auxiliary and Accessory Circuit - Daytona 675 up to VIN 381274



Auxiliary and Accessory Circuit - Daytona 675 from VIN 381275


Key to circuit diagram

Key	Item Description
1	Fuse box (Fuse 4)
2	Ignition switch
3	Indicator relay
4	Front brake light switch
5	Horn switch
6	Direction indicator switch
7	Horn
8	Rear brake light switch
9	Brake light
10	Instrument assembly
11	Diagnostic connector
12	Direction indicator (Instruments)
13	Alarm LED
14	Front right direction Indicator
15	Front left direction Indicator
16	Alarm unit
17	Rear right direction indicator
18	Rear left direction indicator

Key to wiring colours

Key	Wiring Colour
B	Black
U	Blue
N	Brown
G	Green
S	Slate / Grey
O	Orange
K	Pink
R	Red
P	Purple
W	White
Y	Yellow
LG	Light Green
LU	Light Blue

Auxiliary and Accessory Circuit - Daytona 675 from VIN 381275



Lighting Circuit - Street Triple and Street Triple R


Key to circuit diagram

Key	Item Description
1	Fuse box (Fuse 1)
2	Starter relay
3	Main / dip beam switch
4	Pass switch
5	LH dip beam bulb
6	LH main beam bulb
7	LH position lamp
8	RH dip beam bulb
9	RH main beam bulb
10	RH position lamp
11	Instrument assembly
12	Engine sub harness
13	Oil pressure switch
14	Coolant temperature sensor
15	Tail light
16	Number plate lamp
17	Fuse box (Fuse 3)
18	Ignition switch

Key to wiring colours

Key	Wiring Colour
B	Black
U	Blue
N	Brown
G	Green
S	Slate / Grey
O	Orange
K	Pink
R	Red
P	Purple
W	White
Y	Yellow
LG	Light Green
LU	Light Blue

Lighting Circuit - Street Triple and Street Triple R



Starting and Charging Circuit - Street Triple and Street Triple R

Key to circuit diagram

Key	Item Description
1	Battery
2	Starter solenoid
3	Alternator
4	Regulator / rectifier
5	Ignition switch
6	Fuse box (Fuses 1, 2, 4, 5 and 6)
7	Instrument assembly
8	Engine stop switch
9	Starter switch
10	Alarm
11	Fuel pump relay
12	Engine control module
13	Engine control module relay
14	Starter relay
15	Starter motor

Key to wiring colours

Key	Wiring Colour
B	Black
U	Blue
N	Brown
G	Green
S	Slate / Grey
O	Orange
K	Pink
R	Red
P	Purple
W	White
Y	Yellow
LG	Light Green
LU	Light Blue

10

Auxiliary and Accessory Circuit - Street Triple and Street Triple R


Key to circuit diagram

Key	Item Description
1	Fuse box (Fuse 4)
2	Indicator relay
3	Horn
4	LH switch cube
5	Horn switch
6	Direction indicator switch
7	Instrument assembly
8	Direction indicator (Instruments)
9	Alarm LED
10	Front right direction Indicator
11	Front left direction Indicator
12	Alarm unit
13	Rear right direction indicator
14	Rear left direction indicator
15	Diagnostic connector
16	Brake light
17	Rear brake light switch
18	Front brake light switch
19	Ignition switch

Key to wiring colours

Key	Wiring Colour
B	Black
U	Blue
N	Brown
G	Green
S	Slate / Grey
O	Orange
K	Pink
R	Red
P	Purple
W	White
Y	Yellow
LG	Light Green
LU	Light Blue

Auxiliary and Accessory Circuit - Street Triple and Street Triple R



Complete System - Daytona 675 up to VIN 300525 with/without Fuel Pump Relay Modification

Key to circuit diagram

Key	Item Description
1	Instrument assembly
2	Vehicle speed sensor
3	Front brake lever switch
4	Engine stop switch
5	Starter button
6	Exhaust control valve actuator
7	Engine control module
8	Gear position sensor
9	Lambda sensor
10	Fuel injector 1
11	Fuel injector 2
12	Fuel injector 3
13	Secondary air injection solenoid
14	Low fuel sensor
15	Idle speed control actuator
16	Fall detection switch
17	Inlet air temperature sensor
18	Throttle potentiometer
19	Oil pressure switch
20	Coolant temperature sensor
21	Ambient pressure sensor
22	MAP sensor
23	EMS main relay
24	Purge valve
25	Ignition coil 1
26	Ignition Coil 2
27	Ignition coil 3
28	Fuel pump
29	Cooling fan relay
30	Cooling fan
31	Intake flap actuator
32	Sidestand switch
33	Engine ground
34	Crankshaft sensor
35	Diagnostic connector
36	Rear brake lever switch
37	Rear light

38	RH rear indicator
39	Number plate light
40	LH rear indicator
41	Alarm connector (accessory)
42	Starter motor
43	Starter solenoid (fused)
44	Battery
45	Starter relay
46	Rectifier / regulator
47	Alternator
48	Fuse box
49	Ignition switch
50	Clutch lever switch
51	Horn button
52	Direction indicator switch
53	Headlamp dip switch
54	Direction indicator unit
55	LH front indicator
56	LH position light
57	RH position light
58	Dip beam bulb
59	Main beam bulb
60	Horn
61	RH front indicator
62	Fuel pump relay modification
63	Fuel pump relay
64	Engine earth


Complete System - Daytona 675 from VIN 300526 to VIN 323544 with Fuel Pump Relay

Key to circuit diagram

Key	Item Description
1	Instrument assembly
2	Vehicle speed sensor
3	Front brake lever switch
4	Engine stop switch
5	Starter button
6	Exhaust control valve actuator
7	Engine control module
8	Gear position sensor
9	Lambda sensor
10	Fuel injector 1
11	Fuel injector 2
12	Fuel injector 3
13	Secondary air injection solenoid
14	Low fuel sensor
15	Idle speed control actuator
16	Fall detection switch
17	Inlet air temperature sensor
18	Throttle potentiometer
19	Oil pressure switch
20	Coolant temperature sensor
21	Ambient pressure sensor
22	MAP sensor
23	EMS main relay
24	Purge valve
25	Ignition coil 1
26	Ignition Coil 2
27	Ignition coil 3
28	Fuel pump
29	Cooling fan relay
30	Cooling fan
31	Intake flap actuator
32	Sidestand switch
33	Engine ground
34	Crankshaft sensor
35	Diagnostic connector
36	Rear brake lever switch
37	Rear light

38	RH rear indicator
39	Number plate light
40	LH rear indicator
41	Alarm connector (accessory)
42	Starter motor
43	Starter solenoid (fused)
44	Battery
45	Starter relay
46	Rectifier / regulator
47	Alternator
48	Fuse box
49	Ignition switch
50	Clutch lever switch
51	Horn button
52	Direction indicator switch
53	Headlamp dip switch
54	Direction indicator unit
55	LH front indicator
56	LH position light
57	RH position light
58	Dip beam bulb
59	Main beam bulb
60	Horn
61	RH front indicator
62	Fuel pump relay

Circuit Diagram - Complete System - Daytona 675 - From VIN 300526 to VIN 323544 with Fuel Pump Relay



Complete System - Daytona 675 - from VIN 323545 to VIN381274

Key to circuit diagram


Key	Item Description
1	Instrument assembly
2	Vehicle speed sensor
3	Front brake lever switch
4	Engine stop switch
5	Starter button
6	Exhaust control valve actuator
7	Engine control module
8	Gear position sensor
9	Lambda sensor
10	Fuel injector 1
11	Fuel injector 2
12	Fuel injector 3
13	Secondary air injection solenoid
14	Low fuel sensor
15	Idle speed control actuator
16	Fall detection switch
17	Inlet air temperature sensor
18	Throttle potentiometer
19	Oil pressure switch
20	Coolant temperature sensor
21	Ambient pressure sensor
22	MAP sensor
23	EMS main relay
24	Purge valve
25	Ignition coil 1
26	Ignition Coil 2
27	Ignition coil 3
28	Fuel pump
29	Cooling fan relay
30	Cooling fan
31	Intake flap actuator
32	Sidestand switch
33	Engine ground
34	Crankshaft sensor
35	Diagnostic connector
36	Rear brake lever switch
37	Rear light
38	RH rear indicator

39	Number plate light
40	LH rear indicator
41	Alarm connector (accessory)
42	Starter motor
43	Starter solenoid (fused)
44	Battery
45	Starter relay
46	Rectifier / regulator
47	Alternator
48	Fuse box
49	Ignition switch
50	Clutch lever switch
51	Horn button
52	Direction indicator switch
53	Headlamp dip switch
54	Direction indicator unit
55	LH front indicator
56	LH position light
57	RH position light
58	Dip beam bulb
59	Main beam bulb
60	Horn
61	RH front indicator
62	Fuel pump relay

Key to wiring colours

Key	Wiring Colour
B	Black
U	Blue
N	Brown
G	Green
S	Slate / Grey
O	Orange
K	Pink
R	Red
P	Purple
W	White
Y	Yellow
LG	Light Green
LU	Light Blue

Circuit Diagram - Complete System - Daytona 675 - from VIN 323545 to VIN 381274




Complete System - Daytona 675 - from VIN 381275

Key to circuit diagram

Key	Item Description
1	Instrument assembly
2	Vehicle speed sensor
3	Front brake lever switch
4	Engine stop switch
5	Starter button
6	Exhaust control valve actuator
7	Engine control module
8	Gear position sensor
9	Lambda sensor
10	Fuel injector 1
11	Fuel injector 2
12	Fuel injector 3
13	Secondary air injection solenoid
14	Low fuel sensor
15	Idle speed control actuator
16	Fall detection switch
17	Inlet air temperature sensor
18	Throttle potentiometer
19	Oil pressure switch
20	Coolant temperature sensor
21	Ambient pressure sensor
22	MAP sensor
23	EMS main relay
24	Purge valve
25	Ignition coil 1
26	Ignition Coil 2
27	Ignition coil 3
28	Fuel pump
29	Cooling fan relay
30	Cooling fan
31	Intake flap actuator
32	Sidestand switch
33	Engine ground
34	Crankshaft sensor
35	Diagnostic connector
36	Rear brake lever switch
37	Rear light
38	RH rear indicator

39	Number plate light
40	LH rear indicator
41	Alarm connector (accessory)
42	Starter motor
43	Starter solenoid (fused)
44	Battery
45	Starter relay
46	Rectifier / regulator
47	Alternator
48	Fuse box
49	Ignition switch
50	Clutch lever switch
51	Horn button
52	Direction indicator switch
53	Headlamp dip switch
54	Direction indicator unit
55	LH front indicator
56	LH position light
57	RH position light
58	Dip beam bulb
59	Main beam bulb
60	Horn
61	RH front indicator
62	Fuel pump relay
63	Accessory quickshifter

Circuit Diagram - Complete System - Daytona 675 - from VIN 381275



Complete System - Street Triple and Street Triple R

Key to circuit diagram


Key	Item Description
1	Instrument assembly
2	Vehicle speed sensor
3	Front brake lever switch
4	Engine stop switch
5	Starter button
6	Engine control module
7	Gear position sensor
8	Lambda sensor
9	Fuel injector 1
10	Fuel injector 2
11	Fuel injector 3
12	Secondary air injection solenoid
13	Low fuel sensor
14	Idle speed control actuator
15	Fall detection switch
16	Inlet air temperature sensor
17	Throttle potentiometer
18	Oil pressure switch
19	Coolant temperature sensor
20	Ambient pressure sensor
21	MAP sensor
22	EMS main relay
23	Purge valve
24	Ignition coil 1
25	Ignition Coil 2
26	Ignition coil 3
27	Fuel pump relay
28	Fuel pump
29	Cooling fan relay
30	Cooling fan
31	Sidestand switch
32	Engine ground
33	Crankshaft sensor
34	Diagnostic connector
35	Rear brake lever switch
36	Rear light
37	RH rear indicator
38	Number plate light

39	LH rear indicator
40	Alarm connector (accessory)
41	Starter motor
42	Starter solenoid (fused)
43	Battery
44	Starter relay
45	Rectifier / regulator
46	Alternator
47	Fuse box
48	Ignition switch
49	Clutch lever switch
50	Horn button
51	Direction indicator switch
52	Headlamp dip switch
53	Direction indicator unit
54	LH front indicator
55	LH position light
56	LH dip beam bulb
57	LH main beam bulb
58	RH position light
59	RH Dip beam bulb
60	RH main beam bulb
61	Horn
62	RH front indicator

Key to wiring colours

Key	Wiring Colour
B	Black
U	Blue
N	Brown
G	Green
S	Slate / Grey
O	Orange
K	Pink
R	Red
P	Purple
W	White
Y	Yellow
LG	Light Green
LU	Light Blue

Circuit Diagram - Complete System - Street Triple and Street Triple R



This page intentionally left blank

36

37

38

39